

KRONOS Sound Libraries

EXs Expansion Samples



Owner's Manual

KORG

(E) (1)

EXs14 EDM Drums

Thank you for purchasing EXs14 EDM Drums for the Korg KRONOS.

This library includes drum samples, kits, and drum patterns that cover cutting-edge EDM and dance music.

Patterns are provided both for the Drum Track and as RPPR for Sequencer mode. Unlike simple audio loops, you can make even radical changes to tempo without affecting audio quality, and easily change the sounds or edit the rhythms to make them your own.

EXs14 includes approximately 25 MB of PCM samples, 567 Drum Samples, 16 Drum Kits, 16 Programs, 228 Patterns, and 13 Songs (for RPPR).

This owner's manual explains how to install EXs14 on the KRONOS, how to load the Drum Samples, Programs, Drum Kits, Songs and Patterns, and how to purchase an authorization code and authorize the library.

Dance music styles and genres included in RPPR songs

- Electro House
- Progressive House
- Techno/Minimal
- Dub Step
- Glitch Hop
- Trap
- R&B/Funk
- Drum & Bass
- Breaks
- Chill Out/Down Tempo
- Electronica
- Vintage Machine
- KORG Old Machine

About RPPR (Realtime Pattern Play/Recording)

RPPR lets you play patterns (such as EXs14's drum loops) from the keyboard. You can play different patterns from each key, and use multiple keys to play many sounds and phrases simultaneously. Since musical loops (bass, synth riffs, etc.) can also be played simultaneously, you can use RPPR to create or remix entire songs in real-time.

For more information, see "Creating and recording RPPR data" in the Operation Guide.

System requirements

To install EXs14, you'll need:

- KRONOS system version 2.1.2 or later
- Approximately 26 MB or more space on the internal disk

To load the sounds into memory, you'll need:

- Approximately 17 MB free RAM

3 GB of RAM recommended

KRONOS: The KRONOS is shipped from the factory with 2 GB of memory. It is possible to load just EXs14 with the standard 2 GB, but if you want to simultaneously use other EXs options in addition to the preload sounds, we recommend 3 GB of memory. Additional RAM should be installed by authorized Korg service centers only; for more information, see “Installing additional RAM” in the Sampling chapter of the Operation Guide.

KRONOS X: The KRONOS X is shipped from the factory with 3 GB of memory. It is not necessary to add more memory.

To confirm the amount of installed RAM:

1. Press the GLOBAL button to enter the Global mode.
2. Go to the Options Info page.

The amount of installed RAM is shown by the Memory parameter at the top-right of the display, in the System section.

Demo mode

Initially, EXs14 will be in demo mode. You’ll be able to play, edit, and save Programs, Drum Kits, and Songs which use EXs14—but until you purchase an authorization code, their sound will fade out periodically. To purchase an authorization code, go to the online shop at <https://shop.korg.com/kronosSoundLibraries>. For more information, see “Purchasing and authorizing EXs14” on page 11.

Preparations before installing

To install EXs14, you’ll need KRONOS system version 2.1.2 or later, and at least 26 MB of free space on the internal disk.

To check the version of your KRONOS software:

1. Press the front panel GLOBAL button to enter Global mode.
2. Go to the Options Info page.
3. Confirm that the version is 2.1.2 or later. If not, go to <https://shop.korg.com/kronosSupport> and download and install the latest system software.

To check the amount of free space on the internal disk:

1. Press the front panel DISK button to enter Disk mode.
2. Go to the Media Info page.
3. Set the Drive Select parameter to HDD: INTERNAL HD.
4. Confirm that the Free Size is 26 M (MB) or more. If not, please free up space on the disk by removing unnecessary data.

You can remove unwanted files from the disk by using the Utility page’s Delete menu command. If you want to keep the files for your archives, you can use the Copy menu command to save them to an external USB storage device.

Also, data will not be deleted when installing EXs14. However, we recommend that you backup your important data to avoid potential loss.

Installing EXs14

1. Un-zip the downloaded file.

Un-zipping the archive will result in a folder containing several different files and a sub-folder, as shown below.

EXs14 folder contents

File/folder name	Notes
EXs14.exsins	
S014	These are data files used by the installer.
EXs14.tar.gz	
EXs14.PCG	These files contain the Programs, Drum Track Patterns and Drum Kits (PCG) and Songs with RPPR and user patterns (SNG). All of these are included in the installer, but are also provided separately for your convenience.
EXs14.SNG	
Manuals	This folder includes the manual that you're reading now, in English, Japanese, German, and French versions: EXs14_OM_E1.PDF EXs14_OM_F1.PDF EXs14_OM_G1.PDF EXs14_OM_J1.PDF


2. Copy the un-zipped EXs14 folder to a USB storage device, such as flash memory or a USB hard drive.
3. Safely disconnect the USB storage device from your computer.
4. Connect the USB storage device to one of the KRONOS's two USB A ports.
5. Press the DISK button to enter Disk mode.
6. Go to the Disk Utility page.
7. Using the Drive Select menu at the bottom of the page, select the USB storage device.

You may need to wait a few seconds after connecting the device before it is recognized.

8. Open the folder containing the EXs data from step 2.

9. Select the file EXs14.exsins.


The “exsins” suffix stands for “EXs INStaller.”



When a .exsins file is selected, the **Load** button changes to read **Install**. Only one EXs can be installed at a time. If **Multiple Select** is On, **Install** will be disabled.

10. Select Install EXs from the menu, or press the Install button.

The system will check to confirm that the installation files are valid, and that there is sufficient space on the SSD to install the EXs. Next, a dialog box will appear:



Found installer for: [EXs name]

Space required: [nnnn] MB

SSD1: [disk name] [nnnn] GB available

11. Press Install to continue with the installation.

The confirmation message “Are you sure?” will appear.

If you decide to cancel the installation, press the **Cancel** button.

12. Press OK to continue with the installation.

The installation will then begin. This may take a while; a progress bar shows the installation as it proceeds.

Next, the newly installed files will be verified. After the verification has completed successfully, the progress bar will disappear, and the installation is complete. The EXs sample data itself is installed on an invisible, protected part of the disk. To use the EXs, you’ll load its associated files, which will be installed into a new folder named EXs14 EDM Drums within the Korg Options folder, as shown below.

EXs14 EDM Drums folder contents

File/folder name	Notes
EXs14.KSC	This is the Korg Sample Collection file, which lets you load all of the new samples at once.
EXs14.PCG	This file contains the new Programs, Drum Track Patterns and Drum Kits.
EXs14.SNG	This file contains the Songs with RPPR and user patterns.

Note: EXs14.PCG and EXs14.SNG are also included in the unzipped EXs14.zip file. These are identical to the installed EXs14.PCG and EXs14.SNG files. Use them as backups.

Error messages

When installing, error messages may be displayed to indicate problems, as described below.

"Error: invalid option file"

This means that the installation data is corrupted. Copy the file to the USB media again, or if that fails, download the data again.

"Error: not enough disk space for the installation"

This means that the internal disk is too full. Remove data from the disk, backing it up to USB media, in order to free up space.

Loading the new sounds and samples

⚠ Before loading, make sure to back up important data onto the internal disk or a USB storage device. When you load these files into banks and songs in memory, data previously stored in those locations will be overwritten.

Default load locations

By default, the Programs, Drum Kits, and Songs (/User Pattern) will be loaded into the following locations:

- Programs: U-G000...015
- Drum Track Patterns: U230...U405
- Drum Kits: U-G00...15
- Songs: S000...S012


If desired, they can be loaded into different locations as well.

Loading the new sounds and samples

You can load the Programs, Drum Kits, Songs, and Drum Samples into the default locations all at once. To do so:

1. Go to the Disk Load page.
2. Set Drive Select to HDD: INTERNAL HD.
3. Select the Korg Options folder, and press Open.
4. Select the EXs14 EDM Drums folder, and press Open.
5. Select the file EXs14.PCG.
6. Press the Load button.

A dialog box appears.



7. Enable the check-box labeled Load EXs14.SNG too.

This will load the Songs along with the Programs, Drum Track Patterns, and Drum Kits.

8. Set Select .SNG Allocation to Clear.

This will erase any other currently-loaded Songs.

9. Enable the check-box labeled Load EXs14.KSC. too.


This will load the samples along with the Programs and Drum Kits.

- 10. Set Select .KSC Allocation to Append, and Load Method to KSC Setting.**
11. Leave the .PCG Contents parameter set to All.

Below the other parameters, you'll notice a status line showing the Memory Required and Available. (There's also info about whether or not there are enough slots, but this applies to Sampling Mode samples only.)

If the Available value is larger than Memory Required, the text will be in black, and you can proceed.

If the Available value is smaller than Memory Required, it will be shown in red characters. You can free up memory in several different ways; for more information, see "Making room in memory to load EXs14," below.



12. Press OK to load the data.

EXs14 will work in demo mode, fading in and out, until an authorization code is purchased and entered into the KRONOS. For more information, see "Purchasing and authorizing EXs14," below.

Making room in memory to load EXs14

If you've loaded additional EXs or Sampling Mode samples, there may not be enough space to load EXs14 at the same time.

To clear all Sampling Mode samples from within the Load dialog, you can set **Select .KSC Allocation** to **Clear Sampling Mode Data**. This will un-load all Sampling Mode samples, while leaving all EXs samples intact. Make sure that you've saved any edited Sampling Mode samples before doing this!

Alternatively, you can press the Cancel button and make more detailed changes to the loaded samples. For instance, you can go to the Global P0: Basic Setup-Sample Management page to un-load specific Sampling Mode or EXs samples.

Finally, you can revert back to the factory settings by doing the following:


1. Go to the Global P0: Basic Setup-KSC Auto-Load page.
2. Un-check the Auto-Load buttons for all KSCs except for PRELOAD.KSC.
3. Press the Do Auto-Load Now button.

This will first un-load all Sampling Mode and EXs samples, and then revert back to the factory settings.

Automatically loading the EXs14 samples at startup

If you like, you can configure the KRONOS to automatically load the EXs14 Drum Samples at startup. To do so:


1. Press the GLOBAL button to enter Global mode.
2. Go to the Global Basic—KSC Auto-Load page.
3. In the list of KSCs, check the Auto-load box next to EXs14.KSC.



Loading the Programs and Drum Kits into a different bank

1. Follow steps 1–10 under “Loading the new sounds and samples,” above.
 2. Set the .PCG Contents parameter to Bank U-G.
- To the right of this parameter, the To parameter will appear.
3. In the To parameter, select the bank to overwrite.
 4. Press OK.


The Programs and Drum Kits will be loaded into the selected bank.



Selecting the new EXs14 sounds

Programs

1. Press the PROG button to enter Program Mode.
 2. Press the Bank U-G button to select the new bank of Programs.
- Alternatively, if you loaded into a different bank, press the appropriate Bank button.
3. Use the VALUE inc/dec buttons, the VALUE dial, or the on-screen Program Select popup to browse through the new sounds.



Drum Track Patterns

The new Drum Track Patterns are loaded into U230–U405. You can use them in any Program, Combination, or Song. For instance, to assign one of the new patterns to a Program:

1. For an EXi Program, press the Common button in the lower part of the display, and then press the Drum Track tab.
For an HD-1 Program, press the Basic/Vector tab in the lower part of the display, and then press the Drum Track tab.
2. Note the Drum Pattern section, in the upper left of the display.
The Pattern parameter has two popup menus. The one on the left selects between the Preset and User banks; the one on the right selects the pattern within the bank.
3. In the popup menu on the left, select the User bank.
4. In the popup menu on the right, select pattern U230.
5. Make sure that the Shift parameter is set to +00.
6. Press the DRUM TRACK button, and then play on the keyboard; the Drum Pattern will start playing.

You can change both the pattern and the Drum Program (which provides the sounds for the pattern) as the Drum Track continues to play.

7. If you like, select a different Drum Program in the Drum Track Parameters section.

You can also use the Detune parameter to raise or lower the pitch of the drums. For more information, see the chapter “Using the Drum Track” in the Operation Guide.

Songs (for RPPR performance)

Select the song that you want to load, and try out the RPPR function to play the patterns.

1. Press the SEQ button to enter Sequencer mode.
2. Select S000–S012 (if you loaded using “Select .SNG Allocation” Clear).
3. Play notes C#2 or higher to trigger the RPPR patterns.

For more information, see “Creating and recording RPPR data” in the Operation Guide.

EXs14 Programs require the factory preload sounds

The EXs14 Songs use Programs from the factory preload. If the factory banks have been changed, or are not loaded, then the Programs will not sound correctly. If necessary, please first back up your current sounds, and then reload the factory sounds. The factory sounds are stored in the files named PRELOAD.PCG and PRELOAD.KSC in the FACTORY folder on the internal disk.

Purchasing and authorizing EXs14

EXs14 will work in demo mode, fading in and out, until an authorization code is purchased and entered into the KRONOS. To do so:

1. Go to the Global P6: Options Info page.

2. Write down the Public ID, as shown at the top of the display.

Make sure that you've copied it accurately.

3. If you have access to the internet, follow the instructions under “Purchasing option licenses via the internet,” below.

or:

- If you do not have internet access, follow the instructions under “Purchasing option licenses from your Korg distributor,” below.

Purchasing option licenses via the internet

1. Go to <https://shop.korg.com/kronosSoundLibraries>

2. Under the Korg tab, add EXs14 to your cart.

3. When requested, log in to your account.

If you don't already have an account, follow the online instructions to create one. After creating your account, register your KRONOS.

4. Purchase the authorization code for EXs14.

5. After purchasing, you'll receive your authorization code. Note that this code is tied to your Public ID, and will not work on other KRONOS systems.

If you have more than one KRONOS, you'll need to purchase authorizations for each one separately.

6. Once you have the authorization code, follow the instructions under “Authorizing options on the KRONOS,” below.

Purchasing option licenses from your Korg distributor

If you do not have access to the internet, your national Korg distributor will be happy to assist you in purchasing option authorization codes.

- 1. Contact your Korg distributor, and ask them for assistance with purchasing option authorizations for the KRONOS.**

You can find contact information for your Korg distributor by contacting your Korg dealer, or from the following page on the Korg website:
<http://www.korg.com/corporate/distributors/>

- 2. After you purchase the authorization code(s), proceed to "Authorizing options on the KRONOS," below.**

Authorizing options on the KRONOS

- 1. Go to the Global P6: Options Info page.**
- 2. Select the option to authorize from the list of Installed Options.**
- 3. Press the Authorize Selected button.**

The Authorize Selected window will appear.

- 4. Enter the authorization code.**

You'll see the name of the selected option or option bundle at the top of the window. The window also includes an onscreen keyboard, so that you can enter your authorization code.

- 5. Press OK.**

Provided that you entered a valid authorization code, the list will now show the option or option bundle as Authorized, and the audio limitations of Demo mode will be removed.

Support

If you have any questions about the KRONOS Sound Libraries, please contact your national Korg distributor.

You can find contact information for all Korg distributors, world-wide, on the Korg website: <http://www.korg.com/corporate/distributors/>

Voice Name List

Programs

Bank USER-G [HD-1]

#	OSC	Name	Category	Sub Category
000	D	Electro House Kit	Drums	Dance Drums
001	D	Progressive House Kit	Drums	Dance Drums
002	D	Techno / Minimal Kit	Drums	Dance Drums
003	D	Dubstep / Glitch Hop Kit	Drums	Dance Drums
004	D	Trap Kit	Drums	Dance Drums
005	D	R&B / Funk Kit	Drums	Dance Drums
006	D	D&B / Breaks Kit	Drums	Dance Drums
007	D	Chill / Down Tempo Kit	Drums	Dance Drums
008	D	Electronica Kit	Drums	Dance Drums
009	D	Vintage Machine Kit	Drums	Dance Drums
010	D	Korg Vintage Machine Kit	Drums	Dance Drums
011	D	Dance BD Kit [E0~E8]	Drums	Dance Drums
012	D	Dance SD Kit [E0~E8]	Drums	Dance Drums
013	D	Dance Clap Kit [C3~F5]	Drums	Dance Drums
014	D	Dance HH Kit [E0~E8]	Drums	Dance Drums
015	D	Dance Hit Kit [E0~E8]	Drums	Dance Drums

↑ D: Drums program

Drum Kits

U-G00: Electro House Kit

Key	Zone	Drumsample	Bus	Ex
E0	1	EXs14 Mono,444:HH-CI-88-Electro 1-EXs14	IFX4	4
F0	1	EXs14 Mono,445:HH-CI-88-Electro 2-EXs14	IFX4	4
F#0	1	EXs14 Mono,446:HH-Open-88-Electro-EXs14	IFX4	4
G0	1	EXs14 Stereo,2:BD-Techno 2-EXs14-L	IFX2	Off
G#0	1	EXs14 Mono,385:Clap-DDD5-EXs14	IFX3	Off
A0	1	EXs14 Stereo,0:BD-Electro 17-EXs14-L	IFX2	Off
A#0	1	EXs14 Stereo,12:Hi Hat-Electro15-EXs14-L	IFX5	10
B0	1	EXs14 Stereo,25:White Noise -EXs14-L	IFX5	Off
C1	1	EXs14 Mono,10:BD-Electro 11-EXs14	IFX2	Off
C#1	1	EXs14 Mono,8:BD-Electro 09-EXs14	IFX2	Off
D1	1	EXs14 Mono,453:BD-99-Electro 1-EXs14	IFX2	Off
D#1	1	EXs14 Mono,427:BD-88-Electro 1-EXs14	IFX2	Off
E1	1	EXs14 Mono,16:BD-Electro 17-EXs14	IFX2	Off
F1	1	EXs14 Mono,63:SD-Electro 20-EXs14	IFX1	Off
F#1	1	EXs14 Mono,64:SD-Electro 21-EXs14	IFX1	Off
G1	1	EXs14 Mono,52:SD-Electro 09-EXs14	IFX1	Off
G#1	1	EXs14 Mono,51:SD-Electro 08-EXs14	IFX1	Off
A1	1	EXs14 Mono,48:SD-Electro 05-EXs14	IFX1	Off
A#1	1	ROM Mono,537:Crash-Dance 99	IFX4	Off
B1	1	EXs14 Mono,2:BD-Electro 03-EXs14	IFX2	Off
C2	1	EXs14 Mono,2:BD-Electro 03-EXs14	IFX2	Off
C#2	1	EXs14 Mono,15:BD-Electro 16-EXs14	IFX2	Off
D2	1	EXs14 Mono,14:BD-Electro 15-EXs14	IFX2	Off
D#2	1	EXs14 Mono,13:BD-Electro 14-EXs14	IFX2	Off
E2	1	EXs14 Mono,0:BD-Electro 01-EXs14	IFX2	Off
F2	1	EXs14 Mono,59:SD-Electro 16-EXs14	IFX1	Off
F#2	1	EXs14 Mono,48:SD-Electro 05-EXs14	IFX1	Off
G2	1	EXs14 Stereo,5:SD-Electro 27-EXs14	IFX1	Off
G#2	1	EXs14 Mono,62:SD-Electro 19-EXs14	IFX1	Off
A2	1	EXs14 Mono,52:SD-Electro 09-EXs14	IFX1	Off
A#2	1	EXs14 Mono,67:SD-Electro 24-EXs14	IFX1	Off
B2	1	EXs14 Mono,11:BD-Electro 12-EXs14	IFX2	Off
C3	1	EXs14 Mono,12:BD-Electro 13-EXs14	IFX2	Off
C#3	1	EXs14 Mono,353:Rim-DDD1 2-EXs14	IFX1	Off
D3	1	EXs14 Mono,44:SD-Electro 01-EXs14	IFX1	Off
D#3	1	EXs14 Mono,127:Clap-Electro 02-EXs14	IFX5	Off
E3	1	EXs14 Mono,65:SD-Electro 22-EXs14	IFX1	Off
F3	1	EXs14 Mono,142:Tom-Electro-EXs14	IFX3	Off
F#3	1	EXs14 Mono,357:Shaker-DDD1 4-EXs14	IFX5	1
G3	1	EXs14 Mono,142:Tom-Electro-EXs14	IFX3	Off
G#3	1	EXs14 Mono,154:Hi Hat-Electro 03-EXs14	IFX5	1
A3	1	EXs14 Mono,142:Tom-Electro-EXs14	IFX3	Off
A#3	1	EXs14 Mono,152:Hi Hat-Electro 01-EXs14	IFX5	1
B3	1	EXs14 Mono,285:Tom-KPR77 1-EXs14	IFX3	Off
C4	1	EXs14 Mono,285:Tom-KPR77 1-EXs14	IFX3	Off
C#4	1	EXs14 Mono,480:Crash-99-EXs14	IFX5	Off
D4	1	EXs14 Mono,285:Tom-KPR77 1-EXs14	IFX3	Off
D#4	1	EXs14 Mono,481:Ride-99 1-EXs14	IFX5	Off
E4	1	ROM Mono,537:Crash-Dance 99	IFX5	Off
F4	1	EXs14 Mono,482:Ride-99 2-EXs14	IFX5	Off
F#4	1	EXs14 Mono,162:Hi Hat-Electro 11-EXs14	IFX5	2
G4	1	EXs14 Mono,482:Ride-99 2-EXs14	IFX5	Off
G#4	1	EXs14 Mono,157:Hi Hat-Electro 06-EXs14	IFX5	2
A4	1	EXs14 Mono,480:Crash-99-EXs14	IFX5	Off
A#4	1	EXs14 Stereo,13:Hi Hat-Electro16-EXs14-L	IFX5	2
B4	1	EXs14 Mono,392:Ride-DDD5-EXs14	IFX5	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	EXs14 Mono,402:Conga-DDD5 2-EXs14	IFX3	Off
C#5	1	EXs14 Mono,397:Bongo-DDD5 1-EXs14	IFX3	Off
D5	1	EXs14 Mono,401:Conga-DDD5 1-EXs14	IFX3	Off
D#5	1	EXs14 Mono,398:Bongo-DDD5 2-EXs14	IFX3	Off
E5	1	EXs14 Mono,403:Conga-DDD5 3-EXs14	IFX3	Off
F5	1	EXs14 Mono,324:Agogo-DDD1 2-EXs14	IFX3	Off
F#5	1	EXs14 Mono,355:Shaker-DDD1 2-EXs14	IFX3	Off
G5	1	EXs14 Mono,325:Agogo-DDD1 2-EXs14	IFX3	Off
G#5	1	EXs14 Mono,356:Shaker-DDD1 3-EXs14	IFX3	Off
A5	1	EXs14 Mono,377:WD-DDD1 1-EXs14	IFX3	Off
A#5	1	EXs14 Mono,157:Hi Hat-Electro 06-EXs14	IFX3	Off
B5	1	EXs14 Mono,378:WD-DDD1 2-EXs14	IFX3	Off
C6	1	EXs14 Stereo,17:Dance Hit 4-EXs14-L	IFX5	Off
C#6	1	EXs14 Stereo,20:Dance Hit 7-EXs14-L	IFX5	Off
D6	1	EXs14 Stereo,19:Dance Hit 6-EXs14-L	IFX5	Off
D#6	1	EXs14 Stereo,21:Dance Hit 8-EXs14-L	IFX5	Off
E6	1	EXs14 Stereo,19:Dance Hit 6-EXs14-L	IFX5	Off
F6	1	EXs14 Mono,186:Synth Hit 02-EXs14	IFX5	Off
F#6	1	EXs14 Mono,205:Drum Hit 02-EXs14	IFX5	Off
G6	1	EXs14 Mono,187:Synth Hit 03-EXs14	IFX5	Off
G#6	1	EXs14 Mono,202:Synth Hit 18-EXs14	IFX5	Off
A6	1	EXs14 Mono,196:Synth Hit 12-EXs14	IFX5	Off
A#6	1	EXs14 Mono,199:Synth Hit 15-EXs14	IFX5	Off
B6	1	EXs14 Mono,200:Synth Hit 16-EXs14	IFX5	Off
C7	1	EXs14 Stereo,8:Clap-Dance 3-EXs14-L	IFX5	Off
C#7	1	EXs14 Mono,126:Clap-Electro 01-EXs14	IFX5	Off
D7	1	EXs14 Mono,127:Clap-Electro 02-EXs14	IFX5	Off
D#7	1	EXs14 Mono,128:Clap-Electro 03-EXs14	IFX5	Off
E7	1	EXs14 Mono,129:Clap-Electro 04-EXs14	IFX5	Off
F7	1	EXs14 Mono,133:Clap-Electro 08-EXs14	IFX5	Off
F#7	1	EXs14 Mono,287:HH-Closed-KPR77-EXs14	IFX4	3
G7	1	EXs14 Mono,219:Drum Hit 16-EXs14	IFX3	Off
G#7	1	EXs14 Mono,288:HH-Open-KPR77-EXs14	IFX4	3
A7	1	EXs14 Mono,194:Synth Hit 10-EXs14	IFX3	Off
A#7	1	EXs14 Mono,289:Ride-KPR77-EXs14	IFX4	3
B7	1	EXs14 Mono,223:Drum Hit 20-EXs14	IFX3	Off
C8	1	EXs14 Mono,226:Drum Hit 23-EXs14	IFX3	Off
C#8	1	EXs14 Mono,224:Drum Hit 21-EXs14	IFX3	Off
D8	1	EXs14 Mono,258:Acc-Donkama-DE11-EXs14	IFX3	Off
D#8	1	ROM Mono,1156:Voice 42 "Oohh"	IFX3	Off
E8	1	EXs14 Mono,112:SD-Funk 18-EXs14	IFX5	Off

U-G01: Progressive House Kit

Key	Zone	Drumsample	Bus	Ex
E0	1	EXs14 Mono,175:Hi Hat-Funk 06-EXs14	IFX4	4
F0	1	EXs14 Mono,174:Hi Hat-Funk 05-EXs14	IFX4	4
F#0	1	EXs14 Mono,177:Hi Hat-Funk 08-Op-EXs14	IFX4	4
G0	1	EXs14 Mono,131:Clap-Electro 06-EXs14	IFX4	Off
G#0	1	EXs14 Stereo,6:Clap-Dance 1-EXs14-L	IFX4	Off
A0	1	EXs14 Stereo,3:SD-Electro 25-EXs14-L	IFX5	Off
A#0	1	EXs14 Mono,62:SD-Electro 19-EXs14	IFX5	10
B0	1	ROM Mono,39:BD-Trance 1	IFX2	Off
C1	1	EXs14 Stereo,2:BD-Techno 2-EXs14-L	IFX2	Off
C#1	1	EXs14 Mono,11:BD-Electro 12-EXs14	IFX2	Off
D1	1	EXs14 Mono,13:BD-Electro 14-EXs14	IFX2	Off
D#1	1	EXs14 Mono,8:BD-Electro 09-EXs14	IFX2	Off
E1	1	EXs14 Mono,458:BD-99-Electro 6-EXs14	IFX2	Off
F1	1	EXs14 Mono,123:Clap-Dance 3-EXs14-R	IFX1	Off
F#1	1	EXs14 Mono,61:SD-Electro 18-EXs14	IFX1	Off
G1	1	EXs14 Mono,57:SD-Electro 14-EXs14	IFX1	Off
G#1	1	EXs14 Mono,48:SD-Electro 05-EXs14	IFX1	Off
A1	1	EXs14 Mono,58:SD-Electro 15-EXs14	IFX1	Off
A#1	1	ROM Mono,53:Crash Dance 1	IFX4	Off
B1	1	EXs14 Mono,2:BD-Electro 03-EXs14	IFX2	Off
C2	1	EXs14 Mono,6:BD-Electro 07-EXs14	IFX2	Off
C#2	1	EXs14 Mono,5:BD-Electro 06-EXs14	IFX2	Off
D2	1	EXs14 Mono,1:BD-Electro 02-EXs14	IFX2	Off
D#2	1	EXs14 Mono,2:BD-Electro 03-EXs14	IFX2	Off
E2	1	EXs14 Mono,14:BD-Electro 15-EXs14	IFX2	Off
F2	1	EXs14 Mono,115:SD-HipHop 3-EXs14	IFX1	Off
F#2	1	EXs14 Mono,83:SD-Breaks 10-EXs14	IFX1	Off
G2	1	EXs14 Mono,60:SD-Electro 17-EXs14	IFX1	Off
G#2	1	EXs14 Mono,283:SD-KPR77-EXs14	IFX1	Off
A2	1	EXs14 Mono,113:SD-HipHop 1-EXs14	IFX1	Off
A#2	1	EXs14 Mono,44:SD-Electro 01-EXs14	IFX1	Off
B2	1	EXs14 Mono,9:BD-Electro 10-EXs14	IFX2	Off
C3	1	EXs14 Mono,3:BD-Electro 04-EXs14	IFX2	Off
C#3	1	EXs14 Mono,393:Rim-DDD5 1-EXs14	IFX1	Off
D3	1	EXs14 Mono,52:SD-Electro 09-EXs14	IFX1	Off
D#3	1	EXs14 Stereo,6:Clap-Dance 1-EXs14-L	IFX5	Off
E3	1	EXs14 Mono,47:SD-Electro 04-EXs14	IFX1	Off
F3	1	EXs14 Mono,115:SD-HipHop 3-EXs14	IFX3	Off
F#3	1	EXs14 Mono,483:Hi Hat-Cl-99-comp1-EXs14	IFX4	1
G3	1	EXs14 Mono,115:SD-HipHop 3-EXs14	IFX3	Off
G#3	1	EXs14 Mono,486:Hi Hat-Cl-99-comp4-EXs14	IFX4	1
A3	1	EXs14 Mono,115:SD-HipHop 3-EXs14	IFX3	Off
A#3	1	EXs14 Mono,492:Hi Hat-Op-99-comp3-EXs14	IFX4	1
B3	1	EXs14 Mono,555:Tom-Smns 3-EXs14	IFX3	Off
C4	1	EXs14 Mono,555:Tom-Smns 3-EXs14	IFX3	Off
C#4	1	ROM Mono,522:Crash Cymbal 05 f	IFX5	Off
D4	1	EXs14 Mono,555:Tom-Smns 3-EXs14	IFX3	Off
D#4	1	ROM Mono,544:Ride Cymbal 01 ff	IFX5	Off
E4	1	EXs14 Mono,480:Crash-99-EXs14	IFX5	Off
F4	1	EXs14 Mono,481:Ride-99 1-EXs14	IFX5	Off
F#4	1	EXs14 Mono,162:Hi Hat-Electro 11-EXs14	IFX5	2
G4	1	ROM Mono,571:Splash Cymbal 02 ff	IFX5	Off
G#4	1	EXs14 Mono,163:Hi Hat-Electro 12-EXs14	IFX5	2
A4	1	ROM Mono,537:Crash-Dance 99	IFX5	Off
A#4	1	EXs14 Stereo,13:Hi Hat-Electro16-EXs14-L	IFX5	2
B4	1	EXs14 Mono,482:Ride-99 2-EXs14	IFX5	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	EXs14 Mono,378:WD-DDD1 2-EXs14	IFX3	Off
C#5	1	EXs14 Mono,354:Shaker-DDD1 1-EXs14	IFX3	Off
D5	1	EXs14 Mono,377:WD-DDD1 1-EXs14	IFX3	Off
D#5	1	EXs14 Mono,356:Shaker-DDD1 3-EXs14	IFX3	Off
E5	1	EXs14 Mono,358:Tambourine-DDD1 1-EXs14	IFX3	Off
F5	1	EXs14 Mono,359:Tambourine-DDD1 2-EXs14	IFX3	Off
F#5	1	EXs14 Mono,373:WBlock-DDD1 1-EXs14	IFX3	Off
G5	1	EXs14 Mono,360:Tambourine-DDD1 3-EXs14	IFX3	Off
G#5	1	EXs14 Mono,374:WBlock-DDD1 2-EXs14	IFX3	Off
A5	1	EXs14 Mono,373:WBlock-DDD1 1-EXs14	IFX3	Off
A#5	1	EXs14 Mono,405:Claves-DDD5-EXs14	IFX3	Off
B5	1	EXs14 Mono,370:Triangle-DDD1 1-EXs14	IFX3	Off
C6	1	EXs14 Stereo,22:Dance Hit 9-EXs14-L	IFX5	Off
C#6	1	EXs14 Stereo,18:Dance Hit 5-EXs14-L	IFX5	Off
D6	1	EXs14 Mono,225:Drum Hit 22-EXs14	IFX5	Off
D#6	1	EXs14 Mono,217:Drum Hit 14-EXs14	IFX5	Off
E6	1	EXs14 Stereo,15:Dance Hit 2-EXs14-L	IFX5	Off
F6	1	EXs14 Mono,212:Drum Hit 09-EXs14	IFX5	Off
F#6	1	EXs14 Mono,375:WBlock-DDD1 3-EXs14	IFX3	Off
G6	1	EXs14 Mono,213:Drum Hit 10-EXs14	IFX5	Off
G#6	1	EXs14 Mono,376:WBlock-DDD1 4-EXs14	IFX3	Off
A6	1	EXs14 Mono,215:Drum Hit 12-EXs14	IFX5	Off
A#6	1	EXs14 Mono,340:JingleBell-DDD1 1-EXs14	IFX3	Off
B6	1	EXs14 Mono,216:Drum Hit 13-EXs14	IFX5	Off
C7	1	EXs14 Mono,131:Clap-Electro 06-EXs14	IFX5	Off
C#7	1	EXs14 Mono,284:Clap-KPR77-EXs14	IFX5	Off
D7	1	EXs14 Mono,136:Clap-Electro 11-EXs14	IFX5	Off
D#7	1	EXs14 Mono,139:Clap-HipHop 1-EXs14	IFX5	Off
E7	1	EXs14 Mono,265:Cym-Donkama-DE20-EXs14	IFX4	Off
F7	1	EXs14 Mono,232:Dance Hit 3-EXs14-L	IFX5	Off
F#7	1	EXs14 Mono,280:HH-Closed-KPR55-EXs14	IFX5	3
G7	1	EXs14 Mono,237:Dance Hit 5-EXs14-R	IFX5	Off
G#7	1	EXs14 Mono,280:HH-Closed-KPR55-EXs14	IFX5	3
A7	1	ROM Mono,1045:Synth Hit Loop 2	IFX5	Off
A#7	1	ROM Mono,1045:Synth Hit Loop 2	IFX5	Off
B7	1	ROM Mono,1045:Synth Hit Loop 2	IFX5	Off
C8	1	EXs14 Mono,358:Tambourine-DDD1 1-EXs14	IFX3	Off
C#8	1	EXs14 Mono,342:Kiuchi-DDD1 1-EXs14	IFX3	Off
D8	1	EXs14 Mono,359:Tambourine-DDD1 2-EXs14	IFX3	Off
D#8	1	EXs14 Mono,343:Kiuchi-DDD1 2-EXs14	IFX3	Off
E8	1	EXs14 Stereo,13:Hi Hat-Electro16-EXs14-L	IFX3	Off

U-G02: Techno / Minimal Kit

Key	Zone	Drumsample	Bus	Ex
E0	1	ROM Mono,1022:Up Zap	IFX5	Off
F0	1	ROM Mono,1021:Down Zap	IFX5	Off
F#0	1	ROM Mono,1020:Zap 2	IFX5	Off
G0	1	EXs14 Stereo,2:BD-Techno 2-EXs14-L	IFX2	Off
G#0	1	EXs14 Mono,126:Clap-Electro 01-EXs14	IFX5	Off
A0	1	EXs14 Stereo,1:BD-Techno 1-EXs14-L	IFX2	Off
A#0	1	EXs14 Mono,483:Hi Hat-Cl-99-comp1-EXs14	IFX4	5
B0	1	EXs14 Mono,491:Hi Hat-Op-99-comp2-EXs14	IFX4	5
C1	1	EXs14 Stereo,0:BD-Electro 17-EXs14-L	IFX2	Off
C#1	1	EXs14 Mono,451:BD-99 1-EXs14	IFX2	Off
D1	1	EXs14 Mono,429:BD-88-Electro 3-EXs14	IFX2	Off
D#1	1	EXs14 Mono,9:BD-Electro 10-EXs14	IFX2	Off
E1	1	EXs14 Mono,290:BD-DDD1 1-EXs14	IFX2	Off
F1	1	ROM Mono,1174:"Pan"	IFX4	Off
F#1	1	ROM Mono,1144:Voice 30 "Bang"	IFX4	Off
G1	1	EXs14 Mono,72:SD-Electro 27-EXs14-L	IFX1	Off
G#1	1	EXs14 Mono,64:SD-Electro 21-EXs14	IFX1	Off
A1	1	EXs14 Mono,51:SD-Electro 08-EXs14	IFX1	Off
A#1	1	ROM Mono,561:Ride-Dance 99	IFX4	Off
B1	1	ROM Mono,10:BD-05-amb f	IFX2	Off
C2	1	EXs14 Mono,451:BD-99 1-EXs14	IFX2	Off
C#2	1	EXs14 Mono,424:BD-88 3-EXs14	IFX2	Off
D2	1	EXs14 Mono,452:BD-99 2-EXs14	IFX2	Off
D#2	1	EXs14 Mono,457:BD-99-Electro 5-EXs14	IFX2	Off
E2	1	EXs14 Mono,454:BD-99-Electro 2-EXs14	IFX2	Off
F2	1	EXs14 Mono,61:SD-Electro 18-EXs14	IFX1	Off
F#2	1	EXs14 Mono,104:SD-Funk 10-EXs14	IFX1	Off
G2	1	EXs14 Mono,105:SD-Funk 11-EXs14	IFX1	Off
G#2	1	EXs14 Mono,278:SD-KPR55 4-EXs14	IFX1	Off
A2	1	EXs14 Mono,383:SD-DDD5 1-EXs14	IFX1	Off
A#2	1	EXs14 Mono,441:SD-88-Trap 8-EXs14	IFX1	Off
B2	1	EXs14 Mono,424:BD-88 3-EXs14	IFX2	Off
C3	1	EXs14 Mono,452:BD-99 2-EXs14	IFX2	Off
C#3	1	EXs14 Mono,353:Rim-DDD1 2-EXs14	IFX1	Off
D3	1	EXs14 Mono,283:SD-KPR77-EXs14	IFX1	Off
D#3	1	EXs14 Stereo,7:Clap-Dance 2-EXs14-L	IFX1	Off
E3	1	EXs14 Mono,264:SD-Donkama-DE20-EXs14	IFX1	Off
F3	1	EXs14 Mono,386:Tom-DDD5 1-EXs14	IFX3	Off
F#3	1	EXs14 Mono,287:HH-Closed-KPR77-EXs14	IFX4	1
G3	1	EXs14 Mono,386:Tom-DDD5 1-EXs14	IFX3	Off
G#3	1	EXs14 Mono,287:HH-Closed-KPR77-EXs14	IFX4	1
A3	1	EXs14 Mono,386:Tom-DDD5 1-EXs14	IFX3	Off
A#3	1	EXs14 Mono,288:HH-Open-KPR77-EXs14	IFX4	1
B3	1	EXs14 Mono,286:Tom-KPR77 2-EXs14	IFX3	Off
C4	1	EXs14 Mono,286:Tom-KPR77 2-EXs14	IFX3	Off
C#4	1	EXs14 Mono,391:Crash-DDD5-EXs14	IFX4	Off
D4	1	EXs14 Mono,286:Tom-KPR77 2-EXs14	IFX3	Off
D#4	1	EXs14 Mono,392:Ride-DDD5-EXs14	IFX4	Off
E4	1	EXs14 Mono,265:Cym-Donkama-DE20-EXs14	IFX4	Off
F4	1	EXs14 Mono,289:Ride-KPR77-EXs14	IFX4	Off
F#4	1	EXs14 Mono,280:HH-Closed-KPR55-EXs14	IFX4	2
G4	1	EXs14 Mono,481:Ride-99 1-EXs14	IFX5	Off
G#4	1	EXs14 Mono,280:HH-Closed-KPR55-EXs14	IFX4	2
A4	1	EXs14 Mono,256:SD-Donkama-DE11-EXs14	IFX4	Off
A#4	1	EXs14 Mono,281:HH-Open-KPR55-EXs14	IFX4	2
B4	1	ROM Mono,561:Ride-Dance 99	IFX4	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	EXs14 Mono,259:LBongo-DonkamaDE11-EXs14	IFX3	Off
C#5	1	EXs14 Mono,258:Acc-Donkama-DE11-EXs14	IFX5	Off
D5	1	EXs14 Mono,260:LBongo-DonkamaDE11-EXs14	IFX3	Off
D#5	1	EXs14 Mono,262:WBlock-DonkamaDE11-EXs14	IFX3	Off
E5	1	EXs14 Mono,261:Maraca-DonkamaDE11-EXs14	IFX3	Off
F5	1	EXs14 Mono,270:Maraca-DonkamaDE20-EXs14	IFX3	Off
F#5	1	EXs14 Mono,266:Acc-Donkama-DE20-EXs14	IFX5	Off
G5	1	EXs14 Mono,269:Conga-DonkamaDE20-EXs14	IFX3	Off
G#5	1	EXs14 Mono,272:WBlock-DonkamaDE20-EXs14	IFX3	Off
A5	1	EXs14 Mono,271:Claves-DonkamaDE20-EXs14	IFX3	Off
A#5	1	EXs14 Mono,268:LBongo-DonkamaDE20-EXs14	IFX3	Off
B5	1	EXs14 Mono,267:LBongo-DonkamaDE20-EXs14	IFX3	Off
C6	1	EXs14 Mono,193:Synth Hit 09-EXs14	IFX5	Off
C#6	1	EXs14 Mono,196:Synth Hit 12-EXs14	IFX5	Off
D6	1	EXs14 Mono,191:Synth Hit 07-EXs14	IFX5	Off
D#6	1	EXs14 Mono,198:Synth Hit 14-EXs14	IFX5	Off
E6	1	EXs14 Mono,191:Synth Hit 07-EXs14	IFX5	Off
F6	1	EXs14 Mono,195:Synth Hit 11-EXs14	IFX5	Off
F#6	1	EXs14 Mono,194:Synth Hit 10-EXs14	IFX5	Off
G6	1	EXs14 Mono,216:Drum Hit 13-EXs14	IFX5	Off
G#6	1	EXs14 Mono,205:Drum Hit 02-EXs14	IFX5	Off
A6	1	EXs14 Mono,215:Drum Hit 12-EXs14	IFX5	Off
A#6	1	EXs14 Mono,186:Synth Hit 02-EXs14	IFX5	Off
B6	1	EXs14 Stereo,15:Dance Hit 2-EXs14-L	IFX5	Off
C7	1	EXs14 Mono,254:BD-Donkama 1-DE11-EXs14	IFX2	Off
C#7	1	EXs14 Mono,394:Rim-DDD5 2-EXs14	IFX1	7
D7	1	EXs14 Mono,264:SD-Donkama-DE20-EXs14	IFX1	Off
D#7	1	EXs14 Mono,284:Clap-KPR77-EXs14	IFX5	7
E7	1	ROM Mono,996:Perc-Dance 04-Closed	IFX3	Off
F7	1	EXs14 Mono,225:Drum Hit 22-EXs14	IFX5	Off
F#7	1	EXs14 Mono,157:Hi Hat-Electro 06-EXs14	IFX5	3
G7	1	EXs14 Mono,234:Dance Hit 4-EXs14-L	IFX5	Off
G#7	1	EXs14 Mono,159:Hi Hat-Electro 08-EXs14	IFX5	3
A7	1	EXs14 Stereo,18:Dance Hit 5-EXs14-L	IFX5	Off
A#7	1	EXs14 Mono,165:Hi Hat-Electro 14-EXs14	IFX5	3
B7	1	EXs14 Stereo,10:Clap-Electro 12-EXs14-L	IFX5	Off
C8	1	EXs14 Mono,182:Hi Hat-Funk 13-EXs14	IFX5	Off
C#8	1	EXs14 Mono,145:Tom-Breaks 1-EXs14	IFX5	Off
D8	1	EXs14 Mono,183:Hi Hat-Funk 14-EXs14	IFX5	Off
D#8	1	EXs14 Mono,116:SD-HipHop 4-EXs14	IFX5	Off
E8	1	EXs14 Mono,205:Drum Hit 02-EXs14	IFX5	Off

U-G03: Dubstep / Glitch Hop Kit

Key	Zone	Drumsample	Bus	Ex
E0	1	EXs14 Mono,153:Hi Hat-Electro 02-EXs14	IFX4	4
F0	1	EXs14 Mono,153:Hi Hat-Electro 02-EXs14	IFX4	4
F#0	1	EXs14 Mono,152:Hi Hat-Electro 01-EXs14	IFX4	4
G0	1	EXs14 Mono,11:BD-Electro 12-EXs14	IFX2	Off
G#0	1	EXs14 Mono,134:Clap-Electro 09-EXs14	IFX5	Off
A0	1	EXs14 Mono,60:SD-Electro 17-EXs14	IFX3	Off
A#0	1	EXs14 Mono,28:BD-Funk 4-EXs14	IFX2	10
B0	1	EXs14 Mono,37:BD-HipHop 4-EXs14	IFX2	Off
C1	1	EXs14 Mono,430:BD-88-Electro 4-EXs14	IFX2	Off
C#1	1	EXs14 Mono,8:BD-Electro 09-EXs14	IFX2	Off
D1	1	EXs14 Mono,453:BD-99-Electro 1-EXs14	IFX2	Off
D#1	1	EXs14 Mono,30:BD-Funk 6-EXs14	IFX2	Off
E1	1	EXs14 Mono,454:BD-99-Electro 2-EXs14	IFX2	Off
F1	1	EXs14 Mono,49:SD-Electro 06-EXs14	IFX1	Off
F#1	1	EXs14 Mono,117:SD-HipHop 5-EXs14	IFX1	Off
G1	1	EXs14 Mono,115:SD-HipHop 3-EXs14	IFX1	Off
G#1	1	EXs14 Mono,438:SD-88-Trap 5-EXs14	IFX1	Off
A1	1	EXs14 Mono,48:SD-Electro 05-EXs14	IFX1	Off
A#1	1	ROM Mono,535:Crash Dance 1	IFX4	Off
B1	1	EXs14 Mono,2:BD-Electro 03-EXs14	IFX2	Off
C2	1	EXs14 Mono,0:BD-Electro 01-EXs14	IFX2	Off
C#2	1	EXs14 Mono,11:BD-Electro 12-EXs14	IFX2	Off
D2	1	EXs14 Mono,29:BD-Funk 5-EXs14	IFX2	Off
D#2	1	EXs14 Mono,36:BD-HipHop 3-EXs14	IFX2	Off
E2	1	EXs14 Mono,15:BD-Electro 16-EXs14	IFX2	Off
F2	1	EXs14 Mono,67:SD-Electro 24-EXs14	IFX1	Off
F#2	1	EXs14 Stereo,3:SD-Electro 25-EXs14-L	IFX1	Off
G2	1	EXs14 Mono,81:SD-Breaks 08-EXs14	IFX1	Off
G#2	1	EXs14 Mono,48:SD-Electro 05-EXs14	IFX1	Off
A2	1	EXs14 Mono,85:SD-Breaks 12-EXs14	IFX1	Off
A#2	1	EXs14 Mono,45:SD-Electro 02-EXs14	IFX1	Off
B2	1	EXs14 Mono,6:BD-Electro 07-EXs14	IFX2	Off
C3	1	EXs14 Mono,1:BD-Electro 02-EXs14	IFX2	Off
C#3	1	EXs14 Mono,393:Rim-DDD5 1-EXs14	IFX1	Off
D3	1	EXs14 Stereo,3:SD-Electro 25-EXs14-L	IFX1	Off
D#3	1	EXs14 Stereo,9:Clap-Dance 4-EXs14-L	IFX3	Off
E3	1	EXs14 Mono,47:SD-Electro 04-EXs14	IFX1	Off
F3	1	EXs14 Mono,142:Tom-Electro-EXs14	IFX3	Off
F#3	1	EXs14 Mono,448:HiHat-Cl-88 2-Trap-EXs14	IFX4	1
G3	1	EXs14 Mono,142:Tom-Electro-EXs14	IFX3	Off
G#3	1	EXs14 Mono,447:HiHat-Cl-88 1-Trap-EXs14	IFX4	1
A3	1	EXs14 Mono,142:Tom-Electro-EXs14	IFX3	Off
A#3	1	EXs14 Mono,449:HiHat-Open-88-Trap-EXs14	IFX4	1
B3	1	EXs14 Mono,409:Timbale-DDD5-EXs14	IFX3	Off
C4	1	EXs14 Mono,409:Timbale-DDD5-EXs14	IFX3	Off
C#4	1	ROM Mono,535:Crash Dance 1	IFX5	Off
D4	1	EXs14 Mono,409:Timbale-DDD5-EXs14	IFX3	Off
D#4	1	EXs14 Mono,481:Ride-99 1-EXs14	IFX5	Off
E4	1	ROM Mono,537:Crash-Dance 99	IFX5	Off
F4	1	ROM Mono,561:Ride-Dance 99	IFX5	Off
F#4	1	ROM Mono,511:88-HHat Closed	IFX4	2
G4	1	ROM Mono,565:Broken Hi-Hat	IFX5	Off
G#4	1	ROM Mono,511:88-HHat Closed	IFX4	2
A4	1	EXs14 Mono,480:Crash-99-EXs14	IFX5	Off
A#4	1	ROM Mono,512:88-HHat Open	IFX4	2
B4	1	EXs14 Mono,482:Ride-99 2-EXs14	IFX5	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	EXs14 Mono,269:LConga-DonkamaDE20-EXs14	IFX3	Off
C#5	1	ROM Mono,1001:Perc-Dance 07 a	IFX3	Off
D5	1	EXs14 Mono,267:LBongo-DonkamaDE20-EXs14	IFX3	Off
D#5	1	ROM Mono,746:Tambourine 1-Accent	IFX3	Off
E5	1	EXs14 Mono,268:HBongo-DonkamaDE20-EXs14	IFX3	Off
F5	1	ROM Mono,758:Tri.& Tamb. h	IFX3	Off
F#5	1	EXs14 Mono,189:Synth Hit 05-EXs14	IFX5	Off
G5	1	ROM Mono,759:Tri.& Tamb. i	IFX3	Off
G#5	1	EXs14 Mono,197:Synth Hit 13-EXs14	IFX5	Off
A5	1	EXs14 Mono,366:Timbale-DDD1 5-EXs14	IFX3	Off
A#5	1	EXs14 Mono,195:Synth Hit 11-EXs14	IFX5	Off
B5	1	EXs14 Mono,270:Maraca-DonkamaDE20-EXs14	IFX3	Off
C6	1	ROM Mono,967:WD-Kangaroo 5	IFX3	Off
C#6	1	EXs14 Stereo,12:Hi Hat-Electro15-EXs14-L	IFX3	Off
D6	1	ROM Mono,968:WD-Kangaroo 6	IFX3	Off
D#6	1	EXs14 Stereo,13:Hi Hat-Electro16-EXs14-L	IFX3	Off
E6	1	ROM Mono,969:WD-Kangaroo 7	IFX3	Off
F6	1	ROM Mono,1003:Perc-Dance 08	IFX3	Off
F#6	1	ROM Mono,1022:Up Zap	IFX5	Off
G6	1	ROM Mono,948:WD-Big Hand 2	IFX3	Off
G#6	1	ROM Mono,1021:Down Zap	IFX5	5
A6	1	ROM Mono,949:WD-Big Hand 3	IFX3	Off
A#6	1	ROM Mono,1020:Zap 2	IFX5	Off
B6	1	ROM Mono,947:WD-Big Hand 1	IFX3	Off
C7	1	EXs14 Mono,431:BD-88-Trap 1-EXs14	IFX2	Off
C#7	1	ROM Mono,347:88-Rimshot	IFX3	Off
D7	1	ROM Mono,345:88-SD 1 (New)	IFX1	Off
D#7	1	EXs14 Mono,443:Clap-88 2-EXs14	IFX3	Off
E7	1	EXs14 Mono,277:SD-KPR55 3-EXs14	IFX1	Off
F7	1	EXs14 Mono,45:SD-Electro 02-EXs14	IFX5	Off
F#7	1	EXs14 Mono,287:HH-Closed-KPR77-EXs14	IFX4	3
G7	1	ROM Mono,1119:Voice 05	IFX5	Off
G#7	1	EXs14 Mono,288:HH-Open-KPR77-EXs14	IFX4	3
A7	1	ROM Mono,1208:PC Voice 1-05	IFX5	Off
A#7	1	EXs14 Mono,289:Ride-KPR77-EXs14	IFX4	3
B7	1	ROM Mono,1199:Vocoder Voice 20	IFX3	Off
C8	1	ROM Mono,1107:Industry Hit 22	IFX5	Off
C#8	1	ROM Mono,1093:Hammer	IFX3	Off
D8	1	ROM Mono,1098:PianoHit	IFX3	Off
D#8	1	ROM Mono,1094:Industry Hit 11	IFX3	Off
E8	1	ROM Mono,1100:Industry Hit 15	IFX5	Off

U-G04: Trap Kit

Key	Zone	Drumsample	Bus	Ex
E0	1	ROM Mono,498:Hi-Hat WS-Closed a	IFX4	4
F0	1	ROM Mono,499:Hi-Hat WS-Closed b	IFX4	4
F#0	1	ROM Mono,500:Hi-Hat WS-HalfOpen	IFX4	4
G0	1	ROM Mono,573:Finger Snap	IFX5	Off
G#0	1	ROM Mono,581:Hand Claps 2-g	IFX5	Off
A0	1	EXs14 Mono,141:Clap-HipHop 3-EXs14	IFX5	Off
A#0	1	EXs14 Mono,431:BD-88-Trap 1-EXs14	IFX2	6
B0	1	EXs14 Mono,62:SD-Electro 19-EXs14	IFX5	Off
C1	1	EXs14 Mono,34:BD-HipHop 1-EXs14	IFX2	Off
C#1	1	EXs14 Mono,10:BD-Electro 11-EXs14	IFX2	Off
D1	1	EXs14 Mono,38:BD-HipHop 5-EXs14	IFX2	Off
D#1	1	EXs14 Mono,3:BD-Electro 04-EXs14	IFX2	Off
E1	1	EXs14 Mono,36:BD-HipHop 3-EXs14	IFX2	Off
F1	1	EXs14 Mono,278:SD-KPR55 4-EXs14	IFX1	Off
F#1	1	EXs14 Mono,111:SD-Funk 17-EXs14	IFX1	Off
G1	1	EXs14 Mono,112:SD-Funk 18-EXs14	IFX1	Off
G#1	1	EXs14 Stereo,3:SD-Electro 25-EXs14-L	IFX1	Off
A1	1	EXs14 Mono,108:SD-Funk 14-EXs14	IFX1	Off
A#1	1	ROM Mono,538:88-Crash	IFX4	Off
B1	1	ROM Mono,10:BD-05-amb f	IFX2	Off
C2	1	EXs14 Mono,433:BD-88-Trap 3-EXs14	IFX2	Off
C#2	1	EXs14 Mono,433:BD-88-Trap 3-EXs14	IFX2	Off
D2	1	EXs14 Mono,433:BD-88-Trap 3-EXs14	IFX2	Off
D#2	1	EXs14 Mono,431:BD-88-Trap 1-EXs14	IFX2	Off
E2	1	EXs14 Mono,430:BD-88-Electro 4-EXs14	IFX2	Off
F2	1	EXs14 Mono,438:SD-88-Trap 5-EXs14	IFX1	Off
F#2	1	EXs14 Mono,100:SD-Funk 06-EXs14	IFX1	Off
G2	1	EXs14 Mono,439:SD-88-Trap 6-EXs14	IFX1	Off
G#2	1	EXs14 Mono,113:SD-HipHop 1-EXs14	IFX1	Off
A2	1	ROM Mono,345:88:SD 1 (New)	IFX1	Off
A#2	1	EXs14 Mono,383:SD-DDD5 1-EXs14	IFX1	Off
B2	1	EXs14 Mono,432:BD-88-Trap 2-EXs14	IFX2	Off
C3	1	EXs14 Mono,431:BD-88-Trap 1-EXs14	IFX2	Off
C#3	1	ROM Mono,347:88-Rimshot	IFX1	Off
D3	1	EXs14 Mono,441:SD-88-Trap 8-EXs14	IFX1	Off
D#3	1	EXs14 Mono,442:Clap-88 1-EXs14	IFX5	Off
E3	1	EXs14 Mono,436:SD-88-Trap 3-EXs14	IFX1	Off
F3	1	ROM Mono,1012:88-Tom	IFX3	Off
F#3	1	ROM Mono,511:88-HHat Closed	IFX4	2
G3	1	ROM Mono,1012:88-Tom	IFX3	Off
G#3	1	ROM Mono,511:88-HHat Closed	IFX4	2
A3	1	ROM Mono,1012:88-Tom	IFX3	Off
A#3	1	ROM Mono,512:88-HHat Open	IFX4	2
B3	1	EXs14 Mono,286:Tom-KPR77 2-EXs14	IFX3	Off
C4	1	EXs14 Mono,286:Tom-KPR77 2-EXs14	IFX3	Off
C#4	1	ROM Mono,538:88-Crash	IFX4	Off
D4	1	EXs14 Mono,286:Tom-KPR77 2-EXs14	IFX3	Off
D#4	1	ROM Mono,560:Ride Dance 2	IFX4	Off
E4	1	ROM Mono,537:Crash-Dance 99	IFX4	Off
F4	1	ROM Mono,561:Ride-Dance 99	IFX4	Off
F#4	1	EXs14 Mono,448:HiHat-Cl-88 2-Trap-EXs14	IFX4	1
G4	1	ROM Mono,564:China Cymbal 02	IFX4	Off
G#4	1	EXs14 Mono,447:HiHat-Cl-88 1-Trap-EXs14	IFX4	1
A4	1	EXs14 Mono,391:Crash-DDD5-EXs14	IFX5	Off
A#4	1	EXs14 Mono,449:HiHat-Open-88-Trap-EXs14	IFX4	1
B4	1	EXs14 Mono,392:Ride-DDD5-EXs14	IFX5	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	ROM Mono,1013:88-Conga	IFX3	Off
C#5	1	ROM Mono,1015:88-Cowbell	IFX3	Off
D5	1	ROM Mono,1013:88-Conga	IFX3	Off
D#5	1	ROM Mono,1016:88-Maraca	IFX3	Off
E5	1	ROM Mono,347:88-Rimshot	IFX3	Off
F5	1	EXs14 Mono,450:Tublar-Trap-EXs14	L/R	Off
F#5	1	ROM Mono,912:Timpani ff	L/R	Off
G5	1	ROM Mono,1055:Vinyl Hit 2	IFX5	Off
G#5	1	ROM Mono,974:Perc-Dance 01	IFX3	Off
A5	1	ROM Mono,1048:Synth Hit Loop 5	IFX5	Off
A#5	1	ROM Mono,995:Perc-Dance 03-Open	IFX3	Off
B5	1	ROM Mono,1048:Synth Hit Loop 5	IFX5	Off
C6	1	ROM Mono,1024:Orch Hit 2	IFX5	Off
C#6	1	ROM Mono,593:Conga Lo-Heel	IFX3	Off
D6	1	ROM Mono,1025:Orch Hit 3	IFX5	Off
D#6	1	ROM Mono,617:Quinto-Toe	IFX3	Off
E6	1	ROM Mono,1032:Band Hit 2	IFX5	Off
F6	1	ROM Mono,1057:DJ Vinyl Sliced 02	IFX3	Off
F#6	1	ROM Mono,629:Bongo 1 Lo-Slap	IFX5	Off
G6	1	ROM Mono,1131:Voice 17	IFX3	Off
G#6	1	ROM Mono,1117:Voice 03	IFX3	Off
A6	1	ROM Mono,1157:Voice 43 "Go"	IFX3	Off
A#6	1	ROM Mono,1149:Voice 35 "Aow"	IFX3	Off
B6	1	ROM Mono,1125:Voice 11	IFX3	Off
C7	1	ROM Mono,0:BD-01-amb f	IFX2	Off
C#7	1	ROM Mono,242:Sidestick 1 f	IFX1	Off
D7	1	ROM Mono,1027:Orch Hit 5	IFX1	Off
D#7	1	ROM Mono,581:Hand Claps 2-g	IFX5	Off
E7	1	ROM Mono,167:SD-13-dry mp	IFX1	Off
F7	1	EXs14 Mono,246:Scratch 1-EXs14	IFX3	Off
F#7	1	EXs14 Mono,448:HiHat-Cl-88 2-Trap-EXs14	IFX4	3
G7	1	EXs14 Mono,247:Scratch 2-EXs14	IFX3	Off
G#7	1	EXs14 Mono,447:HiHat-Cl-88 1-Trap-EXs14	IFX4	3
A7	1	ROM Mono,1063:DJ Vinyl Sliced 08	IFX3	Off
A#7	1	EXs14 Mono,449:HiHat-Open-88-Trap-EXs14	IFX4	3
B7	1	ROM Mono,1056:DJ Vinyl Sliced 01	IFX3	Off
C8	1	EXs14 Mono,8:BD-Electro 09-EXs14	IFX3	Off
C#8	1	EXs14 Stereo,8:Clap-Dance 3-EXs14-L	IFX3	Off
D8	1	EXs14 Mono,48:SD-Electro 05-EXs14	IFX3	Off
D#8	1	EXs14 Mono,126:Clap-Electro 01-EXs14	IFX5	Off
E8	1	EXs14 Mono,203:Synth Hit 19-EXs14	IFX5	Off

U-G05: R&B / Funk Kit

Key	Zone	Drumsample	Bus	Ex
E0	1	ROM Mono,1280:Vox-Wah Gtr 3	IFX4	Off
F0	1	EXs14 Mono,174:Hi Hat-Funk 05-EXs14	IFX4	7
F#0	1	EXs14 Mono,87:SD-Breaks 14-EXs14	IFX1	Off
G0	1	EXs14 Mono,177:Hi Hat-Funk 08-Op-EXs14	IFX5	7
G#0	1	EXs14 Mono,86:SD-Breaks 13-EXs14	IFX1	Off
A0	1	EXs14 Mono,22:BD-Breaks 4-EXs14	IFX2	Off
A#0	1	ROM Mono,581:Hand Claps 2-g	IFX5	Off
B0	1	ROM Mono,576:Hand Claps 2-b	IFX5	Off
C1	1	EXs14 Mono,30:BD-Funk 6-EXs14	IFX2	Off
C#1	1	EXs14 Mono,11:BD-Electro 12-EXs14	IFX2	Off
D1	1	EXs14 Mono,12:BD-Electro 13-EXs14	IFX2	Off
D#1	1	EXs14 Mono,380:BD-DDD5 1-EXs14	IFX2	Off
E1	1	EXs14 Mono,34:BD-HipHop 1-EXs14	IFX2	Off
F1	1	EXs14 Mono,61:SD-Electro 18-EXs14	IFX1	Off
F#1	1	EXs14 Mono,108:SD-Funk 14-EXs14	IFX1	Off
G1	1	EXs14 Mono,107:SD-Funk 13-EXs14	IFX1	Off
G#1	1	EXs14 Mono,106:SD-Funk 12-EXs14	IFX1	Off
A1	1	EXs14 Mono,105:SD-Funk 11-EXs14	IFX1	Off
A#1	1	ROM Mono,537:Crash-Dance 99	IFX4	Off
B1	1	ROM Mono,8:BD-05-amb mp	IFX2	Off
C2	1	EXs14 Mono,31:BD-Funk 7-EXs14	IFX2	Off
C#2	1	EXs14 Mono,30:BD-Funk 6-EXs14	IFX2	Off
D2	1	EXs14 Mono,29:BD-Funk 5-EXs14	IFX2	Off
D#2	1	EXs14 Mono,28:BD-Funk 4-EXs14	IFX2	Off
E2	1	EXs14 Mono,25:BD-Funk 1-EXs14	IFX2	Off
F2	1	EXs14 Mono,103:SD-Funk 09-EXs14	IFX1	Off
F#2	1	EXs14 Mono,109:SD-Funk 15-EXs14	IFX1	Off
G2	1	EXs14 Mono,99:SD-Funk 05-EXs14	IFX1	Off
G#2	1	EXs14 Mono,101:SD-Funk 07-EXs14	IFX1	Off
A2	1	EXs14 Mono,97:SD-Funk 03-EXs14	IFX1	Off
A#2	1	EXs14 Mono,98:SD-Funk 04-EXs14	IFX1	Off
B2	1	EXs14 Mono,26:BD-Funk 2-EXs14	IFX2	Off
C3	1	EXs14 Mono,27:BD-Funk 3-EXs14	IFX2	Off
C#3	1	EXs14 Mono,396:Stick-DDD5 2-EXs14	IFX1	Off
D3	1	EXs14 Mono,95:SD-Funk 01-EXs14	IFX1	Off
D#3	1	ROM Mono,574:Hand Claps 1	IFX5	Off
E3	1	EXs14 Mono,96:SD-Funk 02-EXs14	IFX1	Off
F3	1	EXs14 Mono,387:Tom-DDD5 2-EXs14	IFX3	Off
F#3	1	EXs14 Mono,170:Hi Hat-Funk 01-EXs14	IFX4	1
G3	1	EXs14 Mono,387:Tom-DDD5 2-EXs14	IFX3	Off
G#3	1	EXs14 Mono,171:Hi Hat-Funk 02-EXs14	IFX4	1
A3	1	EXs14 Mono,387:Tom-DDD5 2-EXs14	IFX3	Off
A#3	1	EXs14 Mono,173:Hi Hat-Funk 04-Op-EXs14	IFX4	1
B3	1	ROM Mono,366:Tom Vintage Lo ff	IFX3	Off
C4	1	ROM Mono,370:Tom Vintage Mid ff	IFX3	Off
C#4	1	ROM Mono,517:Crash Cymbal 01 ff	IFX4	Off
D4	1	ROM Mono,374:Tom Vintage Hi ff	IFX3	Off
D#4	1	ROM Mono,543:Ride Cymbal 01 f	IFX4	Off
E4	1	ROM Mono,529:Crash Cymbal 08 mf	IFX4	Off
F4	1	ROM Mono,549:Ride Cymbal 03 ff	IFX4	Off
F#4	1	EXs14 Mono,444:HH-Cl-88-Electro 1-EXs14	IFX4	2
G4	1	ROM Mono,571:Splash Cymbal 02 ff	IFX4	Off
G#4	1	EXs14 Mono,445:HH-Cl-88-Electro 2-EXs14	IFX4	2
A4	1	ROM Mono,522:Crash Cymbal 05 f	IFX4	Off
A#4	1	EXs14 Mono,446:HH-Open-88-Electro-EXs14	IFX4	2
B4	1	ROM Mono,554:Ride Cymbal 05 f	IFX4	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	ROM Mono,586:Conga Lo-Open f	IFX3	Off
C#5	1	ROM Mono,625:Bongo 1 Lo-StickEdge f	IFX3	Off
D5	1	ROM Mono,598:Conga Hi-Open f	IFX3	Off
D#5	1	ROM Mono,632:Bongo 1 Hi-Pops	IFX3	Off
E5	1	ROM Mono,601:Conga Hi-OpenSlap	IFX3	Off
F5	1	ROM Mono,750:Tambourine 2-Accent	IFX3	Off
F#5	1	ROM Mono,792:Shaker 2 b-Push	IFX3	Off
G5	1	ROM Mono,746:Tambourine 1-Accent	IFX3	Off
G#5	1	ROM Mono,793:Shaker 2 b-Pull	IFX3	Off
A5	1	ROM Mono,718:Maracas 2-Push a	IFX3	Off
A#5	1	ROM Mono,795:Shaker 2 d-Push	IFX3	Off
B5	1	ROM Mono,721:Maracas 2-Pull b	IFX3	Off
C6	1	ROM Mono,781:Shaker 1-Pull a	IFX3	Off
C#6	1	ROM Mono,586:Conga Lo-Open f	IFX3	Off
D6	1	ROM Mono,602:Conga Hi-OpenSlapFlam	IFX3	Off
D#6	1	ROM Mono,597:Conga Hi-Open mf	IFX3	Off
E6	1	ROM Mono,605:Conga Hi-Closed	IFX3	Off
F6	1	EXs14 Mono,340:JingleBell-DDD1 1-EXs14	IFX3	Off
F#6	1	EXs14 Mono,194:Synth Hit 10-EXs14	IFX3	Off
G6	1	EXs14 Mono,341:JingleBell-DDD1 2-EXs14	IFX3	Off
G#6	1	ROM Mono,1241:Fireworks	IFX5	Off
A6	1	ROM Mono,759:Tri.& Tamb. i	IFX3	Off
A#6	1	EXs14 Stereo,23:Record Noise 1-EXs14-L	IFX5	Off
B6	1	EXs14 Mono,116:SD-HipHop 4-EXs14	IFX3	Off
C7	1	EXs14 Mono,19:BD-Breaks 1-EXs14	IFX2	Off
C#7	1	EXs14 Stereo,24:Record Noise 2-EXs14-L	IFX3	Off
D7	1	EXs14 Mono,88:SD-Breaks 15-EXs14	IFX1	Off
D#7	1	EXs14 Mono,77:SD-Breaks 04-EXs14	IFX1	Off
E7	1	EXs14 Mono,114:SD-HipHop 2-EXs14	IFX1	Off
F7	1	EXs14 Mono,181:Hi Hat-Funk 12-EXs14	IFX4	Off
F#7	1	EXs14 Mono,163:Hi Hat-Electro 12-EXs14	IFX5	Off
G7	1	EXs14 Mono,182:Hi Hat-Funk 13-EXs14	IFX5	Off
G#7	1	EXs14 Mono,157:Hi Hat-Electro 06-EXs14	IFX5	Off
A7	1	EXs14 Mono,183:Hi Hat-Funk 14-EXs14	IFX5	Off
A#7	1	EXs14 Stereo,13:Hi Hat-Electro 16-EXs14-L	IFX5	Off
B7	1	EXs14 Mono,184:Hi Hat-HipHop-Open-EXs14	IFX5	Off
C8	1	EXs14 Mono,98:SD-Funk 04-EXs14	IFX1	Off
C#8	1	ROM Mono,476:Hi-Hat Dance 11	IFX3	Off
D8	1	EXs14 Stereo,0:BD-Electro 17-EXs14-L	IFX1	Off
D#8	1	EXs14 Mono,233:Dance Hit 3-EXs14-R	IFX5	Off
E8	1	EXs14 Mono,82:SD-Breaks 09-EXs14	IFX1	Off

U-G06: D&B Breaks Kit

Key	Zone	Drumsample	Bus	Ex
E0	1	EXs14 Mono,170:Hi Hat-Funk 01-EXs14	IFX4	4
F0	1	EXs14 Mono,171:Hi Hat-Funk 02-EXs14	IFX4	4
F#0	1	ROM Mono,124:Fireworks	IFX5	Off
G0	1	EXs14 Mono,442:Clap-88 1-EXs14	IFX5	Off
G#0	1	EXs14 Stereo,3:SD-Electro 25-EXs14-L	IFX3	Off
A0	1	EXs14 Mono,68:SD-Electro 25-EXs14-L	IFX2	Off
A#0	1	EXs14 Mono,225:Drum Hit 22-EXs14	IFX3	10
B0	1	EXs14 Mono,47:SD-Electro 04-EXs14	IFX3	Off
C1	1	EXs14 Mono,15:BD-Electro 16-EXs14	IFX2	Off
C#1	1	EXs14 Mono,37:BD-HipHop 4-EXs14	IFX2	Off
D1	1	EXs14 Mono,34:BD-HipHop 1-EXs14	IFX2	Off
D#1	1	EXs14 Mono,9:BD-Electro 10-EXs14	IFX2	Off
E1	1	EXs14 Mono,1:BD-Electro 02-EXs14	IFX2	Off
F1	1	EXs14 Mono,60:SD-Electro 17-EXs14	IFX1	Off
F#1	1	EXs14 Mono,65:SD-Electro 22-EXs14	IFX1	Off
G1	1	EXs14 Mono,111:SD-Funk 17-EXs14	IFX1	Off
G#1	1	EXs14 Mono,84:SD-Breaks 11-EXs14	IFX1	Off
A1	1	EXs14 Mono,51:SD-Electro 08-EXs14	IFX1	Off
A#1	1	ROM Mono,537:Crash-Dance 99	IFX4	Off
B1	1	ROM Mono,0:BD-01-amb f	IFX2	Off
C2	1	EXs14 Mono,432:BD-88-Trap 2-EXs14	IFX2	Off
C#2	1	EXs14 Mono,11:BD-Electro 12-EXs14	IFX2	Off
D2	1	EXs14 Mono,19:BD-Breaks 1-EXs14	IFX2	Off
D#2	1	EXs14 Mono,0:BD-Electro 01-EXs14	IFX2	Off
E2	1	EXs14 Mono,34:BD-HipHop 1-EXs14	IFX2	Off
F2	1	EXs14 Mono,109:SD-Funk 15-EXs14	IFX1	Off
F#2	1	EXs14 Mono,114:SD-HipHop 2-EXs14	IFX1	Off
G2	1	EXs14 Mono,74:SD-Breaks 01-EXs14	IFX1	Off
G#2	1	EXs14 Mono,90:SD-Breaks 17-EXs14	IFX1	Off
A2	1	EXs14 Mono,107:SD-Funk 13-EXs14	IFX1	Off
A#2	1	EXs14 Mono,421:SD-77 2-EXs14	IFX1	Off
B2	1	EXs14 Mono,457:BD-99-Electro 5-EXs14	IFX2	Off
C3	1	EXs14 Mono,33:BD-Funk 9-EXs14	IFX2	Off
C#3	1	EXs14 Mono,393:Rim-DDD5 1-EXs14	IFX1	Off
D3	1	EXs14 Mono,420:SD-77 1-EXs14	IFX1	Off
D#3	1	EXs14 Mono,127:Clap-Electro 02-EXs14	IFX5	Off
E3	1	EXs14 Mono,87:SD-Breaks 14-EXs14	IFX1	Off
F3	1	EXs14 Stereo,11:Tom-Processed-EXs14-L	IFX3	Off
F#3	1	EXs14 Mono,182:Hi Hat-Funk 13-EXs14	IFX4	1
G3	1	EXs14 Stereo,11:Tom-Processed-EXs14-L	IFX3	Off
G#3	1	EXs14 Mono,182:Hi Hat-Funk 13-EXs14	IFX4	1
A3	1	EXs14 Stereo,11:Tom-Processed-EXs14-L	IFX3	Off
A#3	1	ROM Mono,481:Hi-Hat Dance 16	IFX3	1
B3	1	EXs14 Mono,146:Tom-Breaks 2-EXs14	IFX3	Off
C4	1	EXs14 Mono,146:Tom-Breaks 2-EXs14	IFX3	Off
C#4	1	EXs14 Mono,391:Crash-DDD5-EXs14	IFX4	Off
D4	1	EXs14 Mono,146:Tom-Breaks 2-EXs14	IFX3	Off
D#4	1	EXs14 Mono,392:Ride-DDD5-EXs14	IFX5	Off
E4	1	EXs14 Mono,481:Ride-99 1-EXs14	IFX5	Off
F4	1	ROM Mono,561:Ride-Dance 99	IFX5	Off
F#4	1	EXs14 Mono,178:Hi Hat-Funk 09-EXs14	IFX4	2
G4	1	ROM Mono,565:Broken Hi-Hat	IFX4	Off
G#4	1	EXs14 Mono,179:Hi Hat-Funk 10-EXs14	IFX4	2
A4	1	ROM Mono,536:Crash Dance 2	IFX5	Off
A#4	1	EXs14 Mono,180:Hi Hat-Funk 11-Op-EXs14	IFX4	2
B4	1	EXs14 Mono,481:Ride-99 1-EXs14	IFX4	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	EXs14 Mono,107:SD-Funk 13-EXs14	IFX5	Off
C#5	1	EXs14 Mono,431:BD-88-Trap 1-EXs14	IFX5	Off
D5	1	EXs14 Stereo,4:SD-Electro 26-EXs14-L	IFX1	Off
D#5	1	EXs14 Mono,111:SD-Funk 17-EXs14	IFX1	Off
E5	1	EXs14 Mono,110:SD-Funk 16-EXs14	IFX1	Off
F5	1	EXs14 Mono,448:HiHat-Cl-88 2-Trap-EXs14	IFX3	Off
F#5	1	EXs14 Mono,184:Hi Hat-HipHop-Open-EXs14	IFX3	Off
G5	1	EXs14 Mono,435:SD-88-Trap 2-EXs14	IFX1	Off
G#5	1	EXs14 Mono,164:Hi Hat-Electro 13-EXs14	IFX4	Off
A5	1	EXs14 Stereo,23:Record Noise 1-EXs14-L	IFX3	Off
A#5	1	EXs14 Mono,355:Shaker-DDD1 2-EXs14	IFX3	Off
B5	1	EXs14 Mono,358:Tambourine-DDD1 1-EXs14	IFX3	Off
C6	1	EXs14 Stereo,24:Record Noise 2-EXs14-L	IFX3	Off
C#6	1	EXs14 Mono,107:SD-Funk 13-EXs14	IFX1	Off
D6	1	EXs14 Mono,251:Record Noise 2-EXs14-R	IFX3	Off
D#6	1	EXs14 Mono,20:BD-Breaks 2-EXs14	IFX5	Off
E6	1	ROM Mono,321:SD-Dance 74	IFX2	Off
F6	1	EXs14 Stereo,10:Clap-Electro 12-EXs14-L	IFX5	Off
F#6	1	EXs14 Mono,302:Bongo-DDD1 11-EXs14	IFX3	Off
G6	1	EXs14 Mono,150:Tom-Breaks 6-EXs14	IFX5	Off
G#6	1	EXs14 Mono,303:Bongo-DDD1 12-EXs14	IFX3	Off
A6	1	EXs14 Mono,150:Tom-Breaks 6-EXs14	IFX5	Off
A#6	1	EXs14 Mono,304:Bongo-DDD1 13-EXs14	IFX5	Off
B6	1	EXs14 Stereo,10:Clap-Electro 12-EXs14-L	IFX3	Off
C7	1	EXs14 Mono,458:BD-99-Electro 6-EXs14	IFX2	Off
C#7	1	EXs14 Mono,394:Rim-DDD5 2-EXs14	IFX1	Off
D7	1	ROM Mono,344:99-SD 2	IFX1	Off
D#7	1	EXs14 Mono,128:Clap-Electro 03-EXs14	IFX3	Off
E7	1	EXs14 Mono,0:BD-Electro 01-EXs14	IFX1	Off
F7	1	EXs14 Mono,47:SD-Electro 04-EXs14	IFX4	Off
F#7	1	EXs14 Mono,183:Hi Hat-Funk 14-EXs14	IFX4	Off
G7	1	EXs14 Mono,16:BD-Electro 17-EXs14	IFX3	Off
G#7	1	EXs14 Mono,161:Hi Hat-Electro 10-EXs14	IFX4	Off
A7	1	EXs14 Mono,48:SD-Electro 05-EXs14	IFX1	Off
A#7	1	ROM Mono,119:Vocoder Voice 17	IFX4	Off
B7	1	EXs14 Mono,80:SD-Breaks 07-EXs14	IFX1	Off
C8	1	EXs14 Mono,82:SD-Breaks 09-EXs14	IFX5	Off
C#8	1	ROM Mono,339:SD-WS 08 (Noise)	IFX5	Off
D8	1	EXs14 Mono,47:SD-Electro 04-EXs14	IFX1	Off
D#8	1	EXs14 Mono,46:SD-Electro 03-EXs14	IFX3	Off
E8	1	ROM Mono,1204:PC Voice 1-01 "Two"	IFX3	Off

U-G07: Chill / Down Tempo Kit

Key	Zone	Drumsample	Bus	Ex
E0	1	ROM Mono,414:Hi-Hat Basic 1-Closed mp	IFX4	4
F0	1	ROM Mono,418:Hi-Hat Basic 1-Pedal mp	IFX4	4
F#0	1	ROM Mono,422:Hi-Hat Basic 1-Open mf	IFX4	4
G0	1	ROM Mono,509:99:HHat Closed	IFX4	Off
G#0	1	EXs14 Stereo,23:Record Noise 1-EXs14-L	IFX3	Off
A0	1	EXs14 Mono,249:Record Noise 1-EXs14-R	IFX3	Off
A#0	1	EXs14 Stereo,24:Record Noise 2-EXs14-L	IFX3	Off
B0	1	EXs14 Mono,251:Record Noise 2-EXs14-R	IFX3	Off
C1	1	EXs14 Mono,274:BD-KPR55 2-EXs14	IFX2	Off
C#1	1	EXs14 Mono,11:BD-Electro 12-EXs14	IFX2	Off
D1	1	EXs14 Mono,29:BD-Funk 5-EXs14	IFX2	Off
D#1	1	EXs14 Mono,429:BD-88-Electro 3-EXs14	IFX2	6
E1	1	EXs14 Mono,430:BD-88-Electro 4-EXs14	IFX2	6
F1	1	EXs14 Mono,441:SD-88-Trap 8-EXs14	IFX1	Off
F#1	1	EXs14 Mono,116:SD-HipHop 4-EXs14	IFX1	Off
G1	1	EXs14 Mono,116:SD-HipHop 4-EXs14	IFX1	Off
G#1	1	EXs14 Mono,96:SD-Funk 02-EXs14	IFX1	Off
A1	1	EXs14 Mono,283:SD-KPR77-EXs14	IFX1	Off
A#1	1	ROM Mono,535:Crash Dance 1	IFX4	Off
B1	1	ROM Mono,25:BD-09-dry mf	IFX2	Off
C2	1	EXs14 Mono,429:BD-88-Electro 3-EXs14	IFX2	Off
C#2	1	EXs14 Mono,31:BD-Funk 7-EXs14	IFX2	Off
D2	1	EXs14 Mono,28:BD-Funk 4-EXs14	IFX2	Off
D#2	1	EXs14 Mono,34:BD-HipHop 1-EXs14	IFX2	Off
E2	1	EXs14 Mono,12:BD-Electro 13-EXs14	IFX2	Off
F2	1	EXs14 Mono,107:SD-Funk 13-EXs14	IFX1	Off
F#2	1	EXs14 Mono,103:SD-Funk 09-EXs14	IFX1	Off
G2	1	EXs14 Mono,114:SD-HipHop 2-EXs14	IFX1	Off
G#2	1	EXs14 Mono,100:SD-Funk 06-EXs14	IFX1	Off
A2	1	EXs14 Mono,111:SD-Funk 17-EXs14	IFX1	Off
A#2	1	EXs14 Mono,98:SD-Funk 04-EXs14	IFX1	Off
B2	1	EXs14 Mono,12:BD-Electro 13-EXs14	IFX2	Off
C3	1	EXs14 Mono,428:BD-88-Electro 2-EXs14	IFX2	Off
C#3	1	EXs14 Mono,396:Stick-DDDS 2-EXs14	IFX1	Off
D3	1	EXs14 Mono,99:SD-Funk 05-EXs14	IFX1	Off
D#3	1	EXs14 Mono,132:Clap-Electro 07-EXs14	IFX5	Off
E3	1	EXs14 Mono,283:SD-KPR77-EXs14	IFX1	Off
F3	1	ROM Mono,350:Tom Basic Lo f	IFX3	Off
F#3	1	EXs14 Mono,171:Hi Hat-Funk 02-EXs14	IFX4	1
G3	1	ROM Mono,356:Tom Basic MidHi f	IFX3	Off
G#3	1	EXs14 Mono,172:Hi Hat-Funk 03-EXs14	IFX4	1
A3	1	ROM Mono,360:Tom Basic Hi f	IFX3	Off
A#3	1	EXs14 Mono,173:Hi Hat-Funk 04-Op-EXs14	IFX4	1
B3	1	EXs14 Mono,286:Tom-KPR77 2-EXs14	IFX3	Off
C4	1	EXs14 Mono,286:Tom-KPR77 2-EXs14	IFX3	Off
C#4	1	ROM Mono,515:Crash Cymbal 01 mf	IFX4	Off
D4	1	EXs14 Mono,286:Tom-KPR77 2-EXs14	IFX3	Off
D#4	1	ROM Mono,541:Ride Cymbal 01 mp	IFX4	Off
E4	1	ROM Mono,520:Crash Cymbal 05 mp	IFX4	Off
F4	1	ROM Mono,546:Ride Cymbal 03 mp	IFX4	Off
F#4	1	ROM Mono,511:88:HHat Closed	IFX3	2
G4	1	ROM Mono,566:Splash Cymbal 01 mp	IFX4	Off
G#4	1	ROM Mono,512:88:HHat Open	IFX3	2
A4	1	ROM Mono,524:Crash Cymbal 06 mp	IFX4	Off
A#4	1	ROM Mono,512:88:HHat Open	IFX3	2
B4	1	ROM Mono,550:Ride Cymbal 04 mp	IFX4	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	ROM Mono,618:Bongo 1 Lo-Muffled mp	IFX3	Off
C#5	1	ROM Mono,573:Finger Snap	IFX3	Off
D5	1	ROM Mono,631:Bongo 1 Hi-Open f	IFX3	Off
D#5	1	ROM Mono,578:Hand Claps 2-d	IFX3	Off
E5	1	ROM Mono,633:Bongo 1 Hi-Hightone	IFX3	Off
F5	1	ROM Mono,732:Pandeiro-Jingle b	IFX3	Off
F#5	1	ROM Mono,918:Finger Cymbal	IFX5	Off
G5	1	ROM Mono,733:Pandeiro-Open a	IFX3	Off
G#5	1	ROM Mono,921:Bell Tree-Slow	IFX3	Off
A5	1	ROM Mono,891:Bayo-UpDown a	IFX3	Off
A#5	1	ROM Mono,926:Rainstick 2	IFX5	Off
B5	1	ROM Mono,889:Bayo-Ge	IFX3	Off
C6	1	ROM Mono,751:Tri.& Tamb. a	IFX3	Off
C#6	1	ROM Mono,729:Surdo-Open	IFX3	Off
D6	1	ROM Mono,758:Tri. & Tamb. h	IFX3	Off
D#6	1	ROM Mono,730:Surdo-Mute	IFX3	Off
E6	1	ROM Mono,753:Tri.& Tamb. c	IFX3	Off
F6	1	ROM Mono,799:Shaker 3-Push	IFX3	Off
F#6	1	ROM Mono,1265:Meditation Tree	IFX3	Off
G6	1	ROM Mono,780:Shaker 1-Push b	IFX3	Off
G#6	1	ROM Mono,1260:Noise 2	IFX5	Off
A6	1	ROM Mono,719:Maracas 2-Push b	IFX3	Off
A#6	1	ROM Mono,1261:Cricket Spectrum	IFX5	Off
B6	1	ROM Mono,720:Maracas 2-Pull a	IFX3	Off
C7	1	EXs14 Mono,181:Hi Hat-Funk 12-EXs14	IFX4	Off
C#7	1	EXs14 Mono,184:Hi Hat-HipHop-Open-EXs14	IFX4	Off
D7	1	EXs14 Mono,182:Hi Hat-Funk 13-EXs14	IFX4	Off
D#7	1	EXs14 Mono,174:Hi Hat-Funk 05-EXs14	IFX3	Off
E7	1	EXs14 Mono,183:Hi Hat-Funk 14-EXs14	IFX4	Off
F7	1	EXs14 Mono,157:Hi Hat-Electro 06-EXs14	IFX5	Off
F#7	1	ROM Mono,425:Hi-Hat Basic 2-Closed mp	IFX4	3
G7	1	EXs14 Mono,191:Synth Hit 07-EXs14	IFX3	Off
G#7	1	ROM Mono,426:Hi-Hat Basic 2-Closed mf	IFX4	3
A7	1	EXs14 Stereo,9:Clap-Dance 4-EXs14-L	IFX5	Off
A#7	1	ROM Mono,428:Hi-Hat Basic 2-Open mp	IFX4	3
B7	1	EXs14 Stereo,19:Dance Hit 6-EXs14-L	IFX3	Off
C8	1	EXs14 Mono,20:DB-Breaks 2-EXs14	IFX2	Off
C#8	1	ROM Mono,1373:HarpGliss	IFX5	Off
D8	1	EXs14 Mono,87:SD-Breaks 14-EXs14	IFX5	Off
D#8	1	ROM Mono,1100:Industry Hit 15	IFX5	Off
E8	1	EXs14 Mono,170:Hi Hat-Funk 01-EXs14	IFX4	Off

U-G08: Electronica Kit

Key	Zone	Drumsample	Bus	Ex
E0	1	EXs14 Mono,432:BD-88-Trap 2-EXs14	IFX2	5
F0	1	EXs14 Mono,432:BD-88-Trap 2-EXs14	IFX2	5
F#0	1	EXs14 Mono,442:Clap-88 1-EXs14	IFX3	4
G0	1	EXs14 Mono,432:BD-88-Trap 2-EXs14	IFX2	5
G#0	1	EXs14 Mono,557:Tom-Smns 5-EXs14	IFX3	Off
A0	1	EXs14 Mono,266:Acc-Donkama-DE20-EXs14	IFX2	Off
A#0	1	EXs14 Mono,432:BD-88-Trap 2-EXs14	IFX2	10
B0	1	EXs14 Mono,266:Acc-Donkama-DE20-EXs14	IFX5	Off
C1	1	EXs14 Mono,2:BD-Electro 03-EXs14	IFX2	Off
C#1	1	EXs14 Mono,9:BD-Electro 10-EXs14	IFX2	Off
D1	1	EXs14 Mono,511:BD-Ln-EXs14	IFX2	Off
D#1	1	EXs14 Mono,422:BD-88 1-EXs14	IFX2	Off
E1	1	EXs14 Mono,423:BD-88 2-EXs14	IFX2	Off
F1	1	EXs14 Mono,62:SD-Electro 19-EXs14	IFX1	Off
F#1	1	EXs14 Mono,64:SD-Electro 21-EXs14	IFX1	Off
G1	1	EXs14 Mono,52:SD-Electro 09-EXs14	IFX1	Off
G#1	1	EXs14 Mono,46:SD-Electro 03-EXs14	IFX1	Off
A1	1	EXs14 Mono,512:SD-Ln-EXs14	IFX1	Off
A#1	1	ROM Mono,537:Crash-Dance 99	IFX4	Off
B1	1	EXs14 Mono,2:BD-Electro 03-EXs14	IFX2	Off
C2	1	EXs14 Mono,451:BD-99 1-EXs14	IFX2	Off
C#2	1	EXs14 Mono,426:BD-88 5-EXs14	IFX2	Off
D2	1	EXs14 Mono,274:BD-KPR55 2-EXs14	IFX2	Off
D#2	1	EXs14 Mono,282:BD-KPR77-EXs14	IFX2	Off
E2	1	EXs14 Mono,424:BD-88 3-EXs14	IFX2	Off
F2	1	EXs14 Mono,64:SD-Electro 21-EXs14	IFX1	Off
F#2	1	EXs14 Mono,51:SD-Electro 08-EXs14	IFX1	Off
G2	1	EXs14 Mono,439:SD-88-Trap 6-EXs14	IFX1	Off
G#2	1	EXs14 Mono,82:SD-Breaks 09-EXs14	IFX1	Off
A2	1	EXs14 Mono,415:SD-66-EXs14	IFX1	Off
A#2	1	EXs14 Mono,66:SD-Electro 23-EXs14	IFX1	Off
B2	1	EXs14 Mono,0:BD-Electro 01-EXs14	IFX2	Off
C3	1	EXs14 Mono,452:BD-99 2-EXs14	IFX2	Off
C#3	1	EXs14 Mono,497:Sidestick-DrTr-EXs14	IFX1	Off
D3	1	EXs14 Mono,44:SD-Electro 01-EXs14	IFX1	Off
D#3	1	EXs14 Mono,127:Clap-Electro 02-EXs14	IFX5	Off
E3	1	EXs14 Mono,52:SD-Electro 09-EXs14	IFX1	Off
F3	1	EXs14 Mono,143:Tom-Processed-EXs14-L	IFX3	Off
F#3	1	EXs14 Mono,560:FX-Smns 2-EXs14	IFX5	1
G3	1	EXs14 Mono,143:Tom-Processed-EXs14-L	IFX3	Off
G#3	1	EXs14 Mono,164:Hi Hat-Electro 13-EXs14	IFX5	1
A3	1	EXs14 Mono,143:Tom-Processed-EXs14-L	IFX3	Off
A#3	1	EXs14 Mono,152:Hi Hat-Electro 01-EXs14	IFX5	1
B3	1	EXs14 Mono,279:Tom-KPR55-EXs14	IFX3	Off
C4	1	EXs14 Mono,279:Tom-KPR55-EXs14	IFX3	Off
C#4	1	EXs14 Mono,419:Cym-66-EXs14	IFX4	Off
D4	1	EXs14 Mono,279:Tom-KPR55-EXs14	IFX3	Off
D#4	1	EXs14 Mono,503:Ride-DrTr-EXs14	IFX5	Off
E4	1	EXs14 Mono,527:Crash-Ln-EXs14	IFX5	Off
F4	1	EXs14 Mono,482:Ride-99 2-EXs14	IFX5	Off
F#4	1	EXs14 Mono,164:Hi Hat-Electro 13-EXs14	IFX5	2
G4	1	EXs14 Mono,392:Ride-DDD5-EXs14	IFX5	Off
G#4	1	EXs14 Mono,183:Hi Hat-Funk 14-EXs14	IFX5	2
A4	1	EXs14 Mono,502:Crash-DrTr-EXs14	IFX5	Off
A#4	1	EXs14 Stereo,13:Hi Hat-Electro16-EXs14-L	IFX5	2
B4	1	EXs14 Mono,418:Hi Hat-Open-66-EXs14	IFX5	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	EXs14 Mono,532:Conga-Ln 5-EXs14	IFX3	Off
C#5	1	EXs14 Mono,529:Conga-Ln 2-EXs14	IFX3	Off
D5	1	EXs14 Mono,530:Conga-Ln 3-EXs14	IFX3	Off
D#5	1	EXs14 Mono,531:Conga-Ln 4-EXs14	IFX3	Off
E5	1	EXs14 Mono,528:Conga-Ln 1-EXs14	IFX3	Off
F5	1	EXs14 Mono,484:Hi Hat-Cl-99-comp2-EXs14	IFX4	Off
F#5	1	EXs14 Mono,417:Hi-Hat-Closed-66-EXs14	IFX4	Off
G5	1	EXs14 Mono,490:Hi Hat-Op-99-comp1-EXs14	IFX4	Off
G#5	1	EXs14 Mono,418:Hi-Hat-Open-66-EXs14	IFX3	Off
A5	1	EXs14 Mono,227:Drum Hit 24-EXs14	IFX3	Off
A#5	1	EXs14 Mono,418:Hi-Hat-Open-66-EXs14	IFX5	Off
B5	1	EXs14 Mono,204:Drum Hit 01-EXs14	IFX5	Off
C6	1	EXs14 Mono,259:LBongo-DonkamaDE11-EXs14	IFX3	Off
C#6	1	EXs14 Mono,261:Maraca-DonkamaDE11-EXs14	IFX3	Off
D6	1	EXs14 Mono,260:HBongo-DonkamaDE11-EXs14	IFX3	Off
D#6	1	EXs14 Mono,262:WBlock-DonkamaDE11-EXs14	IFX3	Off
E6	1	EXs14 Mono,271:Claves-DonkamaDE20-EXs14	IFX3	Off
F6	1	EXs14 Mono,267:LBongo-DonkamaDE20-EXs14	IFX3	Off
F#6	1	EXs14 Mono,264:SD-Donkama-DE20-EXs14	IFX3	Off
G6	1	EXs14 Mono,270:Maraca-DonkamaDE20-EXs14	IFX3	Off
G#6	1	EXs14 Mono,455:BD-99-Electro 3-EXs14	IFX3	Off
A6	1	EXs14 Mono,276:SD-KPR55 2-EXs14	IFX1	Off
A#6	1	EXs14 Mono,250:Record Noise 2-EXs14-L	IFX2	Off
B6	1	EXs14 Stereo,11:Tom-Processed-EXs14-L	IFX2	Off
C7	1	EXs14 Stereo,2:BD-Techno 2-EXs14-L	IFX2	Off
C#7	1	ROM Mono,1153:Voice 39 "Uuh"	IFX3	Off
D7	1	EXs14 Mono,420:SD-77 1-EXs14	IFX1	Off
D#7	1	EXs14 Mono,220:Drum Hit 17-EXs14	IFX3	Off
E7	1	EXs14 Mono,189:Synth Hit 05-EXs14	IFX3	Off
F7	1	EXs14 Mono,189:Synth Hit 05-EXs14	IFX5	Off
F#7	1	EXs14 Mono,154:Hi Hat-Electro 03-EXs14	IFX5	3
G7	1	EXs14 Mono,278:SD-KPR55 4-EXs14	IFX3	Off
G#7	1	EXs14 Mono,280:HH-Closed-KPR55-EXs14	IFX4	3
A7	1	EXs14 Mono,222:Drum Hit 19-EXs14	IFX3	Off
A#7	1	EXs14 Mono,289:Ride-KPR77-EXs14	IFX4	3
B7	1	EXs14 Mono,247:Scratch 2-EXs14	IFX3	Off
C8	1	EXs14 Mono,246:Scratch 1-EXs14	IFX3	Off
C#8	1	EXs14 Mono,328:Cowbell-DDD1 1-EXs14	IFX3	Off
D8	1	EXs14 Mono,258:Acc-Donkama-DE11-EXs14	IFX3	Off
D#8	1	EXs14 Mono,330:Cowbell-DDD1 3-EXs14	IFX3	Off
E8	1	EXs14 Mono,304:Bongo-DDD1 13-EXs14	IFX5	Off

U-G09: Vintage Machine Kit

Key	Zone	Drumsample	Bus	Ex
E0	1	EXs14 Mono,559:FX-Smns 1-EXs14	IFX3	Off
F0	1	EXs14 Mono,560:FX-Smns 2-EXs14	IFX3	Off
F#0	1	EXs14 Mono,561:FX-Smns 3-EXs14	IFX3	Off
G0	1	EXs14 Mono,562:FX-Smns 4-EXs14	IFX3	Off
G#0	1	EXs14 Mono,563:FX-Smns 5-EXs14	IFX3	Off
A0	1	EXs14 Mono,564:FX-Smns 6-EXs14	IFX3	Off
A#0	1	EXs14 Mono,565:FX-Smns 7-EXs14	IFX5	Off
B0	1	EXs14 Mono,566:FX-Smns 8-EXs14	IFX5	Off
C1	1	EXs14 Mono,535:BD-Smns 1-EXs14	IFX2	Off
C#1	1	EXs14 Mono,539:BD-Smns 2-EXs14	IFX2	Off
D1	1	EXs14 Mono,536:BD-Smns 2-EXs14	IFX2	Off
D#1	1	EXs14 Mono,537:BD-Smns 3-EXs14	IFX2	Off
E1	1	EXs14 Mono,538:BD-Smns 4-EXs14	IFX2	Off
F1	1	EXs14 Mono,543:SD-Smns 03-EXs14	IFX1	Off
F#1	1	EXs14 Mono,547:SD-Smns 07-EXs14	IFX1	Off
G1	1	EXs14 Mono,541:SD-Smns 01-EXs14	IFX1	Off
G#1	1	EXs14 Mono,546:SD-Smns 06-EXs14	IFX1	Off
A1	1	EXs14 Mono,545:SD-Smns 05-EXs14	IFX1	Off
A#1	1	ROM Mono,561:Ride-Dance 99	IFX4	Off
B1	1	ROM Mono,10:BD-05-amb f	IFX2	Off
C2	1	EXs14 Mono,423:BD-88 2-EXs14	IFX2	Off
C#2	1	EXs14 Mono,511:BD-Ln-EXs14	IFX2	Off
D2	1	EXs14 Mono,425:BD-88 4-EXs14	IFX2	Off
D#2	1	EXs14 Mono,414:BD-66 2-EXs14	IFX2	Off
E2	1	EXs14 Mono,451:BD-99 1-EXs14	IFX2	Off
F2	1	EXs14 Mono,496:SD-DrTr-EXs14	IFX1	Off
F#2	1	EXs14 Mono,512:SD-Ln-EXs14	IFX1	Off
G2	1	EXs14 Mono,440:SD-88-Trap 7-EXs14	IFX1	Off
G#2	1	EXs14 Mono,472:SD-99 12-EXs14	IFX1	Off
A2	1	EXs14 Mono,420:SD-77 1-EXs14	IFX1	Off
A#2	1	EXs14 Mono,415:SD-66-EXs14	IFX1	Off
B2	1	EXs14 Mono,495:BD-DrTr-EXs14	IFX2	Off
C3	1	EXs14 Mono,457:BD-99-Electro 5-EXs14	IFX2	Off
C#3	1	EXs14 Mono,513:Sidestick-Ln-EXs14	IFX1	Off
D3	1	EXs14 Mono,434:SD-88-Trap 1-EXs14	IFX1	Off
D#3	1	EXs14 Mono,514:Clap-Ln-EXs14	IFX1	Off
E3	1	EXs14 Mono,463:SD-99 03-EXs14	IFX1	Off
F3	1	EXs14 Mono,416:Tom-66-EXs14	IFX3	Off
F#3	1	EXs14 Mono,448:HiHat-Cl-88 2-Trap-EXs14	IFX4	1
G3	1	EXs14 Mono,416:Tom-66-EXs14	IFX3	Off
G#3	1	EXs14 Mono,447:HiHat-Cl-88 1-Trap-EXs14	IFX4	1
A3	1	EXs14 Mono,416:Tom-66-EXs14	IFX3	Off
A#3	1	EXs14 Mono,449:HiHat-Open-88-Trap-EXs14	IFX4	1
B3	1	EXs14 Mono,519:Tom-Ln 5-EXs14	IFX3	Off
C4	1	EXs14 Mono,519:Tom-Ln 5-EXs14	IFX3	Off
C#4	1	EXs14 Mono,419:Cym-66-EXs14	IFX4	Off
D4	1	EXs14 Mono,519:Tom-Ln 5-EXs14	IFX3	Off
D#4	1	EXs14 Mono,419:Cym-66-EXs14	IFX4	Off
E4	1	EXs14 Mono,527:Crash-Ln-EXs14	IFX4	Off
F4	1	EXs14 Mono,526:Ride-Ln-EXs14	IFX4	Off
F#4	1	EXs14 Mono,520:Hi Hat-Ln 1-EXs14	IFX4	2
G4	1	EXs14 Mono,481:Ride-99 1-EXs14	IFX4	Off
G#4	1	EXs14 Mono,522:Hi Hat-Ln 3-EXs14	IFX4	2
A4	1	EXs14 Mono,502:Crash-DrTr-EXs14	IFX4	Off
A#4	1	EXs14 Mono,525:Hi Hat-Ln 6-EXs14	IFX4	2
B4	1	EXs14 Mono,503:Ride-DrTr-EXs14	IFX4	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	EXs14 Mono,532:Conga-Ln 5-EXs14	IFX3	Off
C#5	1	EXs14 Mono,531:Conga-Ln 4-EXs14	IFX3	Off
D5	1	EXs14 Mono,530:Conga-Ln 3-EXs14	IFX3	Off
D#5	1	EXs14 Mono,529:Conga-Ln 2-EXs14	IFX3	Off
E5	1	EXs14 Mono,528:Conga-Ln 1-EXs14	IFX3	Off
F5	1	EXs14 Mono,504:Cabasa-DrTr-EXs14	IFX3	Off
F#5	1	EXs14 Mono,417:Hi-Hat-Closed-66-EXs14	IFX4	4
G5	1	EXs14 Mono,505:Cowbell-DrTr-EXs14	IFX3	Off
G#5	1	EXs14 Mono,418:Hi-Hat-Open-66-EXs14	IFX4	4
A5	1	EXs14 Mono,497:Sidestick-DrTr-EXs14	IFX3	Off
A#5	1	EXs14 Mono,418:Hi-Hat-Open-66-EXs14	IFX4	4
B5	1	EXs14 Mono,506:Tambourine-DrTr-EXs14	IFX3	Off
C6	1	EXs14 Mono,499:Tom-DrTr-EXs14	IFX3	Off
C#6	1	EXs14 Mono,533:Cowbell-Ln-EXs14	IFX3	Off
D6	1	EXs14 Mono,499:Tom-DrTr-EXs14	IFX3	Off
D#6	1	EXs14 Mono,534:Tambourine-Ln-EXs14	IFX3	Off
E6	1	EXs14 Mono,499:Tom-DrTr-EXs14	IFX3	Off
F6	1	EXs14 Mono,556:Tom-Smns 4-EXs14	IFX3	Off
F#6	1	EXs14 Mono,500:Hi Hat-Close-DrTr-EXs14	IFX4	3
G6	1	EXs14 Mono,555:Tom-Smns 3-EXs14	IFX3	Off
G#6	1	EXs14 Mono,501:Hi Hat-Open-DrTr-EXs14	IFX4	3
A6	1	EXs14 Mono,554:Tom-Smns 2-EXs14	IFX3	Off
A#6	1	EXs14 Mono,501:Hi Hat-Open-DrTr-EXs14	IFX4	3
B6	1	EXs14 Mono,553:Tom-Smns 1-EXs14	IFX3	Off
C7	1	EXs14 Mono,542:SD-Smns 02-EXs14	IFX3	Off
C#7	1	EXs14 Mono,558:Tom-Smns 6-EXs14	IFX3	Off
D7	1	EXs14 Mono,544:SD-Smns 04-EXs14	IFX3	Off
D#7	1	EXs14 Mono,557:Tom-Smns 5-EXs14	IFX3	Off
E7	1	EXs14 Mono,548:SD-Smns 08-EXs14	IFX5	Off
F7	1	EXs14 Mono,549:SD-Smns 09-EXs14	IFX5	Off
F#7	1	EXs14 Mono,460:BD-99-Electro 8-EXs14	IFX3	Off
G7	1	EXs14 Mono,550:SD-Smns 10-EXs14	IFX5	Off
G#7	1	EXs14 Mono,465:SD-99 05-EXs14	IFX3	Off
A7	1	EXs14 Mono,551:SD-Smns 11-EXs14	IFX5	Off
A#7	1	EXs14 Mono,470:SD-99 10-EXs14	IFX3	Off
B7	1	EXs14 Mono,552:SD-Smns 12-EXs14	IFX5	Off
C8	1	EXs14 Mono,540:BD-Smns 6-EXs14	IFX1	Off
C#8	1	EXs14 Mono,421:SD-77 2-EXs14	IFX1	Off
D8	1	EXs14 Stereo,26:BD-Ln9000-EXs14-L	IFX1	Off
D#8	1	EXs14 Mono,461:SD-99 01-EXs14	IFX1	Off
E8	1	EXs14 Stereo,27:SD-Ln9000-EXs14-L	IFX1	Off

U-G10: Korg Vintage Machine Kit

Key	Zoon	Drumsample	Bus	Ex
E0	1	EXs14 Mono,353:Rim-DDD1 2-EXs14	IFX1	Off
F0	1	EXs14 Mono,352:Rim-DDD1 1-EXs14	IFX1	Off
F#0	1	EXs14 Mono,351:Tsuzumi-DDD1 2-EXs14	IFX3	Off
G0	1	EXs14 Mono,350:Tsuzumi-DDD1 1-EXs14	IFX3	Off
G#0	1	EXs14 Mono,349:Taiko-DDD1 4-EXs14	IFX3	Off
A0	1	EXs14 Mono,348:Taiko-DDD1 3-EXs14	IFX3	Off
A#0	1	EXs14 Mono,347:Taiko-DDD1 2-EXs14	IFX3	10
B0	1	EXs14 Mono,346:Taiko-DDD1 1-EXs14	IFX3	Off
C1	1	EXs14 Mono,290:BD-DDD1 1-EXs14	IFX2	Off
C#1	1	EXs14 Mono,263:BD-Denkama-DE20-EXs14	IFX2	Off
D1	1	EXs14 Mono,282:BD-KPR77-EXs14	IFX2	Off
D#1	1	EXs14 Mono,291:BD-DDD1 2-EXs14	IFX2	Off
E1	1	EXs14 Mono,290:BD-DDD1 1-EXs14	IFX2	Off
F1	1	EXs14 Mono,383:SD-DDD5 1-EXs14	IFX1	Off
F#1	1	EXs14 Mono,277:SD-KPR55 3-EXs14	IFX1	Off
G1	1	EXs14 Mono,275:SD-KPR55 1-EXs14	IFX1	Off
G#1	1	EXs14 Mono,283:SD-KPR77-EXs14	IFX1	Off
A1	1	EXs14 Mono,384:SD-DDD5 2-EXs14	IFX1	Off
A#1	1	ROM Mono,561:Ride-Dance 99	IFX4	Off
B1	1	ROM Mono,10:BD-05-amb f	IFX2	Off
C2	1	EXs14 Mono,282:BD-KPR77-EXs14	IFX2	Off
C#2	1	EXs14 Mono,282:BD-KPR77-EXs14	IFX2	Off
D2	1	EXs14 Mono,274:BD-KPR55 2-EXs14	IFX2	Off
D#2	1	EXs14 Mono,273:BD-KPR55 1-EXs14	IFX2	Off
E2	1	EXs14 Mono,263:BD-Denkama-DE20-EXs14	IFX2	Off
F2	1	EXs14 Mono,383:SD-DDD5 1-EXs14	IFX1	Off
F#2	1	EXs14 Mono,283:SD-KPR77-EXs14	IFX1	Off
G2	1	EXs14 Mono,278:SD-KPR55 4-EXs14	IFX1	Off
G#2	1	EXs14 Mono,277:SD-KPR55 3-EXs14	IFX1	Off
A2	1	EXs14 Mono,276:SD-KPR55 2-EXs14	IFX1	Off
A#2	1	EXs14 Mono,275:SD-KPR55 1-EXs14	IFX1	Off
B2	1	EXs14 Mono,255:BD-Denkama 2-DE11-EXs14	IFX2	Off
C3	1	EXs14 Mono,254:BD-Denkama 1-DE11-EXs14	IFX2	Off
C#3	1	EXs14 Mono,353:Rim-DDD1 2-EXs14	IFX1	Off
D3	1	EXs14 Mono,264:SD-Denkama-DE20-EXs14	IFX1	Off
D#3	1	EXs14 Mono,284:Clap-KPR77-EXs14	IFX3	Off
E3	1	EXs14 Mono,265:Cym-Denkama-DE20-EXs14	IFX1	Off
F3	1	EXs14 Mono,286:Tom-KPR77 2-EXs14	IFX3	Off
F#3	1	EXs14 Mono,261:Maraca-Denkama-DE11-EXs14	IFX4	1
G3	1	EXs14 Mono,286:Tom-KPR77 2-EXs14	IFX3	Off
G#3	1	EXs14 Mono,261:Maraca-Denkama-DE11-EXs14	IFX4	1
A3	1	EXs14 Mono,286:Tom-KPR77 2-EXs14	IFX3	Off
A#3	1	EXs14 Mono,257:Cym-Denkama-DE11-EXs14	IFX4	1
B3	1	EXs14 Mono,408:Tom-DDD5 3-EXs14	IFX3	Off
C4	1	EXs14 Mono,408:Tom-DDD5 3-EXs14	IFX3	Off
C#4	1	EXs14 Mono,265:Cym-Denkama-DE20-EXs14	IFX4	Off
D4	1	EXs14 Mono,408:Tom-DDD5 3-EXs14	IFX3	Off
D#4	1	EXs14 Mono,289:Ride-KPR77-EXs14	IFX4	Off
E4	1	EXs14 Mono,265:Cym-Denkama-DE20-EXs14	IFX4	Off
F4	1	EXs14 Mono,392:Ride-DDD5-EXs14	IFX4	Off
F#4	1	EXs14 Mono,280:HH-Closed-KPR55-EXs14	IFX4	2
G4	1	EXs14 Mono,289:Ride-KPR77-EXs14	IFX4	Off
G#4	1	EXs14 Mono,280:HH-Closed-KPR55-EXs14	IFX4	2
A4	1	EXs14 Mono,391:Crash-DDD5-EXs14	IFX4	Off
A#4	1	EXs14 Mono,281:HH-Open-KPR55-EXs14	IFX4	2
B4	1	EXs14 Mono,392:Ride-DDD5-EXs14	IFX4	Off

Key	Zoon	Drumsample	Bus	Ex
C5	1	EXs14 Mono,259:LBongo-Denkama-DE11-EXs14	IFX3	Off
C#5	1	EXs14 Mono,261:Maraca-Denkama-DE11-EXs14	IFX3	Off
D5	1	EXs14 Mono,260:HBongo-Denkama-DE11-EXs14	IFX3	Off
D#5	1	EXs14 Mono,260:HBongo-Denkama-DE11-EXs14	IFX3	Off
E5	1	EXs14 Mono,262:WBlock-Denkama-DE11-EXs14	IFX3	Off
F5	1	EXs14 Mono,271:Claves-Denkama-DE20-EXs14	IFX3	Off
F#5	1	EXs14 Mono,267:LBongo-Denkama-DE20-EXs14	IFX3	Off
G5	1	EXs14 Mono,269:Conga-Denkama-DE20-EXs14	IFX3	Off
G#5	1	EXs14 Mono,270:Maraca-Denkama-DE20-EXs14	IFX3	Off
A5	1	EXs14 Mono,268:HBongo-Denkama-DE20-EXs14	IFX3	Off
A#5	1	EXs14 Mono,272:WBlock-Denkama-DE20-EXs14	IFX3	Off
B5	1	EXs14 Mono,412:Bass-DDD5-EXs14	IFX3	Off
C6	1	EXs14 Mono,324:Agogo-DDD1 1-EXs14	IFX3	Off
C#6	1	EXs14 Mono,327:Agogo-DDD1 4-EXs14	IFX3	Off
D6	1	EXs14 Mono,325:Agogo-DDD1 2-EXs14	IFX3	Off
D#6	1	EXs14 Mono,410:Agogo-DDD5-EXs14	IFX3	Off
E6	1	EXs14 Mono,326:Agogo-DDD1 3-EXs14	IFX3	Off
F6	1	EXs14 Mono,292:Bongo-DDD1 01-EXs14	IFX3	Off
F#6	1	EXs14 Mono,293:Bongo-DDD1 02-EXs14	IFX3	Off
G6	1	EXs14 Mono,294:Bongo-DDD1 03-EXs14	IFX3	Off
G#6	1	EXs14 Mono,295:Bongo-DDD1 04-EXs14	IFX3	Off
A6	1	EXs14 Mono,296:Bongo-DDD1 05-EXs14	IFX3	Off
A#6	1	EXs14 Mono,297:Bongo-DDD1 06-EXs14	IFX3	Off
B6	1	EXs14 Mono,300:Bongo-DDD1 09-EXs14	IFX3	Off
C7	1	EXs14 Mono,309:Conga-DDD1 04-EXs14	IFX3	Off
C#7	1	EXs14 Mono,363:Timbale-DDD1 2-EXs14	IFX3	Off
D7	1	EXs14 Mono,317:Conga-DDD1 12-EXs14	IFX3	Off
D#7	1	EXs14 Mono,364:Timbale-DDD1 3-EXs14	IFX3	Off
E7	1	EXs14 Mono,319:Conga-DDD1 14-EXs14	IFX3	Off
F7	1	EXs14 Mono,344:Mokugyo-DDD1 1-EXs14	IFX3	Off
F#7	1	EXs14 Mono,345:Mokugyo-DDD1 2-EXs14	IFX3	Off
G7	1	EXs14 Mono,361:Timpani-DDD1-EXs14	IFX3	Off
G#7	1	EXs14 Mono,342:Kiuchi-DDD1 1-EXs14	IFX3	Off
A7	1	EXs14 Mono,343:Kiuchi-DDD1 2-EXs14	IFX3	Off
A#7	1	EXs14 Mono,340:JingleBell-DDD1 1-EXs14	IFX3	Off
B7	1	EXs14 Mono,341:JingleBell-DDD1 2-EXs14	IFX3	Off
C8	1	EXs14 Mono,336:Guiro-DDD1 1-EXs14	IFX3	Off
C#8	1	EXs14 Mono,337:Guiro-DDD1 2-EXs14	IFX3	Off
D8	1	EXs14 Mono,338:Guiro-DDD1 3-EXs14	IFX3	Off
D#8	1	EXs14 Mono,339:Guiro-DDD1 4-EXs14	IFX3	Off
E8	1	EXs14 Mono,379:Whistle-DDD1-EXs14	IFX3	Off
F8	1	EXs14 Mono,361:Timpani-DDD1-EXs14	IFX3	Off

U-G11: Dance BD Kit [E0~E8]

Key	Zone	Drumsample	Bus	Ex
D#0	1	ROM Mono,0:BD-01-amb f	L/R	Off
E0	1	ROM Mono,78:BD-Dance 29	IFX2	Off
F0	1	ROM Mono,44:BD-Ambi	IFX2	Off
F#0	1	ROM Mono,49:BD-Dance 06	IFX2	Off
G0	1	ROM Mono,118:99:BD 1	IFX2	Off
G#0	1	ROM Mono,117:BD-99 Dance 12	IFX2	Off
A0	1	ROM Mono,74:BD-Dance 25	IFX2	Off
A#0	1	ROM Mono,97:BD-Dance 48	IFX2	Off
B0	1	ROM Mono,98:BD-Dance 49	IFX2	Off
C1	1	ROM Mono,99:BD-Dance 50	IFX2	Off
C#1	1	ROM Mono,86:BD-Dance 37	IFX2	Off
D1	1	ROM Mono,56:BD-Hip 3	IFX2	Off
D#1	1	ROM Mono,43:BD-Dance 03	IFX2	Off
E1	1	ROM Mono,58:BD-Dance 12	IFX2	Off
F1	1	ROM Mono,40:BD-Trance 2	IFX2	Off
F#1	1	ROM Mono,39:BD-Trance 1	IFX2	Off
G1	1	EXs14 Mono,457:BD-99-Electro 5-EXs14	IFX2	Off
G#1	1	EXs14 Mono,458:BD-99-Electro 6-EXs14	IFX2	Off
A1	1	EXs14 Mono,459:BD-99-Electro 7-EXs14	IFX2	Off
A#1	1	EXs14 Mono,455:BD-99-Electro 3-EXs14	IFX2	Off
B1	1	EXs14 Mono,456:BD-99-Electro 4-EXs14	IFX2	Off
C2	1	EXs14 Mono,0:BD-Electro 01-EXs14	IFX2	Off
C#2	1	EXs14 Mono,1:BD-Electro 02-EXs14	IFX2	Off
D2	1	EXs14 Mono,2:BD-Electro 03-EXs14	IFX2	Off
D#2	1	EXs14 Mono,3:BD-Electro 04-EXs14	IFX2	Off
E2	1	EXs14 Mono,4:BD-Electro 05-EXs14	IFX2	Off
F2	1	EXs14 Mono,5:BD-Electro 06-EXs14	IFX2	Off
F#2	1	EXs14 Mono,6:BD-Electro 07-EXs14	IFX2	Off
G2	1	EXs14 Mono,6:BD-Electro 07-EXs14	IFX2	Off
G#2	1	EXs14 Mono,8:BD-Electro 09-EXs14	IFX2	Off
A2	1	EXs14 Mono,9:BD-Electro 10-EXs14	IFX2	Off
A#2	1	EXs14 Mono,10:BD-Electro 11-EXs14	IFX2	Off
B2	1	EXs14 Mono,11:BD-Electro 12-EXs14	IFX2	Off
C3	1	EXs14 Mono,12:BD-Electro 13-EXs14	IFX2	Off
C#3	1	EXs14 Mono,13:BD-Electro 14-EXs14	IFX2	Off
D3	1	EXs14 Mono,14:BD-Electro 15-EXs14	IFX2	Off
D#3	1	EXs14 Mono,15:BD-Electro 16-EXs14	IFX2	Off
E3	1	EXs14 Mono,16:BD-Electro 17-EXs14	IFX2	Off
F3	1	EXs14 Stereo,0:BD-Electro 17-EXs14-L	IFX2	Off
F#3	1	EXs14 Mono,427:BD-88-Electro 1-EXs14	IFX2	Off
G3	1	EXs14 Mono,428:BD-88-Electro 2-EXs14	IFX2	Off
G#3	1	EXs14 Mono,453:BD-99-Electro 1-EXs14	IFX2	Off
A3	1	EXs14 Mono,454:BD-99-Electro 2-EXs14	IFX2	Off
A#3	1	EXs14 Mono,19:BD-Breaks 1-EXs14	IFX2	Off
B3	1	EXs14 Mono,20:BD-Breaks 2-EXs14	IFX2	Off
C4	1	EXs14 Mono,21:BD-Breaks 3-EXs14	IFX2	Off
C#4	1	EXs14 Mono,22:BD-Breaks 4-EXs14	IFX2	Off
D4	1	EXs14 Mono,23:BD-Breaks 5-EXs14	IFX2	Off
D#4	1	EXs14 Mono,24:BD-Breaks 6-EXs14	IFX2	Off
E4	1	EXs14 Mono,429:BD-88-Electro 3-EXs14	IFX2	Off
F4	1	EXs14 Mono,430:BD-88-Electro 4-EXs14	IFX2	Off
F#4	1	EXs14 Mono,25:BD-Funk 1-EXs14	IFX2	Off
G4	1	EXs14 Mono,26:BD-Funk 2-EXs14	IFX2	Off
G#4	1	EXs14 Mono,27:BD-Funk 3-EXs14	IFX2	Off
A4	1	EXs14 Mono,28:BD-Funk 4-EXs14	IFX2	Off
A#4	1	EXs14 Mono,29:BD-Funk 5-EXs14	IFX2	Off
B4	1	EXs14 Mono,30:BD-Funk 6-EXs14	IFX2	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	EXs14 Mono,31:BD-Funk 7-EXs14	IFX2	Off
C#5	1	EXs14 Mono,32:BD-Funk 8-EXs14	IFX2	Off
D5	1	EXs14 Mono,33:BD-Funk 9-EXs14	IFX2	Off
D#5	1	EXs14 Mono,34:BD-HipHop 1-EXs14	IFX2	Off
E5	1	EXs14 Mono,35:BD-HipHop 2-EXs14	IFX2	Off
F5	1	EXs14 Mono,36:BD-HipHop 3-EXs14	IFX2	Off
F#5	1	EXs14 Mono,37:BD-HipHop 4-EXs14	IFX2	Off
G5	1	EXs14 Mono,38:BD-HipHop 5-EXs14	IFX2	Off
G#5	1	EXs14 Mono,39:BD-HipHop 6-EXs14	IFX2	Off
A5	1	EXs14 Mono,431:BD-Trap 1-EXs14	IFX2	Off
A#5	1	EXs14 Mono,432:BD-88-Trap 2-EXs14	IFX2	Off
B5	1	EXs14 Mono,254:BD-Donkama 1-DE11-EXs14	IFX2	Off
C6	1	EXs14 Mono,255:BD-Donkama 2-DE11-EXs14	IFX2	Off
C#6	1	EXs14 Mono,263:BD-Donkama-DE20-EXs14	IFX2	Off
D6	1	EXs14 Mono,282:BD-KPR77-EXs14	IFX2	Off
D#6	1	EXs14 Mono,290:BD-DDD1 1-EXs14	IFX2	Off
E6	1	EXs14 Mono,291:BD-DDD1 2-EXs14	IFX2	Off
F6	1	EXs14 Mono,380:BD-DDD5 1-EXs14	IFX2	Off
F#6	1	EXs14 Mono,381:BD-DDD5 2-EXs14	IFX2	Off
G6	1	EXs14 Mono,382:BD-DDD5 3-EXs14	IFX2	Off
G#6	1	EXs14 Mono,433:BD-88-Trap 3-EXs14	IFX2	Off
A6	1	EXs14 Mono,413:BD-66 1-EXs14	IFX2	Off
A#6	1	EXs14 Mono,414:BD-66 2-EXs14	IFX2	Off
B6	1	EXs14 Mono,422:BD-88 1-EXs14	IFX2	Off
C7	1	EXs14 Mono,423:BD-88 2-EXs14	IFX2	Off
C#7	1	EXs14 Mono,424:BD-88 3-EXs14	IFX2	Off
D7	1	EXs14 Mono,425:BD-88 4-EXs14	IFX2	Off
D#7	1	EXs14 Mono,426:BD-88 5-EXs14	IFX2	Off
E7	1	EXs14 Mono,451:BD-99 1-EXs14	IFX2	Off
F7	1	EXs14 Mono,452:BD-99 2-EXs14	IFX2	Off
F#7	1	EXs14 Mono,495:BD-DrTr-EXs14	IFX2	Off
G7	1	EXs14 Mono,511:BD-Ln-EXs14	IFX2	Off
G#7	1	EXs14 Mono,535:BD-Smns 1-EXs14	IFX2	Off
A7	1	EXs14 Mono,536:BD-Smns 2-EXs14	IFX2	Off
A#7	1	EXs14 Mono,537:BD-Smns 3-EXs14	IFX2	Off
B7	1	EXs14 Mono,538:BD-Smns 4-EXs14	IFX2	Off
C8	1	EXs14 Mono,539:BD-Smns 5-EXs14	IFX2	Off
C#8	1	EXs14 Mono,540:BD-Smns 6-EXs14	IFX2	Off
D8	1	EXs14 Stereo,1:BD-Techno 1-EXs14-L	IFX2	Off
D#8	1	EXs14 Stereo,2:BD-Techno 2-EXs14-L	IFX2	Off
E8	1	EXs14 Stereo,26:BD-Ln9000-EXs14-L	IFX2	Off

U-G12: Dance SD Kit [E0~E8]

Key	Zone	Drumsample	Bus	Ex
D#0	1	ROM Mono,0:BD-01-amb f	L/R	Off
E0	1	EXs14 Mono,415:SD-66-EXs14	IFX1	Off
F0	1	EXs14 Mono,479:SD-99 19-EXs14	IFX1	Off
F#0	1	EXs14 Mono,474:SD-99 14-EXs14	IFX1	Off
G0	1	EXs14 Mono,461:SD-99 01-EXs14	IFX1	Off
G#0	1	EXs14 Mono,435:SD-88-Trap 2-EXs14	IFX1	Off
A0	1	EXs14 Mono,436:SD-88-Trap 3-EXs14	IFX1	Off
A#0	1	EXs14 Mono,437:SD-88-Trap 4-EXs14	IFX1	Off
B0	1	EXs14 Mono,438:SD-88-Trap 5-EXs14	IFX1	Off
C1	1	EXs14 Mono,439:SD-88-Trap 6-EXs14	IFX1	Off
C#1	1	EXs14 Mono,440:SD-88-Trap 7-EXs14	IFX1	Off
D1	1	EXs14 Mono,420:SD-77 1-EXs14	IFX1	Off
D#1	1	EXs14 Mono,421:SD-77 2-EXs14	IFX1	Off
E1	1	EXs14 Mono,384:SD-DDD5 2-EXs14	IFX1	Off
F1	1	EXs14 Mono,383:SD-DDD5 1-EXs14	IFX1	Off
F#1	1	EXs14 Mono,283:SD-KPR77-EXs14	IFX1	Off
G1	1	EXs14 Mono,278:SD-KPR55 4-EXs14	IFX1	Off
G#1	1	EXs14 Mono,277:SD-KPR55 3-EXs14	IFX1	Off
A1	1	EXs14 Mono,276:SD-KPR55 2-EXs14	IFX1	Off
A#1	1	EXs14 Mono,275:SD-KPR55 1-EXs14	IFX1	Off
B1	1	EXs14 Mono,264:SD-Donkama-DE20-EXs14	IFX1	Off
C2	1	EXs14 Mono,44:SD-Electro 01-EXs14	IFX1	Off
C#2	1	EXs14 Mono,45:SD-Electro 02-EXs14	IFX1	Off
D2	1	EXs14 Mono,46:SD-Electro 03-EXs14	IFX1	Off
D#2	1	EXs14 Mono,47:SD-Electro 04-EXs14	IFX1	Off
E2	1	EXs14 Mono,48:SD-Electro 05-EXs14	IFX1	Off
F2	1	EXs14 Mono,49:SD-Electro 06-EXs14	IFX1	Off
F#2	1	EXs14 Mono,50:SD-Electro 07-EXs14	IFX1	Off
G2	1	EXs14 Mono,51:SD-Electro 08-EXs14	IFX1	Off
G#2	1	EXs14 Mono,52:SD-Electro 09-EXs14	IFX1	Off
A2	1	EXs14 Mono,53:SD-Electro 10-EXs14	IFX1	Off
A#2	1	EXs14 Mono,54:SD-Electro 11-EXs14	IFX1	Off
B2	1	EXs14 Mono,55:SD-Electro 12-EXs14	IFX1	Off
C3	1	EXs14 Mono,56:SD-Electro 13-EXs14	IFX1	Off
C#3	1	EXs14 Mono,57:SD-Electro 14-EXs14	IFX1	Off
D3	1	EXs14 Mono,58:SD-Electro 15-EXs14	IFX1	Off
D#3	1	EXs14 Mono,59:SD-Electro 16-EXs14	IFX1	Off
E3	1	EXs14 Mono,60:SD-Electro 17-EXs14	IFX1	Off
F3	1	EXs14 Mono,61:SD-Electro 18-EXs14	IFX1	Off
F#3	1	EXs14 Mono,62:SD-Electro 19-EXs14	IFX1	Off
G3	1	EXs14 Mono,63:SD-Electro 20-EXs14	IFX1	Off
G#3	1	EXs14 Mono,64:SD-Electro 21-EXs14	IFX1	Off
A3	1	EXs14 Mono,65:SD-Electro 22-EXs14	IFX1	Off
A#3	1	EXs14 Mono,66:SD-Electro 23-EXs14	IFX1	Off
B3	1	EXs14 Mono,67:SD-Electro 24-EXs14	IFX1	Off
C4	1	EXs14 Stereo,3:SD-Electro 25-EXs14-L	IFX1	Off
C#4	1	EXs14 Stereo,4:SD-Electro 26-EXs14-L	IFX1	Off
D4	1	EXs14 Stereo,5:SD-Electro 27-EXs14-L	IFX1	Off
D#4	1	EXs14 Mono,74:SD-Breaks 01-EXs14	IFX1	Off
E4	1	EXs14 Mono,75:SD-Breaks 02-EXs14	IFX1	Off
F4	1	EXs14 Mono,76:SD-Breaks 03-EXs14	IFX1	Off
F#4	1	EXs14 Mono,77:SD-Breaks 04-EXs14	IFX1	Off
G4	1	EXs14 Mono,78:SD-Breaks 05-EXs14	IFX1	Off
G#4	1	EXs14 Mono,79:SD-Breaks 06-EXs14	IFX1	Off
A4	1	EXs14 Mono,80:SD-Breaks 07-EXs14	IFX1	Off
A#4	1	EXs14 Mono,81:SD-Breaks 08-EXs14	IFX1	Off
B4	1	EXs14 Mono,82:SD-Breaks 09-EXs14	IFX1	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	EXs14 Mono,83:SD-Breaks 10-EXs14	IFX1	Off
C#5	1	EXs14 Mono,84:SD-Breaks 11-EXs14	IFX1	Off
D5	1	EXs14 Mono,85:SD-Breaks 12-EXs14	IFX1	Off
D#5	1	EXs14 Mono,86:SD-Breaks 13-EXs14	IFX1	Off
E5	1	EXs14 Mono,87:SD-Breaks 14-EXs14	IFX1	Off
F5	1	EXs14 Mono,88:SD-Breaks 15-EXs14	IFX1	Off
F#5	1	EXs14 Mono,89:SD-Breaks 16-EXs14	IFX1	Off
G5	1	EXs14 Mono,90:SD-Breaks 17-EXs14	IFX1	Off
G#5	1	EXs14 Mono,91:SD-Breaks 18-EXs14	IFX1	Off
A5	1	EXs14 Mono,92:SD-Breaks 19-EXs14	IFX1	Off
A#5	1	EXs14 Mono,93:SD-Breaks 20-EXs14	IFX1	Off
B5	1	EXs14 Mono,94:SD-Breaks 21-EXs14	IFX1	Off
C6	1	EXs14 Mono,441:SD-88-Trap 8-EXs14	IFX1	Off
C#6	1	EXs14 Mono,95:SD-Funk 01-EXs14	IFX1	Off
D6	1	EXs14 Mono,96:SD-Funk 02-EXs14	IFX1	Off
D#6	1	EXs14 Mono,97:SD-Funk 03-EXs14	IFX1	Off
E6	1	EXs14 Mono,98:SD-Funk 04-EXs14	IFX1	Off
F6	1	EXs14 Mono,99:SD-Funk 05-EXs14	IFX1	Off
F#6	1	EXs14 Mono,100:SD-Funk 06-EXs14	IFX1	Off
G6	1	EXs14 Mono,101:SD-Funk 07-EXs14	IFX1	Off
G#6	1	EXs14 Mono,102:SD-Funk 08-EXs14	IFX1	Off
A6	1	EXs14 Mono,103:SD-Funk 09-EXs14	IFX1	Off
A#6	1	EXs14 Mono,104:SD-Funk 10-EXs14	IFX1	Off
B6	1	EXs14 Mono,105:SD-Funk 11-EXs14	IFX1	Off
C7	1	EXs14 Mono,106:SD-Funk 12-EXs14	IFX1	Off
C#7	1	EXs14 Mono,107:SD-Funk 13-EXs14	IFX1	Off
D7	1	EXs14 Mono,108:SD-Funk 14-EXs14	IFX1	Off
D#7	1	EXs14 Mono,109:SD-Funk 15-EXs14	IFX1	Off
E7	1	EXs14 Mono,110:SD-Funk 16-EXs14	IFX1	Off
F7	1	EXs14 Mono,111:SD-Funk 17-EXs14	IFX1	Off
F#7	1	EXs14 Mono,112:SD-Funk 18-EXs14	IFX1	Off
G7	1	EXs14 Mono,113:SD-HipHop 1-EXs14	IFX1	Off
G#7	1	EXs14 Mono,114:SD-HipHop 2-EXs14	IFX1	Off
A7	1	EXs14 Mono,115:SD-HipHop 3-EXs14	IFX1	Off
A#7	1	EXs14 Mono,116:SD-HipHop 4-EXs14	IFX1	Off
B7	1	EXs14 Mono,117:SD-HipHop 5-EXs14	IFX1	Off
C8	1	EXs14 Stereo,27:SD-Ln9000-EXs14-L	IFX1	Off
C#8	1	EXs14 Mono,541:SD-Smns 01-EXs14	IFX1	Off
D8	1	EXs14 Mono,542:SD-Smns 02-EXs14	IFX1	Off
D#8	1	EXs14 Mono,543:SD-Smns 03-EXs14	IFX1	Off
E8	1	EXs14 Mono,546:SD-Smns 06-EXs14	IFX1	Off

U-G13: Dance Clap Kit [C3~F5]

Key	Zone	Drumsample	Bus	Ex
B2	1	ROM Mono,0:BD-01-amb f	IFX2	Off
C3	1	EXs14 Stereo,6:Clap-Dance 1-EXs14-L	IFX1	Off
C#3	1	EXs14 Stereo,7:Clap-Dance 2-EXs14-L	IFX1	Off
D3	1	EXs14 Stereo,8:Clap-Dance 3-EXs14-L	IFX1	Off
D#3	1	EXs14 Stereo,9:Clap-Dance 4-EXs14-L	IFX1	Off
E3	1	EXs14 Mono,126:Clap-Electro 01-EXs14	IFX1	Off
F3	1	EXs14 Mono,127:Clap-Electro 02-EXs14	IFX1	Off
F#3	1	EXs14 Mono,128:Clap-Electro 03-EXs14	IFX1	Off
G3	1	EXs14 Mono,129:Clap-Electro 04-EXs14	IFX1	Off
G#3	1	EXs14 Mono,130:Clap-Electro 05-EXs14	IFX1	Off
A3	1	EXs14 Mono,131:Clap-Electro 06-EXs14	IFX1	Off
A#3	1	EXs14 Mono,132:Clap-Electro 07-EXs14	IFX1	Off
B3	1	EXs14 Mono,133:Clap-Electro 08-EXs14	IFX1	Off
C4	1	EXs14 Mono,134:Clap-Electro 09-EXs14	IFX1	Off
C#4	1	EXs14 Mono,135:Clap-Electro 10-EXs14	IFX1	Off
D4	1	EXs14 Mono,136:Clap-Electro 11-EXs14	IFX1	Off
D#4	1	EXs14 Mono,443:Clap-88 2-EXs14	IFX1	Off
E4	1	EXs14 Mono,139:Clap-HipHop 1-EXs14	IFX1	Off
F4	1	EXs14 Mono,140:Clap-HipHop 2-EXs14	IFX1	Off
F#4	1	EXs14 Mono,141:Clap-HipHop 3-EXs14	IFX1	Off
G4	1	EXs14 Mono,284:Clap-KPR77-EXs14	IFX1	Off
G#4	1	EXs14 Mono,385:Clap-DDD5-EXs14	IFX1	Off
A4	1	EXs14 Mono,442:Clap-88 1-EXs14	IFX1	Off
A#4	1	ROM Mono,574:Hand Claps 1	IFX1	Off
B4	1	ROM Mono,575:Hand Claps 2-a	IFX1	Off
C5	1	ROM Mono,576:Hand Claps 2-b	IFX1	Off
C#5	1	ROM Mono,577:Hand Claps 2-c	IFX1	Off
D5	1	ROM Mono,578:Hand Claps 2-d	IFX1	Off
D#5	1	ROM Mono,579:Hand Claps 2-e	IFX1	Off
E5	1	ROM Mono,580:Hand Claps 2-f	IFX1	Off
F5	1	ROM Mono,581:Hand Claps 2-g	IFX1	Off

U-G14: Dance HH Kit [E0~E8]

Key	Zone	Drumsample	Bus	Ex
D#0	1	ROM Mono,0:BD-01-amb f	IFX5	3
E0	1	ROM Mono,508:H.Hat-Whispy	IFX5	Off
F0	1	ROM Mono,507:H.Hat-ClangyOpen	IFX5	1
F#0	1	ROM Mono,506:H.Hat-Crisp Open	IFX5	1
G0	1	ROM Mono,505:H.Hat-Ambi	IFX5	1
G#0	1	ROM Mono,504:H.Hat-Hip	IFX5	Off
A0	1	ROM Mono,503:H.Hat-Vintage	IFX5	Off
A#0	1	ROM Mono,502:H.Hat-Chili	IFX5	Off
B0	1	ROM Mono,498:Hi-Hat WS-Closed a	IFX5	2
C1	1	ROM Mono,499:Hi-Hat WS-Closed b	IFX5	2
C#1	1	ROM Mono,500:Hi-Hat WS-HalfOpen	IFX5	2
D1	1	ROM Mono,501:Hi-Hat WS-Open	IFX5	2
D#1	1	ROM Mono,496:Hi-Hat Dance 31	IFX5	2
E1	1	ROM Mono,497:Hi-Hat Dance 32	IFX5	2
F1	1	EXs14 Mono,448:HiHat-Cl-88 2-Trap-EXs14	IFX5	3
F#1	1	EXs14 Mono,447:HiHat-Cl-88 1-Trap-EXs14	IFX5	3
G1	1	EXs14 Mono,449:HiHat-Open-88-Trap-EXs14	IFX5	3
G#1	1	ROM Mono,511:88-HHat Closed	IFX5	3
A1	1	ROM Mono,512:88-HHat Open	IFX5	3
A#1	1	ROM Mono,509:99-HHat Closed	IFX5	4
B1	1	ROM Mono,510:99-HHat Open	IFX5	4
C2	1	EXs14 Stereo,12:Hi Hat-Electro15-EXs14-L	IFX5	Off
C#2	1	EXs14 Stereo,13:Hi Hat-Electro16-EXs14-L	IFX5	Off
D2	1	EXs14 Mono,152:Hi Hat-Electro 01-EXs14	IFX5	Off
D#2	1	EXs14 Mono,153:Hi Hat-Electro 02-EXs14	IFX5	Off
E2	1	EXs14 Mono,154:Hi Hat-Electro 03-EXs14	IFX5	Off
F2	1	EXs14 Mono,155:Hi Hat-Electro 04-EXs14	IFX5	Off
F#2	1	EXs14 Mono,156:Hi Hat-Electro 05-EXs14	IFX5	Off
G2	1	EXs14 Mono,157:Hi Hat-Electro 06-EXs14	IFX5	Off
G#2	1	EXs14 Mono,158:Hi Hat-Electro 07-EXs14	IFX5	Off
A2	1	EXs14 Mono,159:Hi Hat-Electro 08-EXs14	IFX5	Off
A#2	1	EXs14 Mono,160:Hi Hat-Electro 09-EXs14	IFX5	Off
B2	1	EXs14 Mono,161:Hi Hat-Electro 10-EXs14	IFX5	Off
C3	1	EXs14 Mono,162:Hi Hat-Electro 11-EXs14	IFX5	Off
C#3	1	EXs14 Mono,163:Hi Hat-Electro 12-EXs14	IFX5	Off
D3	1	EXs14 Mono,164:Hi Hat-Electro 13-EXs14	IFX5	Off
D#3	1	EXs14 Mono,165:Hi Hat-Electro 14-EXs14	IFX5	Off
E3	1	EXs14 Mono,170:Hi Hat-Funk 01-EXs14	IFX5	4
F3	1	EXs14 Mono,171:Hi Hat-Funk 02-EXs14	IFX5	4
F#3	1	EXs14 Mono,172:Hi Hat-Funk 03-EXs14	IFX5	4
G3	1	EXs14 Mono,173:Hi Hat-Funk 04-Op-EXs14	IFX5	4
G#3	1	EXs14 Mono,174:Hi Hat-Funk 05-EXs14	IFX5	5
A3	1	EXs14 Mono,175:Hi Hat-Funk 06-EXs14	IFX5	5
A#3	1	EXs14 Mono,176:Hi Hat-Funk 07-EXs14	IFX5	5
B3	1	EXs14 Mono,177:Hi Hat-Funk 08-Op-EXs14	IFX5	5
C4	1	EXs14 Mono,178:Hi Hat-Funk 09-EXs14	IFX5	Off
C#4	1	EXs14 Mono,179:Hi Hat-Funk 10-EXs14	IFX5	6
D4	1	EXs14 Mono,180:Hi Hat-Funk 11-Op-EXs14	IFX5	6
D#4	1	EXs14 Mono,181:Hi Hat-Funk 12-EXs14	IFX5	Off
E4	1	EXs14 Mono,182:Hi Hat-Funk 13-EXs14	IFX5	Off
F4	1	EXs14 Mono,183:Hi Hat-Funk 14-EXs14	IFX5	Off
F#4	1	EXs14 Mono,184:Hi Hat-HipHop-Open-EXs14	IFX5	Off
G4	1	EXs14 Mono,280:HH-Closed-KPR55-EXs14	IFX5	16
G#4	1	EXs14 Mono,281:HH-Open-KPR55-EXs14	IFX5	16
A4	1	EXs14 Mono,287:HH-Closed-KPR77-EXs14	IFX5	7
A#4	1	EXs14 Mono,288:HH-Open-KPR77-EXs14	IFX5	7
B4	1	EXs14 Mono,388:HH Closed-DDD5 1-EXs14	IFX5	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	EXs14 Mono,389:HH Closed-DDD5 2-EXs14	IFX5	Off
C#5	1	EXs14 Mono,483:Hi Hat-Cl-99-comp1-EXs14	IFX5	8
D5	1	EXs14 Mono,484:Hi Hat-Cl-99-comp2-EXs14	IFX5	8
D#5	1	EXs14 Mono,485:Hi Hat-Cl-99-comp3-EXs14	IFX5	8
E5	1	EXs14 Mono,486:Hi Hat-Cl-99-comp4-EXs14	IFX5	8
F5	1	EXs14 Mono,487:Hi Hat-Cl-99-comp5-EXs14	IFX5	8
F#5	1	EXs14 Mono,488:Hi Hat-Cl-99-comp6-EXs14	IFX5	8
G5	1	EXs14 Mono,489:Hi Hat-Cl-99-comp7-EXs14	IFX5	8
G#5	1	EXs14 Mono,490:Hi Hat-Op-99-comp1-EXs14	IFX5	8
A5	1	EXs14 Mono,491:Hi Hat-Op-99-comp2-EXs14	IFX5	8
A#5	1	EXs14 Mono,492:Hi Hat-Op-99-comp3-EXs14	IFX5	8
B5	1	EXs14 Mono,493:Hi Hat-Op-99-comp4-EXs14	IFX5	8
C6	1	EXs14 Mono,494:Hi Hat-Op-99-comp5-EXs14	IFX5	8
C#6	1	EXs14 Mono,447:HiHat-Cl-88 1-Trap-EXs14	IFX5	Off
D6	1	EXs14 Mono,448:HiHat-Cl-88 2-Trap-EXs14	IFX5	9
D#6	1	EXs14 Mono,449:HiHat-Open-88-Trap-EXs14	IFX5	9
E6	1	EXs14 Mono,417:Hi-Hat-Closed-66-EXs14	IFX5	9
F6	1	EXs14 Mono,418:Hi-Hat-Open-66-EXs14	IFX5	9
F#6	1	EXs14 Mono,500:Hi Hat-Close-Drt-EXs14	IFX5	10
G6	1	EXs14 Mono,501:Hi Hat-Open-Drt-EXs14	IFX5	10
G#6	1	EXs14 Mono,520:Hi Hat-Ln 1-EXs14	IFX5	17
A6	1	EXs14 Mono,521:Hi Hat-Ln 2-EXs14	IFX5	17
A#6	1	EXs14 Mono,522:Hi Hat-Ln 3-EXs14	IFX5	17
B6	1	EXs14 Mono,523:Hi Hat-Ln 4-EXs14	IFX5	17
C7	1	EXs14 Mono,524:Hi Hat-Ln 5-EXs14	IFX5	11
C#7	1	EXs14 Mono,525:Hi Hat-Ln 6-EXs14	IFX5	11
D7	1	ROM Mono,479:Hi Hat Dance 14	IFX5	Off
D#7	1	ROM Mono,480:Hi-Hat Dance 15	IFX5	12
E7	1	ROM Mono,481:Hi-Hat Dance 16	IFX5	12
F7	1	ROM Mono,482:Hi-Hat Dance 17	IFX5	12
F#7	1	ROM Mono,483:Hi-Hat Dance 18	IFX5	Off
G7	1	ROM Mono,484:Hi-Hat Dance 19	IFX5	13
G#7	1	ROM Mono,485:Hi-Hat Dance 20	IFX5	13
A7	1	ROM Mono,486:Hi-Hat Dance 21	IFX5	13
A#7	1	ROM Mono,487:Hi-Hat Dance 22	IFX5	14
B7	1	ROM Mono,488:Hi-Hat Dance 23	IFX5	14
C8	1	ROM Mono,489:Hi-Hat Dance 24	IFX5	Off
C#8	1	ROM Mono,490:Hi-Hat Dance 25	IFX5	15
D8	1	ROM Mono,491:Hi-Hat Dance 26	IFX5	15
D#8	1	ROM Mono,492:Hi-Hat Dance 27	IFX5	15
E8	1	ROM Mono,513:Hi-Hat WS Syn-Closed	IFX5	Off

U-G15: Dance Hit Kit [E0~E8]

Key	Zone	Drumsample	Bus	Ex
D#0	1	ROM Mono,0:BD-01-amb f	L/R	Off
E0	1	ROM Mono,1053:Synth Hit Decay 4	IFX5	Off
F0	1	ROM Mono,1053:Synth Hit Decay 4	IFX5	Off
F#0	1	ROM Mono,1052:Synth Hit Decay 3	IFX5	Off
G0	1	ROM Mono,1052:Synth Hit Decay 3	IFX5	Off
G#0	1	ROM Mono,1051:Synth Hit Decay 2	IFX5	Off
A0	1	ROM Mono,1051:Synth Hit Decay 2	IFX5	Off
A#0	1	ROM Mono,1050:Synth Hit Decay 1	IFX5	Off
B0	1	ROM Mono,1050:Synth Hit Decay 1	IFX5	Off
C1	1	ROM Mono,1049:Synth Hit Loop 6	IFX5	Off
C#1	1	ROM Mono,1049:Synth Hit Loop 6	IFX5	Off
D1	1	ROM Mono,1048:Synth Hit Loop 5	IFX5	Off
D#1	1	ROM Mono,1048:Synth Hit Loop 5	IFX5	Off
E1	1	ROM Mono,1047:Synth Hit Loop 4	IFX5	Off
F1	1	ROM Mono,1047:Synth Hit Loop 4	IFX5	Off
F#1	1	ROM Mono,1046:Synth Hit Loop 3	IFX5	Off
G1	1	ROM Mono,1046:Synth Hit Loop 3	IFX5	Off
G#1	1	ROM Mono,1045:Synth Hit Loop 2	IFX5	Off
A1	1	ROM Mono,1045:Synth Hit Loop 2	IFX5	Off
A#1	1	ROM Mono,1044:Synth Hit Loop 1	IFX5	Off
B1	1	ROM Mono,1044:Synth Hit Loop 1	IFX5	Off
C2	1	EXs14 Stereo,17:Dance Hit 4-EXs14-L	IFX5	Off
C#2	1	EXs14 Stereo,17:Dance Hit 4-EXs14-L	IFX5	Off
D2	1	EXs14 Stereo,19:Dance Hit 6-EXs14-L	IFX5	Off
D#2	1	EXs14 Stereo,19:Dance Hit 6-EXs14-L	IFX5	Off
E2	1	EXs14 Stereo,20:Dance Hit 7-EXs14-L	IFX5	Off
F2	1	EXs14 Stereo,20:Dance Hit 7-EXs14-L	IFX5	Off
F#2	1	EXs14 Stereo,21:Dance Hit 8-EXs14-L	IFX5	Off
G2	1	EXs14 Stereo,21:Dance Hit 8-EXs14-L	IFX5	Off
G#2	1	EXs14 Mono,186:Synth Hit 02-EXs14	IFX5	Off
A2	1	EXs14 Mono,186:Synth Hit 02-EXs14	IFX5	Off
A#2	1	EXs14 Mono,187:Synth Hit 03-EXs14	IFX5	Off
B2	1	EXs14 Mono,187:Synth Hit 03-EXs14	IFX5	Off
C3	1	EXs14 Mono,188:Synth Hit 04-EXs14	IFX5	Off
C#3	1	EXs14 Mono,188:Synth Hit 04-EXs14	IFX5	Off
D3	1	EXs14 Mono,189:Synth Hit 05-EXs14	IFX5	Off
D#3	1	EXs14 Mono,189:Synth Hit 05-EXs14	IFX5	Off
E3	1	EXs14 Mono,190:Synth Hit 06-EXs14	IFX5	Off
F3	1	EXs14 Mono,190:Synth Hit 06-EXs14	IFX5	Off
F#3	1	EXs14 Mono,191:Synth Hit 07-EXs14	IFX5	Off
G3	1	EXs14 Mono,191:Synth Hit 07-EXs14	IFX5	Off
G#3	1	EXs14 Mono,191:Synth Hit 07-EXs14	IFX5	Off
A3	1	EXs14 Mono,191:Synth Hit 07-EXs14	IFX5	Off
A#3	1	EXs14 Mono,193:Synth Hit 09-EXs14	IFX5	Off
B3	1	EXs14 Mono,193:Synth Hit 09-EXs14	IFX5	Off
C4	1	EXs14 Mono,196:Synth Hit 12-EXs14	IFX5	Off
C#4	1	EXs14 Mono,196:Synth Hit 12-EXs14	IFX5	Off
D4	1	EXs14 Mono,197:Synth Hit 13-EXs14	IFX5	Off
D#4	1	EXs14 Mono,197:Synth Hit 13-EXs14	IFX5	Off
E4	1	EXs14 Mono,198:Synth Hit 14-EXs14	IFX5	Off
F4	1	EXs14 Mono,198:Synth Hit 14-EXs14	IFX5	Off
F#4	1	EXs14 Mono,200:Synth Hit 16-EXs14	IFX5	Off
G4	1	EXs14 Mono,200:Synth Hit 16-EXs14	IFX5	Off
G#4	1	EXs14 Mono,202:Synth Hit 18-EXs14	IFX5	Off
A4	1	EXs14 Mono,202:Synth Hit 18-EXs14	IFX5	Off
A#4	1	EXs14 Mono,203:Synth Hit 19-EXs14	IFX5	Off
B4	1	EXs14 Mono,203:Synth Hit 19-EXs14	IFX5	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	ROM Mono,1023:Orch Hit 1	IFX5	Off
C#5	1	ROM Mono,1023:Orch Hit 1	IFX5	Off
D5	1	ROM Mono,1024:Orch Hit 2	IFX5	Off
D#5	1	ROM Mono,1024:Orch Hit 2	IFX5	Off
E5	1	ROM Mono,1025:Orch Hit 3	IFX5	Off
F5	1	ROM Mono,1025:Orch Hit 3	IFX5	Off
F#5	1	ROM Mono,1026:Orch Hit 4	IFX5	Off
G5	1	ROM Mono,1026:Orch Hit 4	IFX5	Off
G#5	1	ROM Mono,1027:Orch Hit 5	IFX5	Off
A5	1	ROM Mono,1027:Orch Hit 5	IFX5	Off
A#5	1	ROM Mono,1028:Orch Hit 6	IFX5	Off
B5	1	ROM Mono,1028:Orch Hit 6	IFX5	Off
C6	1	ROM Mono,1029:Orch Hit 7	IFX5	Off
C#6	1	ROM Mono,1029:Orch Hit 7	IFX5	Off
D6	1	ROM Mono,1030:Impact Hit	IFX5	Off
D#6	1	ROM Mono,1030:Impact Hit	IFX5	Off
E6	1	ROM Mono,1031:Band Hit 1	IFX5	Off
F6	1	ROM Mono,1031:Band Hit 1	IFX5	Off
F#6	1	ROM Mono,1032:Band Hit 2	IFX5	Off
G6	1	ROM Mono,1032:Band Hit 2	IFX5	Off
G#6	1	ROM Mono,1033:Big Hit	IFX5	Off
A6	1	ROM Mono,1033:Big Hit	IFX5	Off
A#6	1	ROM Mono,1034:Jazz Hit 1	IFX5	Off
B6	1	ROM Mono,1034:Jazz Hit 1	IFX5	Off
C7	1	ROM Mono,1035:Jazz Hit 2	IFX5	Off
C#7	1	ROM Mono,1035:Jazz Hit 2	IFX5	Off
D7	1	ROM Mono,1036:Jazz Hit 3	IFX5	Off
D#7	1	ROM Mono,1036:Jazz Hit 3	IFX5	Off
E7	1	ROM Mono,1041:Dance Hit	IFX5	Off
F7	1	ROM Mono,1041:Dance Hit	IFX5	Off
F#7	1	ROM Mono,1042:VibeChord	IFX5	Off
G7	1	ROM Mono,1042:VibeChord	IFX5	Off
G#7	1	ROM Mono,1043:W.E.P.Chord	IFX5	Off
A7	1	ROM Mono,1043:W.E.P.Chord	IFX5	Off
A#7	1	EXs14 Mono,186:Synth Hit 02-EXs14	IFX5	Off
B7	1	EXs14 Mono,186:Synth Hit 02-EXs14	IFX5	Off
C8	1	EXs14 Mono,212:Drum Hit 09-EXs14	IFX5	Off
C#8	1	EXs14 Mono,212:Drum Hit 09-EXs14	IFX5	Off
D8	1	EXs14 Mono,225:Drum Hit 22-EXs14	IFX5	Off
D#8	1	EXs14 Stereo,22:Dance Hit 9-EXs14-L	IFX5	Off
E8	1	EXs14 Mono,194:Synth Hit 10-EXs14	IFX5	Off

Drum Track Patterns

#	Name
U230	E.House 01 EXs14 [Dance]
U231	E.House 02 EXs14 [Dance]
U232	E.House 03 EXs14 [Dance]
U233	E.House 04 EXs14 [Dance]
U234	E.House 05 EXs14 [Dance]
U235	E.House 06 EXs14 [Dance]
U236	E.House 07 EXs14 [Dance]
U237	E.House 08 EXs14 [Dance]
U238	E.House 09 EXs14 [Dance]
U239	E.House 10 EXs14 [Dance]
U240	E.House 11 EXs14 [Dance]
U241	E.House 12 EXs14 [Dance]
U242	E.House 13 EXs14 [Dance]
U243	E.House 14 EXs14 [Dance]
U244	E.House 15 EXs14 [Dance]
U245	E.House 16 EXs14 [Dance]
U246	E.House 17 EXs14 [Dance]
U247	E.House 18 EXs14 [Dance]
U248	Progresve01 EXs14[Dance]
U249	Progresve02 EXs14[Dance]
U250	Progresve03 EXs14[Dance]
U251	Progresve04 EXs14[Dance]
U252	Progresve05 EXs14[Dance]
U253	Progresve06 EXs14[Dance]
U254	Progresve07 EXs14[Dance]
U255	Progresve08 EXs14[Dance]
U256	Progresve09 EXs14[Dance]
U257	Progresve10 EXs14[Dance]
U258	Progresve11 EXs14[Dance]
U259	Progresve12 EXs14[Dance]
U260	Progresve13 EXs14[Dance]
U261	Techno 01 EXs14 [Dance]
U262	Techno 02 EXs14 [Dance]
U263	Techno 03 EXs14 [Dance]
U264	Techno 04 EXs14 [Dance]
U265	Techno 05 EXs14 [Dance]
U266	Techno 06 EXs14 [Dance]
U267	Techno 07 EXs14 [Dance]
U268	Techno 08 EXs14 [Dance]
U269	Techno 09 EXs14 [Dance]
U270	Techno 10 EXs14 [Dance]
U271	Techno 11 EXs14 [Dance]
U272	Techno 12 EXs14 [Dance]
U273	Techno 13 EXs14 [Dance]
U274	Techno 14 EXs14 [Dance]
U275	Techno 15 EXs14 [Dance]
U276	Techno 16 EXs14 [Dance]
U277	Techno 17 EXs14 [Dance]
U278	Techno 18 EXs14 [Dance]
U279	Techno 19 EXs14 [Dance]
U280	Dubstep 01 EXs14 [Dance]
U281	Dubstep 02 EXs14 [Dance]
U282	Dubstep 03 EXs14 [Dance]
U283	Dubstep 04 EXs14 [Dance]
U284	Dubstep 05 EXs14 [Dance]
U285	Dubstep 06 EXs14 [Dance]
U286	Dubstep 07 EXs14 [Dance]
U287	Dubstep 08 EXs14 [Dance]
U288	Dubstep 09 EXs14 [Dance]
U289	Dubstep 10 EXs14 [Dance]

#	Name
U290	Dubstep 11 EXs14 [Dance]
U291	Dubstep 12 EXs14 [Dance]
U292	GlitchHop01 EXs14 [Dance]
U293	GlitchHop02 EXs14 [Dance]
U294	GlitchHop03 EXs14 [Dance]
U295	GlitchHop04 EXs14 [Dance]
U296	GlitchHop05 EXs14 [Dance]
U297	GlitchHop06 EXs14 [Dance]
U298	GlitchHop07 EXs14 [Dance]
U299	GlitchHop08 EXs14 [Dance]
U300	GlitchHop09 EXs14 [Dance]
U301	GlitchHop10 EXs14 [Dance]
U302	GlitchHop11 EXs14 [Dance]
U303	GlitchHop12 EXs14 [Dance]
U304	Trap 01 EXs14 [Dance]
U305	Trap 02 EXs14 [Dance]
U306	Trap 03 EXs14 [Dance]
U307	Trap 04 EXs14 [Dance]
U308	Trap 05 EXs14 [Dance]
U309	Trap 06 EXs14 [Dance]
U310	Trap 07 EXs14 [Dance]
U311	Trap 08 EXs14 [Dance]
U312	Trap 09 EXs14 [Dance]
U313	Trap 10 EXs14 [Dance]
U314	Trap 11 EXs14 [Dance]
U315	Trap 12 EXs14 [Dance]
U316	Trap 13 EXs14 [Dance]
U317	Trap 14 EXs14 [Dance]
U318	Trap 15 EXs14 [Dance]
U319	Trap 16 EXs14 [Dance]
U320	Trap 17 EXs14 [Dance]
U321	R&B/Funk 01 EXs14 [Dance]
U322	R&B/Funk 02 EXs14 [Dance]
U323	R&B/Funk 03 EXs14 [Dance]
U324	R&B/Funk 04 EXs14 [Dance]
U325	R&B/Funk 05 EXs14 [Dance]
U326	R&B/Funk 06 EXs14 [Dance]
U327	R&B/Funk 07 EXs14 [Dance]
U328	R&B/Funk 08 EXs14 [Dance]
U329	R&B/Funk 09 EXs14 [Dance]
U330	R&B/Funk 10 EXs14 [Dance]
U331	R&B/Funk 11 EXs14 [Dance]
U332	R&B/Funk 12 EXs14 [Dance]
U333	Drum&Bass01 EXs14 [Dance]
U334	Drum&Bass02 EXs14 [Dance]
U335	Drum&Bass03 EXs14 [Dance]
U336	Drum&Bass04 EXs14 [Dance]
U337	Drum&Bass05 EXs14 [Dance]
U338	Drum&Bass06 EXs14 [Dance]
U339	Drum&Bass07 EXs14 [Dance]
U340	Drum&Bass08 EXs14 [Dance]
U341	Drum&Bass09 EXs14 [Dance]
U342	Drum&Bass10 EXs14 [Dance]
U343	Drum&Bass11 EXs14 [Dance]
U344	Drum&Bass12 EXs14 [Dance]
U345	Breaks 01 EXs14 [Dance]
U346	Breaks 02 EXs14 [Dance]
U347	Breaks 03 EXs14 [Dance]
U348	Breaks 04 EXs14 [Dance]
U349	Breaks 05 EXs14 [Dance]

#	Name
U350	Breaks 06 EXs14 [Dance]
U351	Breaks 07 EXs14 [Dance]
U352	Breaks 08 EXs14 [Dance]
U353	Breaks 09 EXs14 [Dance]
U354	Breaks 10 EXs14 [Dance]
U355	Breaks 11 EXs14 [Dance]
U356	Breaks 12 EXs14 [Dance]
U357	Chill 01 EXs14 [Dance]
U358	Chill 02 EXs14 [Dance]
U359	Chill 03 EXs14 [Dance]
U360	Chill 04 EXs14 [Dance]
U361	Chill 05 EXs14 [Dance]
U362	Chill 06 EXs14 [Dance]
U363	Chill 07 EXs14 [Dance]
U364	Chill 08 EXs14 [Dance]
U365	Chill 09 EXs14 [Dance]
U366	Chill 10 EXs14 [Dance]
U367	Chill 11 EXs14 [Dance]
U368	Chill 12 EXs14 [Dance]
U369	Electro 01 EXs14 [Dance]
U370	Electro 02 EXs14 [Dance]
U371	Electro 03 EXs14 [Dance]
U372	Electro 04 EXs14 [Dance]
U373	Electro 05 EXs14 [Dance]
U374	Electro 06 EXs14 [Dance]
U375	Electro 07 EXs14 [Dance]
U376	Electro 08 EXs14 [Dance]
U377	Electro 09 EXs14 [Dance]
U378	Electro 10 EXs14 [Dance]
U379	Electro 11 EXs14 [Dance]
U380	Electro 12 EXs14 [Dance]
U381	Electro 13 EXs14 [Dance]
U382	Vintage 01 EXs14 [Dance]
U383	Vintage 02 EXs14 [Dance]
U384	Vintage 03 EXs14 [Dance]
U385	Vintage 04 EXs14 [Dance]
U386	Vintage 05 EXs14 [Dance]
U387	Vintage 06 EXs14 [Dance]
U388	Vintage 07 EXs14 [Dance]
U389	Vintage 08 EXs14 [Dance]
U390	Vintage 09 EXs14 [Dance]
U391	Vintage 10 EXs14 [Dance]
U392	Vintage 11 EXs14 [Dance]
U393	Vintage 12 EXs14 [Dance]
U394	KorgVtg 01 EXs14 [Dance]
U395	KorgVtg 02 EXs14 [Dance]
U396	KorgVtg 03 EXs14 [Dance]
U397	KorgVtg 04 EXs14 [Dance]
U398	KorgVtg 05 EXs14 [Dance]
U399	KorgVtg 06 EXs14 [Dance]
U400	KorgVtg 07 EXs14 [Dance]
U401	KorgVtg 08 EXs14 [Dance]
U402	KorgVtg 09 EXs14 [Dance]
U403	KorgVtg 10 EXs14 [Dance]
U404	KorgVtg 11 EXs14 [Dance]
U405	KorgVtg 12 EXs14 [Dance]

Demo RPPRs

S000

Electro House

RPPR

S000 Electro House

#	Pattern Name
U00	Electro Beat 01
U01	Electro Beat 02
U02	Electro Beat 03
U03	Electro Beat 04
U04	Electro Beat 05
U05	Electro Beat 06
U06	Electro Beat 07
U07	Electro Beat 08
U08	Electro Beat 09
U09	Electro Beat 10
U10	Electro Beat 11
U11	Electro Beat 12
U12	Electro Beat 13
U13	Electro Beat 14
U14	Electro Beat 15
U15	Electro Beat 16
U16	Electro Beat 17
U17	Electro Beat 18
U18	Electro Bass
U19	Electro Synth 1
U20	Electro Synth 2

S001

Progressive House

S002

Techno / Minimal

S003

Dubstep

S004

Glitch Hop

S005

Trap

S006

R&B / Funk

S007

Drum & Bass

S008

Breaks

S009

Chill / Down Tempo

S010

Electronica

S011

Vintage Machine

S012

Korg Vintage Machine

Demo RPPRs by KORG Inc.
- all right reserved

RPPR

S000 Electro House

S002 Techno / Minimal

#	Pattern Nmae
U00	Techno Beat 01
U01	Techno Beat 02
U02	Techno Beat 03
U03	Techno Beat 04
U04	Techno Beat 05
U05	Techno Beat 06
U06	Techno Beat 07
U07	Techno Beat 08
U08	Techno Beat 09
U09	Techno Beat 10
U10	Techno Beat 11
U11	Techno Beat 12
U12	Techno Beat 13
U13	Techno Beat 14
U14	Techno Beat 15
U15	Techno Beat 16
U16	Techno Beat 17
U17	Techno Beat 18
U18	Techno Beat 19
U19	Techno Bass
U20	Techno Hit 1
U21	Techno Per
U22	Techno Synth 1
U23	Techno Hit 2
U24	Techno Synth 2

S 005 Trap

#	Pattern Nmae
U00	Trap Beat 01
U01	Trap Beat 02
U02	Trap Beat 03
U03	Trap Beat 04
U04	Trap Beat 05
U05	Trap Beat 06
U06	Trap Beat 07
U07	Trap Beat 08
U08	Trap Beat 09
U09	Trap Beat 10
U10	Trap Beat 11
U11	Trap Beat 12
U12	Trap Beat 13
U13	Trap Beat 14
U14	Trap Beat 15
U15	Trap Beat 16
U16	Trap Beat 17
U17	Trap Synth 1
U18	Trap Chord
U19	Trap Synth 2
U20	Trap Synth 3

S 006 R&B / Funk

#	Pattern Nmae
U00	R&B / Funk Beat 01
U01	R&B / Funk Beat 02
U02	R&B / Funk Beat 03
U03	R&B / Funk Beat 04
U04	R&B / Funk Beat 05
U05	R&B / Funk Beat 06
U06	R&B / Funk Beat 07
U07	R&B / Funk Beat 08
U08	R&B / Funk Beat 09
U09	R&B / Funk Beat 10
U10	R&B / Funk Beat 11
U11	R&B / Funk Beat 12
U12	R&B / Funk Bass
U13	R&B / Funk Ep
U14	R&B / Funk Str

S 007 Drum & Bass

#	Pattern Nmae
U00	Drum & Bass Beat 01
U01	Drum & Bass Beat 02
U02	Drum & Bass Beat 03
U03	Drum & Bass Beat 04
U04	Drum & Bass Beat 05
U05	Drum & Bass Beat 06
U06	Drum & Bass Beat 07
U07	Drum & Bass Beat 08
U08	Drum & Bass Beat 09
U09	Drum & Bass Beat 10
U10	Drum & Bass Beat 11
U11	Drum & Bass Beat 12
U12	Drum & Bass Bass 1
U13	Drum & Bass Bass 2
U14	Drum & Bass Synth

S004 Glitch Hop

#	Pattern Nmae
U00	Glitch Hop Beat 1
U01	Glitch Hop Beat 2
U02	Glitch Hop Beat 3
U03	Glitch Hop Beat 4
U04	Glitch Hop Beat 5
U05	Glitch Hop Beat 6
U06	Glitch Hop Beat 7
U07	Glitch Hop Beat 8
U08	Glitch Hop Beat 9
U09	Glitch Hop Beat 10
U10	Glitch Hop Beat 11
U11	Glitch Hop Beat 12
U12	Glitch Hop Bass 1
U13	Glitch Hop Bass 2
U14	Glitch Hop Synth 1
U15	Glitch Hop Synth 2

S008 Breaks

#	Pattern Name
U00	Breaks 01
U01	Breaks 02
U02	Breaks 03
U03	Breaks 04
U04	Breaks 05
U05	Breaks 06
U06	Breaks 07
U07	Breaks 08
U08	Breaks 09
U09	Breaks 10
U10	Breaks 11
U11	Breaks 12
U12	Breaks Bass 1
U13	Breaks Bass 2
U14	Breaks Synth 1
U15	Breaks Synth 2

S011 Vintage Machine

#	Pattern Name
U00	Vintage Machine Beat 01
U01	Vintage Machine Beat 02
U02	Vintage Machine Beat 03
U03	Vintage Machine Beat 04
U04	Vintage Machine Beat 05
U05	Vintage Machine Beat 06
U06	Vintage Machine Beat 07
U07	Vintage Machine Beat 08
U08	Vintage Machine Beat 09
U09	Vintage Machine Beat 10
U10	Vintage Machine Beat 11
U11	Vintage Machine Beat 12
U12	Vintage Machine Beat Bass
U13	Vintage Machine Beat SQ 1
U14	Vintage Machine Beat SQ 2
U15	Vintage Machine Beat SFX

S009 Chill / Down Tempo

#	Pattern Name
U00	Chill Down Tempo Beat 01
U01	Chill Down Tempo Beat 02
U02	Chill Down Tempo Beat 03
U03	Chill Down Tempo Beat 04
U04	Chill Down Tempo Beat 05
U05	Chill Down Tempo Beat 06
U06	Chill Down Tempo Beat 07
U07	Chill Down Tempo Beat 08
U08	Chill Down Tempo Beat 09
U09	Chill Down Tempo Beat 10
U10	Chill Down Tempo Beat 11
U11	Chill Down Tempo Beat 12
U12	Chill Down Tempo Beat Bass
U13	Chill Down Tempo Beat Ep
U14	Chill Down Tempo Beat Str
U15	Chill Down Tempo Beat Pf
U16	Chill Down Tempo Beat SQ

S012 Korg Vintage Machine

#	Pattern Name
U00	Korg VintMachine Beat 01
U01	Korg VintMachine Beat 02
U02	Korg VintMachine Beat 03
U03	Korg VintMachine Beat 04
U04	Korg VintMachine Beat 05
U05	Korg VintMachine Beat 06
U06	Korg VintMachine Beat 07
U07	Korg VintMachine Beat 08
U08	Korg VintMachine Beat 09
U09	Korg VintMachine Beat 10
U10	Korg VintMachine Beat 11
U11	Korg VintMachine Beat 12
U12	Korg Vint Machine Bass
U13	Korg Vint Machine SQ
U14	Korg Vint Machine Voice
U15	Korg Vint Machine Synth

S010 Electronica

#	Pattern Name
U00	Electronica Beat 01
U01	Electronica Beat 02
U02	Electronica Beat 03
U03	Electronica Beat 04
U04	Electronica Beat 05
U05	Electronica Beat 06
U06	Electronica Beat 07
U07	Electronica Beat 08
U08	Electronica Beat 09
U09	Electronica Beat 10
U10	Electronica Beat 11
U11	Electronica Beat 12
U12	Electronica Beat 13
U13	Electronica Bass 1
U14	Electronica Bass 2
U15	Electronica Synth 1
U16	Electronica Synth 2

KORG INC.

4015-2 Yanokuchi, Inagi-City, Tokyo 206-0812 JAPAN

© 2014 KORG INC.