

KRONOS Sound Libraries

EXs Expansion Samples



Manuel d'utilisation

KORG

(F) (1)

EXs14 EDM Drums

Nous vous remercions d'avoir choisi EXs14 EDM Drums pour le KRONOS de Korg.

Cette série comprend des échantillons de batterie, des kits de batterie et des patterns pour musique dance (électronique).

Les patterns sont disponibles pour la piste de batterie et pour la fonction RPPR en mode Sequencer. A la différence des boucles audio, vous pouvez changer radicalement le tempo sans modifier la qualité audio. De plus, vous pouvez changer de son facilement ou personnaliser les rythmes.

EXs14 compte environ 25 Mo d'échantillons PCM, 567 échantillons de batterie, 16 kits de batterie, 16 programmes, 228 patterns et 13 morceaux (pour la fonction RPPR).

Ce mode d'emploi explique comment installer EXs14 sur le KRONOS, comment charger les échantillons de batterie, les programmes, les kits de batterie, les morceaux et les patterns, et comment acheter un code d'autorisation pour la bibliothèque.

Styles de musique dance des morceaux RPPR

- Electro House
- Progressive House
- Techno/Minimal
- Dub Step
- Glitch Hop
- Trap
- R&B/Funk
- Drum & Bass
- Breaks
- Chill Out/Down Tempo
- Electronica
- Vintage Machine
- KORG Old Machine

Fonction RPPR (Realtime Pattern Play/Recording)

La fonction RPPR permet de reproduire des patterns (les boucles de batterie d'EXs14, p.ex.) en actionnant des touches du clavier. Vous pouvez reproduire les patterns successivement ou les lancer simultanément. Comme la fonction RPPR permet aussi de lancer des riffs de basse et de synthé, vous pouvez l'utiliser pour créer des remix en temps réel.

Pour en savoir plus, voyez "Creating and recording RPPR data" dans le manuel de l'utilisateur.

Système requis

Pour installer EXs14, il vous faut:

- La version 2.1.2 ou ultérieure du système du KRONOS
- Environ 26 Mo d'espace disponible sur le disque interne

Pour charger les sons en mémoire, il faut:

- Environ 17 Mo de RAM disponible

3 Go de mémoire RAM recommandés

KRONOS: A la sortie d'usine, le KRONOS dispose de 2Go de mémoire. Bien que 2Go suffisent pour l'utilisation exclusive d'EXs14, nous vous conseillons d'augmenter la mémoire à 3Go si vous souhaitez utiliser d'autres options EXs. La mémoire RAM supplémentaire doit être installée par un centre SAV agréé par Korg. Voyez à ce sujet "Installing additional RAM" dans le manuel de l'utilisateur.

KRONOS X: A la sortie d'usine, le KRONOS X dispose de 3Go de mémoire. Il n'est pas nécessaire d'augmenter sa mémoire.

Pour vérifier la mémoire RAM installée:

1. Appuyez sur le bouton GLOBAL pour passer en mode Global.
2. Affichez la page "Options Info".

Le paramètre "Memory" de la section "System" dans le coin supérieur droit de l'écran indique la quantité de mémoire RAM installée.

Mode de démonstration

Au départ, EXs14 est en mode de démonstration. Cela vous permet d'utiliser, d'éditer et de sauvegarder des programmes, des combinaisons, des kits de batteries, des séquences d'onde et des morceaux exploitant EXs14. Cependant, tant que vous n'achetez pas de code d'autorisation, le son s'estompe périodiquement. Pour acheter un code d'autorisation, rendez-vous à la boutique en ligne sur le site <https://shop.korg.com/kronosSoundLibraries>. Pour en savoir plus, voyez "Acheter et autoriser EXs14" à la page 11.

Préparations avant l'installation

Pour installer EXs14, il vous faut la version 2.1.2 ou ultérieure du système du KRONOS et au moins 26 Mo d'espace disponible sur le disque interne.

Pour vérifier la version du système de votre KRONOS:

1. Appuyez sur le bouton GLOBAL en façade pour passer en mode Global.
2. Affichez la page "Options Info".

La version est affichée sous "System" dans le coin supérieur droit de l'écran.

3. Vérifiez qu'il s'agit de la version 2.1.2 ou d'une version ultérieure. Si ce n'est pas le cas, rendez-vous sur le site <https://shop.korg.com/kronosSupport> et téléchargez puis installez la version la plus récente du système.

Pour vérifier l'espace disponible sur le disque interne:

1. Appuyez sur le bouton DISK en façade pour passer en mode Disk.
2. Affichez la page "Media Info".
3. Réglez "Drive Select" sur "HDD: INTERNAL HD".
4. Vérifiez que l'espace disponible ("Free Size") est d'au moins 26 M (Mo). Sinon, libérez de la place sur le disque en supprimant des données superflues.

Vous pouvez supprimer des fichiers indésirables du disque avec la commande "Delete" du menu de la page "Utility". Si vous souhaitez conserver ces fichiers, utilisez la commande "Copy" du menu pour les archiver sur un support de mémoire USB externe.

Notez également que l'installation d'EXs14 n'efface pas de données. Nous vous conseillons toutefois de faire une copie de sauvegarde de vos données importantes pour éviter tout risque de perte de données.

Installer EXs14

1. Ouvrez le fichier d'archive téléchargé.

L'ouverture de l'archive produit un dossier contenant différents fichiers et un sous-dossier décrits ci-dessous.

Contenu du dossier EXs14

Nom de fichier/dossier	Remarques
EXs14.exsins	
S014	Fichiers de données exploités par l'utilitaire d'installation.
EXs14.tar.gz	
EXs14.PCG	Ces fichiers contiennent les programmes, patterns pour pistes rythmiques et les kits de batterie (PCG) ainsi que les morceaux avec RPPR et patterns utilisateur (SNG). Ils sont tous inclus dans l'utilitaire d'installation mais sont également fournis séparément pour vous faciliter la tâche.
EXs14.SNG	
Manuals	Ce dossier contient le manuel que vous êtes en train de lire en anglais, français, allemand et japonais: EXs14_OM_E1.PDF EXs14_OM_F1.PDF EXs14_OM_G1.PDF EXs14_OM_J1.PDF


2. Copiez le dossier EXs14 sur un support de mémoire USB comme un disque dur ou une clé USB.
3. Déconnectez correctement le support de mémoire USB de l'ordinateur.
4. Branchez le support de mémoire USB à une des deux prises USB A du KRONOS.
5. Appuyez sur le bouton DISK pour passer en mode Disk.
6. Affichez la page "Disk Utility".
7. Utilisez le menu "Drive Select" dans le bas de la page pour sélectionner le support de mémoire USB.

Vous pouvez être amené à patienter quelques secondes après la connexion du support avant qu'il ne soit reconnu.

8. Ouvrez le dossier contenant les données EXs (voyez l'étape 2).

9. Sélectionnez le fichier "EXs14.exsins".


Le suffixe "exsins" est l'abréviation de "EXs INStaller".



Quand un fichier .exsins est sélectionné, le bouton [Load] se transforme en bouton [Install]. Vous ne pouvez installer qu'une seule option EXs à la fois. Si "Multiple Select" est activé, [Install] est désactivé.

10. Sélectionnez "Install EXs" dans le menu ou appuyez sur le bouton [Install].

Le système vérifie si les fichiers d'installation sont valides et s'il y a assez de place sur le disque SSD pour installer EXs. Une fenêtre de dialogue apparaît.



Found installer for: [nom de l'option EXs]

Space required: [nnn] MB

SSD1: [nom du disque] [nnn] GB [mémoire disponible]

11. Appuyez sur [Install] pour poursuivre l'installation.

Une demande de confirmation "Are you sure?" apparaît.

Pour annuler l'installation, appuyez sur le bouton [Cancel].

12. Appuyez sur [OK] pour poursuivre l'installation.

L'installation démarre. Elle peut prendre un certain temps: une barre de progression indique où en est l'installation.

Ensuite les fichiers installés sont vérifiés. Si la vérification ne fait état d'aucun problème, la barre de progression disparaît et l'installation est terminée. Les données d'échantillons EXs sont installées dans une partie invisible et protégée du disque. Pour utiliser EXs, chargez ses fichiers associés qui seront installés dans un nouveau dossier appelé "EXs14 EDM Drums" au sein du dossier "Korg Options".

Contenu du dossier 'EXs14 EDM Drums'

Nom de fichier/dossier	Remarques
EXs14.KSC	Fichier "Korg Sample Collection" qui vous permet de charger tous les nouveaux échantillons en une fois.
EXs14.PCG	Ce fichier contient les nouveaux programmes, patterns pour pistes rythmiques et kits de batterie.
EXs14.SNG	Ce fichier contient les morceaux avec RPPR et patterns utilisateur.

Remarque: Les fichiers EXs14.PCG et EXs14.SNG sont aussi inclus dans l'archive EXs14.zip. Ils sont identiques aux fichiers EXs14.PCG et EXs14.SNG installés. Utilisez-les comme copies de secours..

Messages d'erreur

Lors de l'installation, des messages d'erreur peuvent apparaître en cas de problème.

"Error: invalid option file"

Ce message indique que les données d'installation sont corrompues. Copiez de nouveau le fichier sur le support USB et, si l'opération échoue encore, téléchargez à nouveau les données.

"Error: not enough disk space for the installation"

Ce message indique qu'il n'y a pas assez de place sur le disque interne. Supprimez des données de la mémoire en les archivant sur un support USB pour libérer de l'espace.

Charger les nouveaux sons et échantillons

 Avant le chargement, veillez à archiver vos données importantes sur le disque interne ou sur un dispositif de mémoire USB. Quand vous chargez ces fichiers dans des mémoires de banques et de morceaux, les données se trouvant dans ces mémoires sont remplacées.

Destinations par défaut des données chargées

Par défaut, les programmes, kits de batterie et morceaux sont chargés dans les endroits suivants:


- Programmes: U-G000...015
- Patterns pour pistes rythmiques: U230...U405
- Kits de batterie: U-G00...15
- Morceaux: S000...012

Vous pouvez toutefois sélectionner d'autres destinations.

Charger les nouveaux sons et échantillons

Vous pouvez charger tous les programmes, kits de batterie, morceaux de démonstration et échantillons de batterie dans les emplacements par défaut en une fois. Pour cela:

1. Affichez la page "Disk Load".
2. Réglez "Drive Select" sur "HDD: INTERNAL HD".
3. Sélectionnez le dossier "Korg Options" et appuyez sur [Open].
4. Sélectionnez le dossier "EXs14 EDM Drums" et appuyez sur [Open].
5. Sélectionnez le fichier "EXs14.PCG".
6. Appuyez sur le bouton [Load]. Une fenêtre de dialogue apparaît.



7. Sélectionnez l'option "Load EXs14.SNG too".

Les morceaux sont chargés en même temps que les programmes, les patterns Drum Track et les kits de batterie.

8. Réglez "Select .SNG Allocation" sur "Clear".

Ce réglage efface tout autre morceau actuellement chargé.

9. Sélectionnez l'option "Load EXs14.KSC too".

Les échantillons sont chargés en même temps que les programmes et les kits de batterie.


10. Réglez "Select .KSC Allocation" sur "Append" et "Load Method" sur "KSC Setting".

11. Laissez le paramètre “.PCG Contents” réglé sur “All”.

Sous les autres paramètres se trouve une ligne affichant “Memory Required” (la mémoire nécessaire) et “Available” (disponible). (L’information sur les emplacements disponibles (“Slots”) ne concerne que les échantillons Sampling Mode.)

Si la valeur “Available” est supérieure à la valeur “Memory Required”, le texte s’affiche en noir et vous pouvez continuer.

Si la valeur “Available” est inférieure à la valeur “Memory Required”, le texte s’affiche en rouge. Vous pouvez libérer de la mémoire de différentes façons. Voyez “Libérer de la mémoire pour charger EXs14” ci-dessous.



12. Appuyez sur [OK] pour charger les données.

EXs14 fonctionne en mode de démonstration (les sons deviennent parfois inaudibles) jusqu’à ce que vous achetiez et entrez un code d’autorisation dans le KRONOS. Pour en savoir plus, voyez “Acheter et autoriser EXs14” plus loin.

Libérer de la mémoire pour charger EXs14

Si vous chargez des échantillons EXs ou Sampling Mode supplémentaires, il se pourrait qu'il n'y ait pas assez d'espace disponible pour charger simultanément les échantillons EXs14.

Pour supprimer tous les échantillons Sampling Mode à partir de la fenêtre de dialogue “Load”, réglez “Select .KSC Allocation” sur “Clear Sampling Mode Data”. Tous les échantillons Sampling Mode sont supprimés mais les échantillons EXs sont conservés. Veillez à sauvegarder les échantillons Sampling Mode que vous avez modifiés au préalable!

Alternativement, vous pouvez appuyer sur le bouton [Cancel] et procéder à des changements plus précis concernant les échantillons. Vous pouvez, par exemple, afficher la page “Global P0: Basic Setup–Sample Management” et supprimer des échantillons Sampling Mode ou EXs spécifiques.

Enfin, vous pouvez rétablir les réglages d’usine en effectuant la procédure suivante:


1. Accédez à la page “Global P0: Basic Setup-KSC Auto-Load”.
2. Désélectionnez les boutons [Auto-Load] pour tous les fichiers KSC sauf “PRELOAD.KSC”.
3. Appuyez sur le bouton [Do Auto-Load Now].

Cette opération supprime d’abord tous les échantillons Sampling Mode et EXs, puis rétablit les réglages d’usine.

Charger automatiquement les échantillons EXs14 au démarrage

Vous pouvez régler le KRONOS pour qu'il charge automatiquement les échantillons de batterie EXs14 au démarrage. Pour cela:


1. Appuyez sur le bouton GLOBAL pour passer en mode Global.
2. Affichez la page "Global Basic—KSC Auto-Load".
3. Dans la liste des fichiers KSC, cochez la case "Auto-load" à côté de "EXs14.KSC".



Charger les programmes et les kits de batterie dans une autre banque

1. Effectuez les opérations 1~10 décrites sous "Charger les nouveaux sons et échantillons", plus haut.
2. Réglez ".PCG Contents" sur "Bank U-G".
A droite de ce paramètre, le paramètre "To" apparaît.
3. Utilisez le paramètre "To" pour sélectionner la banque dont le contenu sera remplacé.
4. Appuyez sur [OK].


Les programmes et kits de batterie sont chargés dans la banque sélectionnée.



Sélectionner les nouveaux sons

Programmes

1. Appuyez sur le bouton PROG pour passer en mode Program.
2. Appuyez sur le bouton Bank U-G pour sélectionner la nouvelle banque de programmes.
- Si les programmes ont été chargés dans une autre banque, appuyez sur le bouton Bank correspondant.
3. Utilisez les boutons Inc/Dec, la molette VALUE ou le menu déroulant "Program Select" pour faire votre choix parmi les nouveaux sons.



Patterns pour piste rythmique

Les nouveaux patterns de piste rythmique sont chargés dans les mémoires U230~U405. Vous pouvez les utiliser dans n'importe quel programme, combinaison ou un morceau. A titre d'exemple, voici comment assigner un des nouveaux patterns à un programme:

1. Pour un programme HD-1, appuyez sur l'onglet [Basic/Vector] dans le bas de l'écran puis appuyez sur l'onglet [Drum Track].

Pour un programme EXi, appuyez sur le bouton [Common] dans le bas de l'écran puis appuyez sur l'onglet [Drum Track].

2. Notez la section "Drum Pattern" dans le coin supérieur gauche de l'écran.

Le paramètre "Pattern" a deux menus déroulants. Celui de gauche permet de sélectionner une banque "Preset" ou "User" tandis que celui de droite permet de choisir un pattern au sein de la banque.

3. Dans le menu gauche, sélectionnez la banque "User".
4. Dans le menu déroulant de droite, sélectionnez le pattern "U230".
5. Vérifiez que le paramètre "Shift" est réglé sur "+00".
6. Appuyez sur le bouton DRUM TRACK puis jouez sur le clavier: le pattern de batterie démarre.

Vous pouvez changer de pattern et de programme de batterie (qui fournit les sons du pattern) durant la reproduction de la piste rythmique.

7. Si vous le souhaitez, vous pouvez changer de programme de batterie dans la section "Drum Track Parameters".

Vous pouvez aussi utiliser le paramètre "Detune" pour éléver ou abaisser la hauteur des sons de batterie.

Pour en savoir plus, voyez le chapitre "Utilisation de la fonction 'Drum Track'" dans le Manuel de l'utilisateur.

Morceaux et fonction 'RPPR'

Choisissez le morceau à charger et essayez la fonction RPPR pour reproduire les patterns.

1. Appuyez sur le bouton SEQ pour passer en mode Sequencer.
2. Choisissez "S000-S012" (si vous avez choisi le réglage "Clear" pour "Select .SNG Allocation").
3. Actionnez des touches à partir de C#2 pour lancer les patterns RPPR.

Pour en savoir plus, voyez "Creating and recording RPPR data" dans le manuel de l'utilisateur.

Les programmes EXs14 requièrent les sons d'usine

Les programmes EXs14 utilisent les kits de batterie ("Drum Kits") et échantillons de batterie ("Drum Samples") chargés en usine. Si les banques d'usine ont été modifiées ou n'ont pas été chargées, les programmes n'auront pas le son voulu. Si nécessaire, archivez d'abord vos sons actuels puis rechargez les sons d'usine. Les sons d'usine sont conservés dans les fichiers PRELOAD.PCG et PRELOAD.KSC situés dans le dossier FACTORY sur le disque interne.

Acheter et autoriser EXs14

EXs14 fonctionne en mode de démonstration (les sons deviennent parfois inaudibles) jusqu'à ce que vous achetiez et entrez un code d'autorisation dans le KRONOS. Pour cela:

1. Affichez la page "Global P6: Options Info".
2. Notez l'identifiant "Public ID" affiché dans le haut de l'écran.
Vérifiez que vous l'avez copié correctement.
3. Si vous avez accès à l'internet, suivez les instructions données dans la section ci-dessous, "Acheter des licences pour options sur internet".
ou:
Si vous n'avez pas d'accès internet, suivez les instructions données dans la section suivante, ""Acheter des licences pour options auprès du distributeur Korg"".

Acheter des licences pour options sur internet

1. Rendez-vous sur <https://shop.korg.com/kronosSoundLibraries>
2. Rendez-vous sous l'onglet "Korg" et ajoutez "EXs14" à votre panier.
3. Accédez à votre compte quand vous y êtes invité.
Si vous n'avez pas encore de compte, créez-en un en suivant les instructions à l'écran. Après avoir créé votre compte, enregistrez votre KRONOS.
4. Achetez le code d'autorisation pour l' EXs14.
5. Après l'achat, vous recevrez votre code d'autorisation. Notez que ce code est lié à l'identifiant "Public ID" et ne fonctionnera pas sur d'autres systèmes KRONOS.
Si vous avez plusieurs KRONOS, vous devez acheter des autorisations distinctes pour chacun d'entre eux.
6. Quand vous avez le code d'autorisation, suivez les instructions de la section "Autoriser les options sur le KRONOS", ci-dessous.

Acheter des licences pour options auprès du distributeur Korg

Si vous n'avez pas d'accès internet, votre distributeur national Korg se fera un plaisir de vous aider à acquérir des codes d'autorisation.

1. Contactez votre distributeur Korg et demandez-lui de vous aider à acheter des autorisations pour options KRONOS.

Pour savoir comment contacter votre distributeur Korg, adressez-vous à votre revendeur Korg ou consultez la page suivante sur le site web Korg:

<http://www.korg.com/corporate/distributors/>

2. **Après avoir acheté le ou les codes d'autorisation, passez à la section "Autoriser les options sur le KRONOS", ci-dessous.**

Autoriser les options sur le KRONOS

1. Affichez la page "Global P6: Options Info".
2. Sélectionnez l'option à autoriser dans la liste "Installed Options".
3. Appuyez sur le bouton [Authorize Selected].

La fenêtre "Authorize Selected" s'affiche.

4. Entrez le code d'autorisation.

Le nom de l'option ou de la série d'options sélectionnée apparaît dans le haut de la fenêtre. La fenêtre affiche un clavier à l'écran permettant d'entrer le code d'autorisation.

5. Appuyez sur [OK].

Si vous avez entré un code d'autorisation valide, la liste indique que l'option ou la série d'options est autorisée ("Authorized") et les restrictions audio du mode de démonstration sont supprimées.

Assistance

Si vous avez la moindre question concernant les bibliothèques de sons pour KRONOS, adressez-vous au distributeur Korg de votre pays.

Vous trouverez des informations sur les distributeurs Korg du monde entier sur le site <http://www.korg.com/corporate/distributors/>

Voice Name List

Programs

Bank USER-G [HD-1]

#	OSC	Name	Category	Sub Category
000	D	Electro House Kit	Drums	Dance Drums
001	D	Progressive House Kit	Drums	Dance Drums
002	D	Techno / Minimal Kit	Drums	Dance Drums
003	D	Dubstep / Glitch Hop Kit	Drums	Dance Drums
004	D	Trap Kit	Drums	Dance Drums
005	D	R&B / Funk Kit	Drums	Dance Drums
006	D	D&B / Breaks Kit	Drums	Dance Drums
007	D	Chill / Down Tempo Kit	Drums	Dance Drums
008	D	Electronica Kit	Drums	Dance Drums
009	D	Vintage Machine Kit	Drums	Dance Drums
010	D	Korg Vintage Machine Kit	Drums	Dance Drums
011	D	Dance BD Kit [E0~E8]	Drums	Dance Drums
012	D	Dance SD Kit [E0~E8]	Drums	Dance Drums
013	D	Dance Clap Kit [C3~F5]	Drums	Dance Drums
014	D	Dance HH Kit [E0~E8]	Drums	Dance Drums
015	D	Dance Hit Kit [E0~E8]	Drums	Dance Drums

↑ D: Drums program

Drum Kits

U-G00: Electro House Kit

Key	Zone	Drumsample	Bus	Ex
E0	1	EXs14 Mono,444:HH-CI-88-Electro 1-EXs14	IFX4	4
F0	1	EXs14 Mono,445:HH-CI-88-Electro 2-EXs14	IFX4	4
F#0	1	EXs14 Mono,446:HH-Open-88-Electro-EXs14	IFX4	4
G0	1	EXs14 Stereo,2:BD-Techno 2-EXs14-L	IFX2	Off
G#0	1	EXs14 Mono,385:Clap-DDD5-EXs14	IFX3	Off
A0	1	EXs14 Stereo,0:BD-Electro 17-EXs14-L	IFX2	Off
A#0	1	EXs14 Stereo,12:Hi Hat-Electro15-EXs14-L	IFX5	10
B0	1	EXs14 Stereo,25:White Noise -EXs14-L	IFX5	Off
C1	1	EXs14 Mono,10:BD-Electro 11-EXs14	IFX2	Off
C#1	1	EXs14 Mono,8:BD-Electro 09-EXs14	IFX2	Off
D1	1	EXs14 Mono,453:BD-99-Electro 1-EXs14	IFX2	Off
D#1	1	EXs14 Mono,427:BD-88-Electro 1-EXs14	IFX2	Off
E1	1	EXs14 Mono,16:BD-Electro 17-EXs14	IFX2	Off
F1	1	EXs14 Mono,63:SD-Electro 20-EXs14	IFX1	Off
F#1	1	EXs14 Mono,64:SD-Electro 21-EXs14	IFX1	Off
G1	1	EXs14 Mono,52:SD-Electro 09-EXs14	IFX1	Off
G#1	1	EXs14 Mono,51:SD-Electro 08-EXs14	IFX1	Off
A1	1	EXs14 Mono,48:SD-Electro 05-EXs14	IFX1	Off
A#1	1	ROM Mono,537:Crash-Dance 99	IFX4	Off
B1	1	EXs14 Mono,2:BD-Electro 03-EXs14	IFX2	Off
C2	1	EXs14 Mono,2:BD-Electro 03-EXs14	IFX2	Off
C#2	1	EXs14 Mono,15:BD-Electro 16-EXs14	IFX2	Off
D2	1	EXs14 Mono,14:BD-Electro 15-EXs14	IFX2	Off
D#2	1	EXs14 Mono,13:BD-Electro 14-EXs14	IFX2	Off
E2	1	EXs14 Mono,0:BD-Electro 01-EXs14	IFX2	Off
F2	1	EXs14 Mono,59:SD-Electro 16-EXs14	IFX1	Off
F#2	1	EXs14 Mono,48:SD-Electro 05-EXs14	IFX1	Off
G2	1	EXs14 Stereo,5:SD-Electro 27-EXs14	IFX1	Off
G#2	1	EXs14 Mono,62:SD-Electro 19-EXs14	IFX1	Off
A2	1	EXs14 Mono,52:SD-Electro 09-EXs14	IFX1	Off
A#2	1	EXs14 Mono,67:SD-Electro 24-EXs14	IFX1	Off
B2	1	EXs14 Mono,11:BD-Electro 12-EXs14	IFX2	Off
C3	1	EXs14 Mono,12:BD-Electro 13-EXs14	IFX2	Off
C#3	1	EXs14 Mono,353:Rim-DDD1 2-EXs14	IFX1	Off
D3	1	EXs14 Mono,44:SD-Electro 01-EXs14	IFX1	Off
D#3	1	EXs14 Mono,127:Clap-Electro 02-EXs14	IFX5	Off
E3	1	EXs14 Mono,65:SD-Electro 22-EXs14	IFX1	Off
F3	1	EXs14 Mono,142:Tom-Electro-EXs14	IFX3	Off
F#3	1	EXs14 Mono,357:Shaker-DDD1 4-EXs14	IFX5	1
G3	1	EXs14 Mono,142:Tom-Electro-EXs14	IFX3	Off
G#3	1	EXs14 Mono,154:Hi Hat-Electro 03-EXs14	IFX5	1
A3	1	EXs14 Mono,142:Tom-Electro-EXs14	IFX3	Off
A#3	1	EXs14 Mono,152:Hi Hat-Electro 01-EXs14	IFX5	1
B3	1	EXs14 Mono,285:Tom-KPR77 1-EXs14	IFX3	Off
C4	1	EXs14 Mono,285:Tom-KPR77 1-EXs14	IFX3	Off
C#4	1	EXs14 Mono,480:Crash-99-EXs14	IFX5	Off
D4	1	EXs14 Mono,285:Tom-KPR77 1-EXs14	IFX3	Off
D#4	1	EXs14 Mono,481:Ride-99 1-EXs14	IFX5	Off
E4	1	ROM Mono,537:Crash-Dance 99	IFX5	Off
F4	1	EXs14 Mono,482:Ride-99 2-EXs14	IFX5	Off
F#4	1	EXs14 Mono,162:Hi Hat-Electro 11-EXs14	IFX5	2
G4	1	EXs14 Mono,482:Ride-99 2-EXs14	IFX5	Off
G#4	1	EXs14 Mono,157:Hi Hat-Electro 06-EXs14	IFX5	2
A4	1	EXs14 Mono,480:Crash-99-EXs14	IFX5	Off
A#4	1	EXs14 Stereo,13:Hi Hat-Electro16-EXs14-L	IFX5	2
B4	1	EXs14 Mono,392:Ride-DDD5-EXs14	IFX5	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	EXs14 Mono,402:Conga-DDD5 2-EXs14	IFX3	Off
C#5	1	EXs14 Mono,397:Bongo-DDD5 1-EXs14	IFX3	Off
D5	1	EXs14 Mono,401:Conga-DDD5 1-EXs14	IFX3	Off
D#5	1	EXs14 Mono,398:Bongo-DDD5 2-EXs14	IFX3	Off
E5	1	EXs14 Mono,403:Conga-DDD5 3-EXs14	IFX3	Off
F5	1	EXs14 Mono,324:Agogo-DDD1 2-EXs14	IFX3	Off
F#5	1	EXs14 Mono,355:Shaker-DDD1 2-EXs14	IFX3	Off
G5	1	EXs14 Mono,325:Agogo-DDD1 2-EXs14	IFX3	Off
G#5	1	EXs14 Mono,356:Shaker-DDD1 3-EXs14	IFX3	Off
A5	1	EXs14 Mono,377:WD-DDD1 1-EXs14	IFX3	Off
A#5	1	EXs14 Mono,157:Hi Hat-Electro 06-EXs14	IFX3	Off
B5	1	EXs14 Mono,378:WD-DDD1 2-EXs14	IFX3	Off
C6	1	EXs14 Stereo,17:Dance Hit 4-EXs14-L	IFX5	Off
C#6	1	EXs14 Stereo,20:Dance Hit 7-EXs14-L	IFX5	Off
D6	1	EXs14 Stereo,19:Dance Hit 6-EXs14-L	IFX5	Off
D#6	1	EXs14 Stereo,21:Dance Hit 8-EXs14-L	IFX5	Off
E6	1	EXs14 Stereo,19:Dance Hit 6-EXs14-L	IFX5	Off
F6	1	EXs14 Mono,186:Synth Hit 02-EXs14	IFX5	Off
F#6	1	EXs14 Mono,205:Drum Hit 02-EXs14	IFX5	Off
G6	1	EXs14 Mono,187:Synth Hit 03-EXs14	IFX5	Off
G#6	1	EXs14 Mono,202:Synth Hit 18-EXs14	IFX5	Off
A6	1	EXs14 Mono,196:Synth Hit 12-EXs14	IFX5	Off
A#6	1	EXs14 Mono,199:Synth Hit 15-EXs14	IFX5	Off
B6	1	EXs14 Mono,200:Synth Hit 16-EXs14	IFX5	Off
C7	1	EXs14 Stereo,8:Clap-Dance 3-EXs14-L	IFX5	Off
C#7	1	EXs14 Mono,126:Clap-Electro 01-EXs14	IFX5	Off
D7	1	EXs14 Mono,127:Clap-Electro 02-EXs14	IFX5	Off
D#7	1	EXs14 Mono,128:Clap-Electro 03-EXs14	IFX5	Off
E7	1	EXs14 Mono,129:Clap-Electro 04-EXs14	IFX5	Off
F7	1	EXs14 Mono,133:Clap-Electro 08-EXs14	IFX5	Off
F#7	1	EXs14 Mono,287:HH-Closed-KPR77-EXs14	IFX4	3
G7	1	EXs14 Mono,219:Drum Hit 16-EXs14	IFX3	Off
G#7	1	EXs14 Mono,288:HH-Open-KPR77-EXs14	IFX4	3
A7	1	EXs14 Mono,194:Synth Hit 10-EXs14	IFX3	Off
A#7	1	EXs14 Mono,289:Ride-KPR77-EXs14	IFX4	3
B7	1	EXs14 Mono,223:Drum Hit 20-EXs14	IFX3	Off
C8	1	EXs14 Mono,226:Drum Hit 23-EXs14	IFX3	Off
C#8	1	EXs14 Mono,224:Drum Hit 21-EXs14	IFX3	Off
D8	1	EXs14 Mono,258:Acc-Donkama-DE11-EXs14	IFX3	Off
D#8	1	ROM Mono,1156:Voice 42 "Oohh"	IFX3	Off
E8	1	EXs14 Mono,112:SD-Funk 18-EXs14	IFX5	Off

U-G01: Progressive House Kit

Key	Zone	Drumsample	Bus	Ex
E0	1	EXs14 Mono,175:Hi Hat-Funk 06-EXs14	IFX4	4
F0	1	EXs14 Mono,174:Hi Hat-Funk 05-EXs14	IFX4	4
F#0	1	EXs14 Mono,177:Hi Hat-Funk 08-Op-EXs14	IFX4	4
G0	1	EXs14 Mono,131:Clap-Electro 06-EXs14	IFX4	Off
G#0	1	EXs14 Stereo,6:Clap-Dance 1-EXs14-L	IFX4	Off
A0	1	EXs14 Stereo,3:SD-Electro 25-EXs14-L	IFX5	Off
A#0	1	EXs14 Mono,62:SD-Electro 19-EXs14	IFX5	10
B0	1	ROM Mono,39:BD-Trance 1	IFX2	Off
C1	1	EXs14 Stereo,2:BD-Techno 2-EXs14-L	IFX2	Off
C#1	1	EXs14 Mono,11:BD-Electro 12-EXs14	IFX2	Off
D1	1	EXs14 Mono,13:BD-Electro 14-EXs14	IFX2	Off
D#1	1	EXs14 Mono,8:BD-Electro 09-EXs14	IFX2	Off
E1	1	EXs14 Mono,458:BD-99-Electro 6-EXs14	IFX2	Off
F1	1	EXs14 Mono,123:Clap-Dance 3-EXs14-R	IFX1	Off
F#1	1	EXs14 Mono,61:SD-Electro 18-EXs14	IFX1	Off
G1	1	EXs14 Mono,57:SD-Electro 14-EXs14	IFX1	Off
G#1	1	EXs14 Mono,48:SD-Electro 05-EXs14	IFX1	Off
A1	1	EXs14 Mono,58:SD-Electro 15-EXs14	IFX1	Off
A#1	1	ROM Mono,53:Crash Dance 1	IFX4	Off
B1	1	EXs14 Mono,2:BD-Electro 03-EXs14	IFX2	Off
C2	1	EXs14 Mono,6:BD-Electro 07-EXs14	IFX2	Off
C#2	1	EXs14 Mono,5:BD-Electro 06-EXs14	IFX2	Off
D2	1	EXs14 Mono,1:BD-Electro 02-EXs14	IFX2	Off
D#2	1	EXs14 Mono,2:BD-Electro 03-EXs14	IFX2	Off
E2	1	EXs14 Mono,14:BD-Electro 15-EXs14	IFX2	Off
F2	1	EXs14 Mono,115:SD-HipHop 3-EXs14	IFX1	Off
F#2	1	EXs14 Mono,83:SD-Breaks 10-EXs14	IFX1	Off
G2	1	EXs14 Mono,60:SD-Electro 17-EXs14	IFX1	Off
G#2	1	EXs14 Mono,283:SD-KPR77-EXs14	IFX1	Off
A2	1	EXs14 Mono,113:SD-HipHop 1-EXs14	IFX1	Off
A#2	1	EXs14 Mono,44:SD-Electro 01-EXs14	IFX1	Off
B2	1	EXs14 Mono,9:BD-Electro 10-EXs14	IFX2	Off
C3	1	EXs14 Mono,3:BD-Electro 04-EXs14	IFX2	Off
C#3	1	EXs14 Mono,393:Rim-DDD5 1-EXs14	IFX1	Off
D3	1	EXs14 Mono,52:SD-Electro 09-EXs14	IFX1	Off
D#3	1	EXs14 Stereo,6:Clap-Dance 1-EXs14-L	IFX5	Off
E3	1	EXs14 Mono,47:SD-Electro 04-EXs14	IFX1	Off
F3	1	EXs14 Mono,115:SD-HipHop 3-EXs14	IFX3	Off
F#3	1	EXs14 Mono,483:Hi Hat-Cl-99-comp1-EXs14	IFX4	1
G3	1	EXs14 Mono,115:SD-HipHop 3-EXs14	IFX3	Off
G#3	1	EXs14 Mono,486:Hi Hat-Cl-99-comp4-EXs14	IFX4	1
A3	1	EXs14 Mono,115:SD-HipHop 3-EXs14	IFX3	Off
A#3	1	EXs14 Mono,492:Hi Hat-Op-99-comp3-EXs14	IFX4	1
B3	1	EXs14 Mono,555:Tom-Smns 3-EXs14	IFX3	Off
C4	1	EXs14 Mono,555:Tom-Smns 3-EXs14	IFX3	Off
C#4	1	ROM Mono,522:Crash Cymbal 05 f	IFX5	Off
D4	1	EXs14 Mono,555:Tom-Smns 3-EXs14	IFX3	Off
D#4	1	ROM Mono,544:Ride Cymbal 01 ff	IFX5	Off
E4	1	EXs14 Mono,480:Crash-99-EXs14	IFX5	Off
F4	1	EXs14 Mono,481:Ride-99 1-EXs14	IFX5	Off
F#4	1	EXs14 Mono,162:Hi Hat-Electro 11-EXs14	IFX5	2
G4	1	ROM Mono,571:Splash Cymbal 02 ff	IFX5	Off
G#4	1	EXs14 Mono,163:Hi Hat-Electro 12-EXs14	IFX5	2
A4	1	ROM Mono,537:Crash-Dance 99	IFX5	Off
A#4	1	EXs14 Stereo,13:Hi Hat-Electro16-EXs14-L	IFX5	2
B4	1	EXs14 Mono,482:Ride-99 2-EXs14	IFX5	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	EXs14 Mono,378:WD-DDD1 2-EXs14	IFX3	Off
C#5	1	EXs14 Mono,354:Shaker-DDD1 1-EXs14	IFX3	Off
D5	1	EXs14 Mono,377:WD-DDD1 1-EXs14	IFX3	Off
D#5	1	EXs14 Mono,356:Shaker-DDD1 3-EXs14	IFX3	Off
E5	1	EXs14 Mono,358:Tambourine-DDD1 1-EXs14	IFX3	Off
F5	1	EXs14 Mono,359:Tambourine-DDD1 2-EXs14	IFX3	Off
F#5	1	EXs14 Mono,373:WBlock-DDD1 1-EXs14	IFX3	Off
G5	1	EXs14 Mono,360:Tambourine-DDD1 3-EXs14	IFX3	Off
G#5	1	EXs14 Mono,374:WBlock-DDD1 2-EXs14	IFX3	Off
A5	1	EXs14 Mono,373:WBlock-DDD1 1-EXs14	IFX3	Off
A#5	1	EXs14 Mono,405:Claves-DDD5-EXs14	IFX3	Off
B5	1	EXs14 Mono,370:Triangle-DDD1 1-EXs14	IFX3	Off
C6	1	EXs14 Stereo,22:Dance Hit 9-EXs14-L	IFX5	Off
C#6	1	EXs14 Stereo,18:Dance Hit 5-EXs14-L	IFX5	Off
D6	1	EXs14 Mono,225:Drum Hit 22-EXs14	IFX5	Off
D#6	1	EXs14 Mono,217:Drum Hit 14-EXs14	IFX5	Off
E6	1	EXs14 Stereo,15:Dance Hit 2-EXs14-L	IFX5	Off
F6	1	EXs14 Mono,212:Drum Hit 09-EXs14	IFX5	Off
F#6	1	EXs14 Mono,375:WBlock-DDD1 3-EXs14	IFX3	Off
G6	1	EXs14 Mono,213:Drum Hit 10-EXs14	IFX5	Off
G#6	1	EXs14 Mono,376:WBlock-DDD1 4-EXs14	IFX3	Off
A6	1	EXs14 Mono,215:Drum Hit 12-EXs14	IFX5	Off
A#6	1	EXs14 Mono,340:JingleBell-DDD1 1-EXs14	IFX3	Off
B6	1	EXs14 Mono,216:Drum Hit 13-EXs14	IFX5	Off
C7	1	EXs14 Mono,131:Clap-Electro 06-EXs14	IFX5	Off
C#7	1	EXs14 Mono,284:Clap-KPR77-EXs14	IFX5	Off
D7	1	EXs14 Mono,136:Clap-Electro 11-EXs14	IFX5	Off
D#7	1	EXs14 Mono,139:Clap-HipHop 1-EXs14	IFX5	Off
E7	1	EXs14 Mono,265:Cym-Donkama-DE20-EXs14	IFX4	Off
F7	1	EXs14 Mono,232:Dance Hit 3-EXs14-L	IFX5	Off
F#7	1	EXs14 Mono,280:HH-Closed-KPR55-EXs14	IFX5	3
G7	1	EXs14 Mono,237:Dance Hit 5-EXs14-R	IFX5	Off
G#7	1	EXs14 Mono,280:HH-Closed-KPR55-EXs14	IFX5	3
A7	1	ROM Mono,1045:Synth Hit Loop 2	IFX5	Off
A#7	1	ROM Mono,1045:Synth Hit Loop 2	IFX5	Off
B7	1	ROM Mono,1045:Synth Hit Loop 2	IFX5	Off
C8	1	EXs14 Mono,358:Tambourine-DDD1 1-EXs14	IFX3	Off
C#8	1	EXs14 Mono,342:Kiuchi-DDD1 1-EXs14	IFX3	Off
D8	1	EXs14 Mono,359:Tambourine-DDD1 2-EXs14	IFX3	Off
D#8	1	EXs14 Mono,343:Kiuchi-DDD1 2-EXs14	IFX3	Off
E8	1	EXs14 Stereo,13:Hi Hat-Electro16-EXs14-L	IFX3	Off

U-G02: Techno / Minimal Kit

Key	Zone	Drumsample	Bus	Ex
E0	1	ROM Mono,1022:Up Zap	IFX5	Off
F0	1	ROM Mono,1021:Down Zap	IFX5	Off
F#0	1	ROM Mono,1020:Zap 2	IFX5	Off
G0	1	EXs14 Stereo,2:BD-Techno 2-EXs14-L	IFX2	Off
G#0	1	EXs14 Mono,126:Clap-Electro 01-EXs14	IFX5	Off
A0	1	EXs14 Stereo,1:BD-Techno 1-EXs14-L	IFX2	Off
A#0	1	EXs14 Mono,483:Hi Hat-Cl-99-comp1-EXs14	IFX4	5
B0	1	EXs14 Mono,491:Hi Hat-Op-99-comp2-EXs14	IFX4	5
C1	1	EXs14 Stereo,0:BD-Electro 17-EXs14-L	IFX2	Off
C#1	1	EXs14 Mono,451:BD-99 1-EXs14	IFX2	Off
D1	1	EXs14 Mono,429:BD-88-Electro 3-EXs14	IFX2	Off
D#1	1	EXs14 Mono,9:BD-Electro 10-EXs14	IFX2	Off
E1	1	EXs14 Mono,290:BD-DDD1 1-EXs14	IFX2	Off
F1	1	ROM Mono,1174:"Pan"	IFX4	Off
F#1	1	ROM Mono,1144:Voice 30 "Bang"	IFX4	Off
G1	1	EXs14 Mono,72:SD-Electro 27-EXs14-L	IFX1	Off
G#1	1	EXs14 Mono,64:SD-Electro 21-EXs14	IFX1	Off
A1	1	EXs14 Mono,51:SD-Electro 08-EXs14	IFX1	Off
A#1	1	ROM Mono,561:Ride-Dance 99	IFX4	Off
B1	1	ROM Mono,10:BD-05-amb f	IFX2	Off
C2	1	EXs14 Mono,451:BD-99 1-EXs14	IFX2	Off
C#2	1	EXs14 Mono,424:BD-88 3-EXs14	IFX2	Off
D2	1	EXs14 Mono,452:BD-99 2-EXs14	IFX2	Off
D#2	1	EXs14 Mono,457:BD-99-Electro 5-EXs14	IFX2	Off
E2	1	EXs14 Mono,454:BD-99-Electro 2-EXs14	IFX2	Off
F2	1	EXs14 Mono,61:SD-Electro 18-EXs14	IFX1	Off
F#2	1	EXs14 Mono,104:SD-Funk 10-EXs14	IFX1	Off
G2	1	EXs14 Mono,105:SD-Funk 11-EXs14	IFX1	Off
G#2	1	EXs14 Mono,278:SD-KPR55 4-EXs14	IFX1	Off
A2	1	EXs14 Mono,383:SD-DDD5 1-EXs14	IFX1	Off
A#2	1	EXs14 Mono,441:SD-88-Trap 8-EXs14	IFX1	Off
B2	1	EXs14 Mono,424:BD-88 3-EXs14	IFX2	Off
C3	1	EXs14 Mono,452:BD-99 2-EXs14	IFX2	Off
C#3	1	EXs14 Mono,353:Rim-DDD1 2-EXs14	IFX1	Off
D3	1	EXs14 Mono,283:SD-KPR77-EXs14	IFX1	Off
D#3	1	EXs14 Stereo,7:Clap-Dance 2-EXs14-L	IFX1	Off
E3	1	EXs14 Mono,264:SD-Donkama-DE20-EXs14	IFX1	Off
F3	1	EXs14 Mono,386:Tom-DDD5 1-EXs14	IFX3	Off
F#3	1	EXs14 Mono,287:HH-Closed-KPR77-EXs14	IFX4	1
G3	1	EXs14 Mono,386:Tom-DDD5 1-EXs14	IFX3	Off
G#3	1	EXs14 Mono,287:HH-Closed-KPR77-EXs14	IFX4	1
A3	1	EXs14 Mono,386:Tom-DDD5 1-EXs14	IFX3	Off
A#3	1	EXs14 Mono,288:HH-Open-KPR77-EXs14	IFX4	1
B3	1	EXs14 Mono,286:Tom-KPR77 2-EXs14	IFX3	Off
C4	1	EXs14 Mono,286:Tom-KPR77 2-EXs14	IFX3	Off
C#4	1	EXs14 Mono,391:Crash-DDD5-EXs14	IFX4	Off
D4	1	EXs14 Mono,286:Tom-KPR77 2-EXs14	IFX3	Off
D#4	1	EXs14 Mono,392:Ride-DDD5-EXs14	IFX4	Off
E4	1	EXs14 Mono,265:Cym-Donkama-DE20-EXs14	IFX4	Off
F4	1	EXs14 Mono,289:Ride-KPR77-EXs14	IFX4	Off
F#4	1	EXs14 Mono,280:HH-Closed-KPR55-EXs14	IFX4	2
G4	1	EXs14 Mono,481:Ride-99 1-EXs14	IFX5	Off
G#4	1	EXs14 Mono,280:HH-Closed-KPR55-EXs14	IFX4	2
A4	1	EXs14 Mono,256:SD-Donkama-DE11-EXs14	IFX4	Off
A#4	1	EXs14 Mono,281:HH-Open-KPR55-EXs14	IFX4	2
B4	1	ROM Mono,561:Ride-Dance 99	IFX4	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	EXs14 Mono,259:LBongo-DonkamaDE11-EXs14	IFX3	Off
C#5	1	EXs14 Mono,258:Acc-Donkama-DE11-EXs14	IFX5	Off
D5	1	EXs14 Mono,260:LBongo-DonkamaDE11-EXs14	IFX3	Off
D#5	1	EXs14 Mono,262:WBlock-DonkamaDE11-EXs14	IFX3	Off
E5	1	EXs14 Mono,261:Maraca-DonkamaDE11-EXs14	IFX3	Off
F5	1	EXs14 Mono,270:Maraca-DonkamaDE20-EXs14	IFX3	Off
F#5	1	EXs14 Mono,266:Acc-Donkama-DE20-EXs14	IFX5	Off
G5	1	EXs14 Mono,269:Conga-DonkamaDE20-EXs14	IFX3	Off
G#5	1	EXs14 Mono,272:WBlock-DonkamaDE20-EXs14	IFX3	Off
A5	1	EXs14 Mono,271:Claves-DonkamaDE20-EXs14	IFX3	Off
A#5	1	EXs14 Mono,268:LBongo-DonkamaDE20-EXs14	IFX3	Off
B5	1	EXs14 Mono,267:LBongo-DonkamaDE20-EXs14	IFX3	Off
C6	1	EXs14 Mono,193:Synth Hit 09-EXs14	IFX5	Off
C#6	1	EXs14 Mono,196:Synth Hit 12-EXs14	IFX5	Off
D6	1	EXs14 Mono,191:Synth Hit 07-EXs14	IFX5	Off
D#6	1	EXs14 Mono,198:Synth Hit 14-EXs14	IFX5	Off
E6	1	EXs14 Mono,191:Synth Hit 07-EXs14	IFX5	Off
F6	1	EXs14 Mono,195:Synth Hit 11-EXs14	IFX5	Off
F#6	1	EXs14 Mono,194:Synth Hit 10-EXs14	IFX5	Off
G6	1	EXs14 Mono,216:Drum Hit 13-EXs14	IFX5	Off
G#6	1	EXs14 Mono,205:Drum Hit 02-EXs14	IFX5	Off
A6	1	EXs14 Mono,215:Drum Hit 12-EXs14	IFX5	Off
A#6	1	EXs14 Mono,186:Synth Hit 02-EXs14	IFX5	Off
B6	1	EXs14 Stereo,15:Dance Hit 2-EXs14-L	IFX5	Off
C7	1	EXs14 Mono,254:BD-Donkama 1-DE11-EXs14	IFX2	Off
C#7	1	EXs14 Mono,394:Rim-DDD5 2-EXs14	IFX1	7
D7	1	EXs14 Mono,264:SD-Donkama-DE20-EXs14	IFX1	Off
D#7	1	EXs14 Mono,284:Clap-KPR77-EXs14	IFX5	7
E7	1	ROM Mono,996:Perc-Dance 04-Closed	IFX3	Off
F7	1	EXs14 Mono,225:Drum Hit 22-EXs14	IFX5	Off
F#7	1	EXs14 Mono,157:Hi Hat-Electro 06-EXs14	IFX5	3
G7	1	EXs14 Mono,234:Dance Hit 4-EXs14-L	IFX5	Off
G#7	1	EXs14 Mono,159:Hi Hat-Electro 08-EXs14	IFX5	3
A7	1	EXs14 Stereo,18:Dance Hit 5-EXs14-L	IFX5	Off
A#7	1	EXs14 Mono,165:Hi Hat-Electro 14-EXs14	IFX5	3
B7	1	EXs14 Stereo,10:Clap-Electro 12-EXs14-L	IFX5	Off
C8	1	EXs14 Mono,182:Hi Hat-Funk 13-EXs14	IFX5	Off
C#8	1	EXs14 Mono,145:Tom-Breaks 1-EXs14	IFX5	Off
D8	1	EXs14 Mono,183:Hi Hat-Funk 14-EXs14	IFX5	Off
D#8	1	EXs14 Mono,116:SD-HipHop 4-EXs14	IFX5	Off
E8	1	EXs14 Mono,205:Drum Hit 02-EXs14	IFX5	Off

U-G03: Dubstep / Glitch Hop Kit

Key	Zone	Drumsample	Bus	Ex
E0	1	EXs14 Mono,153:Hi Hat-Electro 02-EXs14	IFX4	4
F0	1	EXs14 Mono,153:Hi Hat-Electro 02-EXs14	IFX4	4
F#0	1	EXs14 Mono,152:Hi Hat-Electro 01-EXs14	IFX4	4
G0	1	EXs14 Mono,11:BD-Electro 12-EXs14	IFX2	Off
G#0	1	EXs14 Mono,134:Clap-Electro 09-EXs14	IFX5	Off
A0	1	EXs14 Mono,60:SD-Electro 17-EXs14	IFX3	Off
A#0	1	EXs14 Mono,28:BD-Funk 4-EXs14	IFX2	10
B0	1	EXs14 Mono,37:BD-HipHop 4-EXs14	IFX2	Off
C1	1	EXs14 Mono,430:BD-88-Electro 4-EXs14	IFX2	Off
C#1	1	EXs14 Mono,8:BD-Electro 09-EXs14	IFX2	Off
D1	1	EXs14 Mono,453:BD-99-Electro 1-EXs14	IFX2	Off
D#1	1	EXs14 Mono,30:BD-Funk 6-EXs14	IFX2	Off
E1	1	EXs14 Mono,454:BD-99-Electro 2-EXs14	IFX2	Off
F1	1	EXs14 Mono,49:SD-Electro 06-EXs14	IFX1	Off
F#1	1	EXs14 Mono,117:SD-HipHop 5-EXs14	IFX1	Off
G1	1	EXs14 Mono,115:SD-HipHop 3-EXs14	IFX1	Off
G#1	1	EXs14 Mono,438:SD-88-Trap 5-EXs14	IFX1	Off
A1	1	EXs14 Mono,48:SD-Electro 05-EXs14	IFX1	Off
A#1	1	ROM Mono,535:Crash Dance 1	IFX4	Off
B1	1	EXs14 Mono,2:BD-Electro 03-EXs14	IFX2	Off
C2	1	EXs14 Mono,0:BD-Electro 01-EXs14	IFX2	Off
C#2	1	EXs14 Mono,11:BD-Electro 12-EXs14	IFX2	Off
D2	1	EXs14 Mono,29:BD-Funk 5-EXs14	IFX2	Off
D#2	1	EXs14 Mono,36:BD-HipHop 3-EXs14	IFX2	Off
E2	1	EXs14 Mono,15:BD-Electro 16-EXs14	IFX2	Off
F2	1	EXs14 Mono,67:SD-Electro 24-EXs14	IFX1	Off
F#2	1	EXs14 Stereo,3:SD-Electro 25-EXs14-L	IFX1	Off
G2	1	EXs14 Mono,81:SD-Breaks 08-EXs14	IFX1	Off
G#2	1	EXs14 Mono,48:SD-Electro 05-EXs14	IFX1	Off
A2	1	EXs14 Mono,85:SD-Breaks 12-EXs14	IFX1	Off
A#2	1	EXs14 Mono,45:SD-Electro 02-EXs14	IFX1	Off
B2	1	EXs14 Mono,6:BD-Electro 07-EXs14	IFX2	Off
C3	1	EXs14 Mono,1:BD-Electro 02-EXs14	IFX2	Off
C#3	1	EXs14 Mono,393:Rim-DDD5 1-EXs14	IFX1	Off
D3	1	EXs14 Stereo,3:SD-Electro 25-EXs14-L	IFX1	Off
D#3	1	EXs14 Stereo,9:Clap-Dance 4-EXs14-L	IFX3	Off
E3	1	EXs14 Mono,47:SD-Electro 04-EXs14	IFX1	Off
F3	1	EXs14 Mono,142:Tom-Electro-EXs14	IFX3	Off
F#3	1	EXs14 Mono,448:HiHat-Cl-88 2-Trap-EXs14	IFX4	1
G3	1	EXs14 Mono,142:Tom-Electro-EXs14	IFX3	Off
G#3	1	EXs14 Mono,447:HiHat-Cl-88 1-Trap-EXs14	IFX4	1
A3	1	EXs14 Mono,142:Tom-Electro-EXs14	IFX3	Off
A#3	1	EXs14 Mono,449:HiHat-Open-88-Trap-EXs14	IFX4	1
B3	1	EXs14 Mono,409:Timbale-DDD5-EXs14	IFX3	Off
C4	1	EXs14 Mono,409:Timbale-DDD5-EXs14	IFX3	Off
C#4	1	ROM Mono,535:Crash Dance 1	IFX5	Off
D4	1	EXs14 Mono,409:Timbale-DDD5-EXs14	IFX3	Off
D#4	1	EXs14 Mono,481:Ride-99 1-EXs14	IFX5	Off
E4	1	ROM Mono,537:Crash-Dance 99	IFX5	Off
F4	1	ROM Mono,561:Ride-Dance 99	IFX5	Off
F#4	1	ROM Mono,511:88-HHat Closed	IFX4	2
G4	1	ROM Mono,565:Broken Hi-Hat	IFX5	Off
G#4	1	ROM Mono,511:88-HHat Closed	IFX4	2
A4	1	EXs14 Mono,480:Crash-99-EXs14	IFX5	Off
A#4	1	ROM Mono,512:88-HHat Open	IFX4	2
B4	1	EXs14 Mono,482:Ride-99 2-EXs14	IFX5	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	EXs14 Mono,269:LConga-DonkamaDE20-EXs14	IFX3	Off
C#5	1	ROM Mono,1001:Perc-Dance 07 a	IFX3	Off
D5	1	EXs14 Mono,267:LBongo-DonkamaDE20-EXs14	IFX3	Off
D#5	1	ROM Mono,746:Tambourine 1-Accent	IFX3	Off
E5	1	EXs14 Mono,268:HBongo-DonkamaDE20-EXs14	IFX3	Off
F5	1	ROM Mono,758:Tri.& Tamb. h	IFX3	Off
F#5	1	EXs14 Mono,189:Synth Hit 05-EXs14	IFX5	Off
G5	1	ROM Mono,759:Tri.& Tamb. i	IFX3	Off
G#5	1	EXs14 Mono,197:Synth Hit 13-EXs14	IFX5	Off
A5	1	EXs14 Mono,366:Timbale-DDD1 5-EXs14	IFX3	Off
A#5	1	EXs14 Mono,195:Synth Hit 11-EXs14	IFX5	Off
B5	1	EXs14 Mono,270:Maraca-DonkamaDE20-EXs14	IFX3	Off
C6	1	ROM Mono,967:WD-Kangaroo 5	IFX3	Off
C#6	1	EXs14 Stereo,12:Hi Hat-Electro15-EXs14-L	IFX3	Off
D6	1	ROM Mono,968:WD-Kangaroo 6	IFX3	Off
D#6	1	EXs14 Stereo,13:Hi Hat-Electro16-EXs14-L	IFX3	Off
E6	1	ROM Mono,969:WD-Kangaroo 7	IFX3	Off
F6	1	ROM Mono,1003:Perc-Dance 08	IFX3	Off
F#6	1	ROM Mono,1022:Up Zap	IFX5	Off
G6	1	ROM Mono,948:WD-Big Hand 2	IFX3	Off
G#6	1	ROM Mono,1021:Down Zap	IFX5	5
A6	1	ROM Mono,949:WD-Big Hand 3	IFX3	Off
A#6	1	ROM Mono,1020:Zap 2	IFX5	Off
B6	1	ROM Mono,947:WD-Big Hand 1	IFX3	Off
C7	1	EXs14 Mono,431:BD-88-Trap 1-EXs14	IFX2	Off
C#7	1	ROM Mono,347:88-Rimshot	IFX3	Off
D7	1	ROM Mono,345:88-SD 1 (New)	IFX1	Off
D#7	1	EXs14 Mono,443:Clap-88 2-EXs14	IFX3	Off
E7	1	EXs14 Mono,277:SD-KPR55 3-EXs14	IFX1	Off
F7	1	EXs14 Mono,45:SD-Electro 02-EXs14	IFX5	Off
F#7	1	EXs14 Mono,287:HH-Closed-KPR77-EXs14	IFX4	3
G7	1	ROM Mono,1119:Voice 05	IFX5	Off
G#7	1	EXs14 Mono,288:HH-Open-KPR77-EXs14	IFX4	3
A7	1	ROM Mono,1208:PC Voice 1-05	IFX5	Off
A#7	1	EXs14 Mono,289:Ride-KPR77-EXs14	IFX4	3
B7	1	ROM Mono,1199:Vocoder Voice 20	IFX3	Off
C8	1	ROM Mono,1107:Industry Hit 22	IFX5	Off
C#8	1	ROM Mono,1093:Hammer	IFX3	Off
D8	1	ROM Mono,1098:PianoHit	IFX3	Off
D#8	1	ROM Mono,1094:Industry Hit 11	IFX3	Off
E8	1	ROM Mono,1100:Industry Hit 15	IFX5	Off

U-G04: Trap Kit

Key	Zone	Drumsample	Bus	Ex
E0	1	ROM Mono,498:Hi-Hat WS-Closed a	IFX4	4
F0	1	ROM Mono,499:Hi-Hat WS-Closed b	IFX4	4
F#0	1	ROM Mono,500:Hi-Hat WS-HalfOpen	IFX4	4
G0	1	ROM Mono,573:Finger Snap	IFX5	Off
G#0	1	ROM Mono,581:Hand Claps 2-g	IFX5	Off
A0	1	EXs14 Mono,141:Clap-HipHop 3-EXs14	IFX5	Off
A#0	1	EXs14 Mono,431:BD-88-Trap 1-EXs14	IFX2	6
B0	1	EXs14 Mono,62:SD-Electro 19-EXs14	IFX5	Off
C1	1	EXs14 Mono,34:BD-HipHop 1-EXs14	IFX2	Off
C#1	1	EXs14 Mono,10:BD-Electro 11-EXs14	IFX2	Off
D1	1	EXs14 Mono,38:BD-HipHop 5-EXs14	IFX2	Off
D#1	1	EXs14 Mono,3:BD-Electro 04-EXs14	IFX2	Off
E1	1	EXs14 Mono,36:BD-HipHop 3-EXs14	IFX2	Off
F1	1	EXs14 Mono,278:SD-KPR55 4-EXs14	IFX1	Off
F#1	1	EXs14 Mono,111:SD-Funk 17-EXs14	IFX1	Off
G1	1	EXs14 Mono,112:SD-Funk 18-EXs14	IFX1	Off
G#1	1	EXs14 Stereo,3:SD-Electro 25-EXs14-L	IFX1	Off
A1	1	EXs14 Mono,108:SD-Funk 14-EXs14	IFX1	Off
A#1	1	ROM Mono,538:88-Crash	IFX4	Off
B1	1	ROM Mono,10:BD-05-amb f	IFX2	Off
C2	1	EXs14 Mono,433:BD-88-Trap 3-EXs14	IFX2	Off
C#2	1	EXs14 Mono,433:BD-88-Trap 3-EXs14	IFX2	Off
D2	1	EXs14 Mono,433:BD-88-Trap 3-EXs14	IFX2	Off
D#2	1	EXs14 Mono,431:BD-88-Trap 1-EXs14	IFX2	Off
E2	1	EXs14 Mono,430:BD-88-Electro 4-EXs14	IFX2	Off
F2	1	EXs14 Mono,438:SD-88-Trap 5-EXs14	IFX1	Off
F#2	1	EXs14 Mono,100:SD-Funk 06-EXs14	IFX1	Off
G2	1	EXs14 Mono,439:SD-88-Trap 6-EXs14	IFX1	Off
G#2	1	EXs14 Mono,113:SD-HipHop 1-EXs14	IFX1	Off
A2	1	ROM Mono,345:88:SD 1 (New)	IFX1	Off
A#2	1	EXs14 Mono,383:SD-DDD5 1-EXs14	IFX1	Off
B2	1	EXs14 Mono,432:BD-88-Trap 2-EXs14	IFX2	Off
C3	1	EXs14 Mono,431:BD-88-Trap 1-EXs14	IFX2	Off
C#3	1	ROM Mono,347:88-Rimshot	IFX1	Off
D3	1	EXs14 Mono,441:SD-88-Trap 8-EXs14	IFX1	Off
D#3	1	EXs14 Mono,442:Clap-88 1-EXs14	IFX5	Off
E3	1	EXs14 Mono,436:SD-88-Trap 3-EXs14	IFX1	Off
F3	1	ROM Mono,1012:88-Tom	IFX3	Off
F#3	1	ROM Mono,511:88-HHat Closed	IFX4	2
G3	1	ROM Mono,1012:88-Tom	IFX3	Off
G#3	1	ROM Mono,511:88-HHat Closed	IFX4	2
A3	1	ROM Mono,1012:88-Tom	IFX3	Off
A#3	1	ROM Mono,512:88-HHat Open	IFX4	2
B3	1	EXs14 Mono,286:Tom-KPR77 2-EXs14	IFX3	Off
C4	1	EXs14 Mono,286:Tom-KPR77 2-EXs14	IFX3	Off
C#4	1	ROM Mono,538:88-Crash	IFX4	Off
D4	1	EXs14 Mono,286:Tom-KPR77 2-EXs14	IFX3	Off
D#4	1	ROM Mono,560:Ride Dance 2	IFX4	Off
E4	1	ROM Mono,537:Crash-Dance 99	IFX4	Off
F4	1	ROM Mono,561:Ride-Dance 99	IFX4	Off
F#4	1	EXs14 Mono,448:HiHat-Cl-88 2-Trap-EXs14	IFX4	1
G4	1	ROM Mono,564:China Cymbal 02	IFX4	Off
G#4	1	EXs14 Mono,447:HiHat-Cl-88 1-Trap-EXs14	IFX4	1
A4	1	EXs14 Mono,391:Crash-DDD5-EXs14	IFX5	Off
A#4	1	EXs14 Mono,449:HiHat-Open-88-Trap-EXs14	IFX4	1
B4	1	EXs14 Mono,392:Ride-DDD5-EXs14	IFX5	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	ROM Mono,1013:88-Conga	IFX3	Off
C#5	1	ROM Mono,1015:88-Cowbell	IFX3	Off
D5	1	ROM Mono,1013:88-Conga	IFX3	Off
D#5	1	ROM Mono,1016:88-Maraca	IFX3	Off
E5	1	ROM Mono,347:88-Rimshot	IFX3	Off
F5	1	EXs14 Mono,450:Tublar-Trap-EXs14	L/R	Off
F#5	1	ROM Mono,912:Timpani ff	L/R	Off
G5	1	ROM Mono,1055:Vinyl Hit 2	IFX5	Off
G#5	1	ROM Mono,974:Perc-Dance 01	IFX3	Off
A5	1	ROM Mono,1048:Synth Hit Loop 5	IFX5	Off
A#5	1	ROM Mono,995:Perc-Dance 03-Open	IFX3	Off
B5	1	ROM Mono,1048:Synth Hit Loop 5	IFX5	Off
C6	1	ROM Mono,1024:Orch Hit 2	IFX5	Off
C#6	1	ROM Mono,593:Conga Lo-Heel	IFX3	Off
D6	1	ROM Mono,1025:Orch Hit 3	IFX5	Off
D#6	1	ROM Mono,617:Quinto-Toe	IFX3	Off
E6	1	ROM Mono,1032:Band Hit 2	IFX5	Off
F6	1	ROM Mono,1057:DJ Vinyl Sliced 02	IFX3	Off
F#6	1	ROM Mono,629:Bongo 1 Lo-Slap	IFX5	Off
G6	1	ROM Mono,1131:Voice 17	IFX3	Off
G#6	1	ROM Mono,1117:Voice 03	IFX3	Off
A6	1	ROM Mono,1157:Voice 43 "Go"	IFX3	Off
A#6	1	ROM Mono,1149:Voice 35 "Aow"	IFX3	Off
B6	1	ROM Mono,1125:Voice 11	IFX3	Off
C7	1	ROM Mono,0:BD-01-amb f	IFX2	Off
C#7	1	ROM Mono,242:Sidestick 1 f	IFX1	Off
D7	1	ROM Mono,1027:Orch Hit 5	IFX1	Off
D#7	1	ROM Mono,581:Hand Claps 2-g	IFX5	Off
E7	1	ROM Mono,167:SD-13-dry mp	IFX1	Off
F7	1	EXs14 Mono,246:Scratch 1-EXs14	IFX3	Off
F#7	1	EXs14 Mono,448:HiHat-Cl-88 2-Trap-EXs14	IFX4	3
G7	1	EXs14 Mono,247:Scratch 2-EXs14	IFX3	Off
G#7	1	EXs14 Mono,447:HiHat-Cl-88 1-Trap-EXs14	IFX4	3
A7	1	ROM Mono,1063:DJ Vinyl Sliced 08	IFX3	Off
A#7	1	EXs14 Mono,449:HiHat-Open-88-Trap-EXs14	IFX4	3
B7	1	ROM Mono,1056:DJ Vinyl Sliced 01	IFX3	Off
C8	1	EXs14 Mono,8:BD-Electro 09-EXs14	IFX3	Off
C#8	1	EXs14 Stereo,8:Clap-Dance 3-EXs14-L	IFX3	Off
D8	1	EXs14 Mono,48:SD-Electro 05-EXs14	IFX3	Off
D#8	1	EXs14 Mono,126:Clap-Electro 01-EXs14	IFX5	Off
E8	1	EXs14 Mono,203:Synth Hit 19-EXs14	IFX5	Off

U-G05: R&B / Funk Kit

Key	Zone	Drumsample	Bus	Ex
E0	1	ROM Mono,1280:Vox-Wah Gtr 3	IFX4	Off
F0	1	EXs14 Mono,174:Hi Hat-Funk 05-EXs14	IFX4	7
F#0	1	EXs14 Mono,87:SD-Breaks 14-EXs14	IFX1	Off
G0	1	EXs14 Mono,177:Hi Hat-Funk 08-Op-EXs14	IFX5	7
G#0	1	EXs14 Mono,86:SD-Breaks 13-EXs14	IFX1	Off
A0	1	EXs14 Mono,22:BD-Breaks 4-EXs14	IFX2	Off
A#0	1	ROM Mono,581:Hand Claps 2-g	IFX5	Off
B0	1	ROM Mono,576:Hand Claps 2-b	IFX5	Off
C1	1	EXs14 Mono,30:BD-Funk 6-EXs14	IFX2	Off
C#1	1	EXs14 Mono,11:BD-Electro 12-EXs14	IFX2	Off
D1	1	EXs14 Mono,12:BD-Electro 13-EXs14	IFX2	Off
D#1	1	EXs14 Mono,380:BD-DDD5 1-EXs14	IFX2	Off
E1	1	EXs14 Mono,34:BD-HipHop 1-EXs14	IFX2	Off
F1	1	EXs14 Mono,61:SD-Electro 18-EXs14	IFX1	Off
F#1	1	EXs14 Mono,108:SD-Funk 14-EXs14	IFX1	Off
G1	1	EXs14 Mono,107:SD-Funk 13-EXs14	IFX1	Off
G#1	1	EXs14 Mono,106:SD-Funk 12-EXs14	IFX1	Off
A1	1	EXs14 Mono,105:SD-Funk 11-EXs14	IFX1	Off
A#1	1	ROM Mono,537:Crash-Dance 99	IFX4	Off
B1	1	ROM Mono,8:BD-05-amb mp	IFX2	Off
C2	1	EXs14 Mono,31:BD-Funk 7-EXs14	IFX2	Off
C#2	1	EXs14 Mono,30:BD-Funk 6-EXs14	IFX2	Off
D2	1	EXs14 Mono,29:BD-Funk 5-EXs14	IFX2	Off
D#2	1	EXs14 Mono,28:BD-Funk 4-EXs14	IFX2	Off
E2	1	EXs14 Mono,25:BD-Funk 1-EXs14	IFX2	Off
F2	1	EXs14 Mono,103:SD-Funk 09-EXs14	IFX1	Off
F#2	1	EXs14 Mono,109:SD-Funk 15-EXs14	IFX1	Off
G2	1	EXs14 Mono,99:SD-Funk 05-EXs14	IFX1	Off
G#2	1	EXs14 Mono,101:SD-Funk 07-EXs14	IFX1	Off
A2	1	EXs14 Mono,97:SD-Funk 03-EXs14	IFX1	Off
A#2	1	EXs14 Mono,98:SD-Funk 04-EXs14	IFX1	Off
B2	1	EXs14 Mono,26:BD-Funk 2-EXs14	IFX2	Off
C3	1	EXs14 Mono,27:BD-Funk 3-EXs14	IFX2	Off
C#3	1	EXs14 Mono,396:Stick-DDD5 2-EXs14	IFX1	Off
D3	1	EXs14 Mono,95:SD-Funk 01-EXs14	IFX1	Off
D#3	1	ROM Mono,574:Hand Claps 1	IFX5	Off
E3	1	EXs14 Mono,96:SD-Funk 02-EXs14	IFX1	Off
F3	1	EXs14 Mono,387:Tom-DDD5 2-EXs14	IFX3	Off
F#3	1	EXs14 Mono,170:Hi Hat-Funk 01-EXs14	IFX4	1
G3	1	EXs14 Mono,387:Tom-DDD5 2-EXs14	IFX3	Off
G#3	1	EXs14 Mono,171:Hi Hat-Funk 02-EXs14	IFX4	1
A3	1	EXs14 Mono,387:Tom-DDD5 2-EXs14	IFX3	Off
A#3	1	EXs14 Mono,173:Hi Hat-Funk 04-Op-EXs14	IFX4	1
B3	1	ROM Mono,366:Tom Vintage Lo ff	IFX3	Off
C4	1	ROM Mono,370:Tom Vintage Mid ff	IFX3	Off
C#4	1	ROM Mono,517:Crash Cymbal 01 ff	IFX4	Off
D4	1	ROM Mono,374:Tom Vintage Hi ff	IFX3	Off
D#4	1	ROM Mono,543:Ride Cymbal 01 f	IFX4	Off
E4	1	ROM Mono,529:Crash Cymbal 08 mf	IFX4	Off
F4	1	ROM Mono,549:Ride Cymbal 03 ff	IFX4	Off
F#4	1	EXs14 Mono,444:HH-Cl-88-Electro 1-EXs14	IFX4	2
G4	1	ROM Mono,571:Splash Cymbal 02 ff	IFX4	Off
G#4	1	EXs14 Mono,445:HH-Cl-88-Electro 2-EXs14	IFX4	2
A4	1	ROM Mono,522:Crash Cymbal 05 f	IFX4	Off
A#4	1	EXs14 Mono,446:HH-Open-88-Electro-EXs14	IFX4	2
B4	1	ROM Mono,554:Ride Cymbal 05 f	IFX4	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	ROM Mono,586:Conga Lo-Open f	IFX3	Off
C#5	1	ROM Mono,625:Bongo 1 Lo-StickEdge f	IFX3	Off
D5	1	ROM Mono,598:Conga Hi-Open f	IFX3	Off
D#5	1	ROM Mono,632:Bongo 1 Hi-Pops	IFX3	Off
E5	1	ROM Mono,601:Conga Hi-OpenSlap	IFX3	Off
F5	1	ROM Mono,750:Tambourine 2-Accent	IFX3	Off
F#5	1	ROM Mono,792:Shaker 2 b-Push	IFX3	Off
G5	1	ROM Mono,746:Tambourine 1-Accent	IFX3	Off
G#5	1	ROM Mono,793:Shaker 2 b-Pull	IFX3	Off
A5	1	ROM Mono,718:Maracas 2-Push a	IFX3	Off
A#5	1	ROM Mono,795:Shaker 2 d-Push	IFX3	Off
B5	1	ROM Mono,721:Maracas 2-Pull b	IFX3	Off
C6	1	ROM Mono,781:Shaker 1-Pull a	IFX3	Off
C#6	1	ROM Mono,586:Conga Lo-Open f	IFX3	Off
D6	1	ROM Mono,602:Conga Hi-OpenSlapFlam	IFX3	Off
D#6	1	ROM Mono,597:Conga Hi-Open mf	IFX3	Off
E6	1	ROM Mono,605:Conga Hi-Closed	IFX3	Off
F6	1	EXs14 Mono,340:JingleBell-DDD1 1-EXs14	IFX3	Off
F#6	1	EXs14 Mono,194:Synth Hit 10-EXs14	IFX3	Off
G6	1	EXs14 Mono,341:JingleBell-DDD1 2-EXs14	IFX3	Off
G#6	1	ROM Mono,1241:Fireworks	IFX5	Off
A6	1	ROM Mono,759:Tri.& Tamb. i	IFX3	Off
A#6	1	EXs14 Stereo,23:Record Noise 1-EXs14-L	IFX5	Off
B6	1	EXs14 Mono,116:SD-HipHop 4-EXs14	IFX3	Off
C7	1	EXs14 Mono,19:BD-Breaks 1-EXs14	IFX2	Off
C#7	1	EXs14 Stereo,24:Record Noise 2-EXs14-L	IFX3	Off
D7	1	EXs14 Mono,88:SD-Breaks 15-EXs14	IFX1	Off
D#7	1	EXs14 Mono,77:SD-Breaks 04-EXs14	IFX1	Off
E7	1	EXs14 Mono,114:SD-HipHop 2-EXs14	IFX1	Off
F7	1	EXs14 Mono,181:Hi Hat-Funk 12-EXs14	IFX4	Off
F#7	1	EXs14 Mono,163:Hi Hat-Electro 12-EXs14	IFX5	Off
G7	1	EXs14 Mono,182:Hi Hat-Funk 13-EXs14	IFX5	Off
G#7	1	EXs14 Mono,157:Hi Hat-Electro 06-EXs14	IFX5	Off
A7	1	EXs14 Mono,183:Hi Hat-Funk 14-EXs14	IFX5	Off
A#7	1	EXs14 Stereo,13:Hi Hat-Electro 16-EXs14-L	IFX5	Off
B7	1	EXs14 Mono,184:Hi Hat-HipHop-Open-EXs14	IFX5	Off
C8	1	EXs14 Mono,98:SD-Funk 04-EXs14	IFX1	Off
C#8	1	ROM Mono,476:Hi-Hat Dance 11	IFX3	Off
D8	1	EXs14 Stereo,0:BD-Electro 17-EXs14-L	IFX1	Off
D#8	1	EXs14 Mono,233:Dance Hit 3-EXs14-R	IFX5	Off
E8	1	EXs14 Mono,82:SD-Breaks 09-EXs14	IFX1	Off

U-G06: D&B Breaks Kit

Key	Zone	Drumsample	Bus	Ex
E0	1	EXs14 Mono,170:Hi Hat-Funk 01-EXs14	IFX4	4
F0	1	EXs14 Mono,171:Hi Hat-Funk 02-EXs14	IFX4	4
F#0	1	ROM Mono,124:Fireworks	IFX5	Off
G0	1	EXs14 Mono,442:Clap-88 1-EXs14	IFX5	Off
G#0	1	EXs14 Stereo,3:SD-Electro 25-EXs14-L	IFX3	Off
A0	1	EXs14 Mono,68:SD-Electro 25-EXs14-L	IFX2	Off
A#0	1	EXs14 Mono,225:Drum Hit 22-EXs14	IFX3	10
B0	1	EXs14 Mono,47:SD-Electro 04-EXs14	IFX3	Off
C1	1	EXs14 Mono,15:BD-Electro 16-EXs14	IFX2	Off
C#1	1	EXs14 Mono,37:BD-HipHop 4-EXs14	IFX2	Off
D1	1	EXs14 Mono,34:BD-HipHop 1-EXs14	IFX2	Off
D#1	1	EXs14 Mono,9:BD-Electro 10-EXs14	IFX2	Off
E1	1	EXs14 Mono,1:BD-Electro 02-EXs14	IFX2	Off
F1	1	EXs14 Mono,60:SD-Electro 17-EXs14	IFX1	Off
F#1	1	EXs14 Mono,65:SD-Electro 22-EXs14	IFX1	Off
G1	1	EXs14 Mono,111:SD-Funk 17-EXs14	IFX1	Off
G#1	1	EXs14 Mono,84:SD-Breaks 11-EXs14	IFX1	Off
A1	1	EXs14 Mono,51:SD-Electro 08-EXs14	IFX1	Off
A#1	1	ROM Mono,537:Crash-Dance 99	IFX4	Off
B1	1	ROM Mono,0:BD-01-amb f	IFX2	Off
C2	1	EXs14 Mono,432:BD-88-Trap 2-EXs14	IFX2	Off
C#2	1	EXs14 Mono,11:BD-Electro 12-EXs14	IFX2	Off
D2	1	EXs14 Mono,19:BD-Breaks 1-EXs14	IFX2	Off
D#2	1	EXs14 Mono,0:BD-Electro 01-EXs14	IFX2	Off
E2	1	EXs14 Mono,34:BD-HipHop 1-EXs14	IFX2	Off
F2	1	EXs14 Mono,109:SD-Funk 15-EXs14	IFX1	Off
F#2	1	EXs14 Mono,114:SD-HipHop 2-EXs14	IFX1	Off
G2	1	EXs14 Mono,74:SD-Breaks 01-EXs14	IFX1	Off
G#2	1	EXs14 Mono,90:SD-Breaks 17-EXs14	IFX1	Off
A2	1	EXs14 Mono,107:SD-Funk 13-EXs14	IFX1	Off
A#2	1	EXs14 Mono,421:SD-77 2-EXs14	IFX1	Off
B2	1	EXs14 Mono,457:BD-99-Electro 5-EXs14	IFX2	Off
C3	1	EXs14 Mono,33:BD-Funk 9-EXs14	IFX2	Off
C#3	1	EXs14 Mono,393:Rim-DDD5 1-EXs14	IFX1	Off
D3	1	EXs14 Mono,420:SD-77 1-EXs14	IFX1	Off
D#3	1	EXs14 Mono,127:Clap-Electro 02-EXs14	IFX5	Off
E3	1	EXs14 Mono,87:SD-Breaks 14-EXs14	IFX1	Off
F3	1	EXs14 Stereo,11:Tom-Processed-EXs14-L	IFX3	Off
F#3	1	EXs14 Mono,182:Hi Hat-Funk 13-EXs14	IFX4	1
G3	1	EXs14 Stereo,11:Tom-Processed-EXs14-L	IFX3	Off
G#3	1	EXs14 Mono,182:Hi Hat-Funk 13-EXs14	IFX4	1
A3	1	EXs14 Stereo,11:Tom-Processed-EXs14-L	IFX3	Off
A#3	1	ROM Mono,481:Hi-Hat Dance 16	IFX3	1
B3	1	EXs14 Mono,146:Tom-Breaks 2-EXs14	IFX3	Off
C4	1	EXs14 Mono,146:Tom-Breaks 2-EXs14	IFX3	Off
C#4	1	EXs14 Mono,391:Crash-DDD5-EXs14	IFX4	Off
D4	1	EXs14 Mono,146:Tom-Breaks 2-EXs14	IFX3	Off
D#4	1	EXs14 Mono,392:Ride-DDD5-EXs14	IFX5	Off
E4	1	EXs14 Mono,481:Ride-99 1-EXs14	IFX5	Off
F4	1	ROM Mono,561:Ride-Dance 99	IFX5	Off
F#4	1	EXs14 Mono,178:Hi Hat-Funk 09-EXs14	IFX4	2
G4	1	ROM Mono,565:Broken Hi-Hat	IFX4	Off
G#4	1	EXs14 Mono,179:Hi Hat-Funk 10-EXs14	IFX4	2
A4	1	ROM Mono,536:Crash Dance 2	IFX5	Off
A#4	1	EXs14 Mono,180:Hi Hat-Funk 11-Op-EXs14	IFX4	2
B4	1	EXs14 Mono,481:Ride-99 1-EXs14	IFX4	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	EXs14 Mono,107:SD-Funk 13-EXs14	IFX5	Off
C#5	1	EXs14 Mono,431:BD-88-Trap 1-EXs14	IFX5	Off
D5	1	EXs14 Stereo,4:SD-Electro 26-EXs14-L	IFX1	Off
D#5	1	EXs14 Mono,111:SD-Funk 17-EXs14	IFX1	Off
E5	1	EXs14 Mono,110:SD-Funk 16-EXs14	IFX1	Off
F5	1	EXs14 Mono,448:HiHat-Cl-88 2-Trap-EXs14	IFX3	Off
F#5	1	EXs14 Mono,184:Hi Hat-HipHop-Open-EXs14	IFX3	Off
G5	1	EXs14 Mono,435:SD-88-Trap 2-EXs14	IFX1	Off
G#5	1	EXs14 Mono,164:Hi Hat-Electro 13-EXs14	IFX4	Off
A5	1	EXs14 Stereo,23:Record Noise 1-EXs14-L	IFX3	Off
A#5	1	EXs14 Mono,355:Shaker-DDD1 2-EXs14	IFX3	Off
B5	1	EXs14 Mono,358:Tambourine-DDD1 1-EXs14	IFX3	Off
C6	1	EXs14 Stereo,24:Record Noise 2-EXs14-L	IFX3	Off
C#6	1	EXs14 Mono,107:SD-Funk 13-EXs14	IFX1	Off
D6	1	EXs14 Mono,251:Record Noise 2-EXs14-R	IFX3	Off
D#6	1	EXs14 Mono,20:BD-Breaks 2-EXs14	IFX5	Off
E6	1	ROM Mono,321:SD-Dance 74	IFX2	Off
F6	1	EXs14 Stereo,10:Clap-Electro 12-EXs14-L	IFX5	Off
F#6	1	EXs14 Mono,302:Bongo-DDD1 11-EXs14	IFX3	Off
G6	1	EXs14 Mono,150:Tom-Breaks 6-EXs14	IFX5	Off
G#6	1	EXs14 Mono,303:Bongo-DDD1 12-EXs14	IFX3	Off
A6	1	EXs14 Mono,150:Tom-Breaks 6-EXs14	IFX5	Off
A#6	1	EXs14 Mono,304:Bongo-DDD1 13-EXs14	IFX5	Off
B6	1	EXs14 Stereo,10:Clap-Electro 12-EXs14-L	IFX3	Off
C7	1	EXs14 Mono,458:BD-99-Electro 6-EXs14	IFX2	Off
C#7	1	EXs14 Mono,394:Rim-DDD5 2-EXs14	IFX1	Off
D7	1	ROM Mono,344:99-SD 2	IFX1	Off
D#7	1	EXs14 Mono,128:Clap-Electro 03-EXs14	IFX3	Off
E7	1	EXs14 Mono,0:BD-Electro 01-EXs14	IFX1	Off
F7	1	EXs14 Mono,47:SD-Electro 04-EXs14	IFX4	Off
F#7	1	EXs14 Mono,183:Hi Hat-Funk 14-EXs14	IFX4	Off
G7	1	EXs14 Mono,16:BD-Electro 17-EXs14	IFX3	Off
G#7	1	EXs14 Mono,161:Hi Hat-Electro 10-EXs14	IFX4	Off
A7	1	EXs14 Mono,48:SD-Electro 05-EXs14	IFX1	Off
A#7	1	ROM Mono,119:Vocoder Voice 17	IFX4	Off
B7	1	EXs14 Mono,80:SD-Breaks 07-EXs14	IFX1	Off
C8	1	EXs14 Mono,82:SD-Breaks 09-EXs14	IFX5	Off
C#8	1	ROM Mono,339:SD-WS 08 (Noise)	IFX5	Off
D8	1	EXs14 Mono,47:SD-Electro 04-EXs14	IFX1	Off
D#8	1	EXs14 Mono,46:SD-Electro 03-EXs14	IFX3	Off
E8	1	ROM Mono,1204:PC Voice 1-01 "Two"	IFX3	Off

U-G07: Chill / Down Tempo Kit

Key	Zone	Drumsample	Bus	Ex
E0	1	ROM Mono,414:Hi-Hat Basic 1-Closed mp	IFX4	4
F0	1	ROM Mono,418:Hi-Hat Basic 1-Pedal mp	IFX4	4
F#0	1	ROM Mono,422:Hi-Hat Basic 1-Open mf	IFX4	4
G0	1	ROM Mono,509:99:HHat Closed	IFX4	Off
G#0	1	EXs14 Stereo,23:Record Noise 1-EXs14-L	IFX3	Off
A0	1	EXs14 Mono,249:Record Noise 1-EXs14-R	IFX3	Off
A#0	1	EXs14 Stereo,24:Record Noise 2-EXs14-L	IFX3	Off
B0	1	EXs14 Mono,251:Record Noise 2-EXs14-R	IFX3	Off
C1	1	EXs14 Mono,274:BD-KPR55 2-EXs14	IFX2	Off
C#1	1	EXs14 Mono,11:BD-Electro 12-EXs14	IFX2	Off
D1	1	EXs14 Mono,29:BD-Funk 5-EXs14	IFX2	Off
D#1	1	EXs14 Mono,429:BD-88-Electro 3-EXs14	IFX2	6
E1	1	EXs14 Mono,430:BD-88-Electro 4-EXs14	IFX2	6
F1	1	EXs14 Mono,441:SD-88-Trap 8-EXs14	IFX1	Off
F#1	1	EXs14 Mono,116:SD-HipHop 4-EXs14	IFX1	Off
G1	1	EXs14 Mono,116:SD-HipHop 4-EXs14	IFX1	Off
G#1	1	EXs14 Mono,96:SD-Funk 02-EXs14	IFX1	Off
A1	1	EXs14 Mono,283:SD-KPR77-EXs14	IFX1	Off
A#1	1	ROM Mono,535:Crash Dance 1	IFX4	Off
B1	1	ROM Mono,25:BD-09-dry mf	IFX2	Off
C2	1	EXs14 Mono,429:BD-88-Electro 3-EXs14	IFX2	Off
C#2	1	EXs14 Mono,31:BD-Funk 7-EXs14	IFX2	Off
D2	1	EXs14 Mono,28:BD-Funk 4-EXs14	IFX2	Off
D#2	1	EXs14 Mono,34:BD-HipHop 1-EXs14	IFX2	Off
E2	1	EXs14 Mono,12:BD-Electro 13-EXs14	IFX2	Off
F2	1	EXs14 Mono,107:SD-Funk 13-EXs14	IFX1	Off
F#2	1	EXs14 Mono,103:SD-Funk 09-EXs14	IFX1	Off
G2	1	EXs14 Mono,114:SD-HipHop 2-EXs14	IFX1	Off
G#2	1	EXs14 Mono,100:SD-Funk 06-EXs14	IFX1	Off
A2	1	EXs14 Mono,111:SD-Funk 17-EXs14	IFX1	Off
A#2	1	EXs14 Mono,98:SD-Funk 04-EXs14	IFX1	Off
B2	1	EXs14 Mono,12:BD-Electro 13-EXs14	IFX2	Off
C3	1	EXs14 Mono,428:BD-88-Electro 2-EXs14	IFX2	Off
C#3	1	EXs14 Mono,396:Stick-DDDS 2-EXs14	IFX1	Off
D3	1	EXs14 Mono,99:SD-Funk 05-EXs14	IFX1	Off
D#3	1	EXs14 Mono,132:Clap-Electro 07-EXs14	IFX5	Off
E3	1	EXs14 Mono,283:SD-KPR77-EXs14	IFX1	Off
F3	1	ROM Mono,350:Tom Basic Lo f	IFX3	Off
F#3	1	EXs14 Mono,171:Hi Hat-Funk 02-EXs14	IFX4	1
G3	1	ROM Mono,356:Tom Basic MidHi f	IFX3	Off
G#3	1	EXs14 Mono,172:Hi Hat-Funk 03-EXs14	IFX4	1
A3	1	ROM Mono,360:Tom Basic Hi f	IFX3	Off
A#3	1	EXs14 Mono,173:Hi Hat-Funk 04-Op-EXs14	IFX4	1
B3	1	EXs14 Mono,286:Tom-KPR77 2-EXs14	IFX3	Off
C4	1	EXs14 Mono,286:Tom-KPR77 2-EXs14	IFX3	Off
C#4	1	ROM Mono,515:Crash Cymbal 01 mf	IFX4	Off
D4	1	EXs14 Mono,286:Tom-KPR77 2-EXs14	IFX3	Off
D#4	1	ROM Mono,541:Ride Cymbal 01 mp	IFX4	Off
E4	1	ROM Mono,520:Crash Cymbal 05 mp	IFX4	Off
F4	1	ROM Mono,546:Ride Cymbal 03 mp	IFX4	Off
F#4	1	ROM Mono,511:88:HHat Closed	IFX3	2
G4	1	ROM Mono,566:Splash Cymbal 01 mp	IFX4	Off
G#4	1	ROM Mono,512:88:HHat Open	IFX3	2
A4	1	ROM Mono,524:Crash Cymbal 06 mp	IFX4	Off
A#4	1	ROM Mono,512:88:HHat Open	IFX3	2
B4	1	ROM Mono,550:Ride Cymbal 04 mp	IFX4	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	ROM Mono,618:Bongo 1 Lo-Muffled mp	IFX3	Off
C#5	1	ROM Mono,573:Finger Snap	IFX3	Off
D5	1	ROM Mono,631:Bongo 1 Hi-Open f	IFX3	Off
D#5	1	ROM Mono,578:Hand Claps 2-d	IFX3	Off
E5	1	ROM Mono,633:Bongo 1 Hi-Hightone	IFX3	Off
F5	1	ROM Mono,732:Pandeiro-Jingle b	IFX3	Off
F#5	1	ROM Mono,918:Finger Cymbal	IFX5	Off
G5	1	ROM Mono,733:Pandeiro-Open a	IFX3	Off
G#5	1	ROM Mono,921:Bell Tree-Slow	IFX3	Off
A5	1	ROM Mono,891:Bayo-UpDown a	IFX3	Off
A#5	1	ROM Mono,926:Rainstick 2	IFX5	Off
B5	1	ROM Mono,889:Bayo-Ge	IFX3	Off
C6	1	ROM Mono,751:Tri.& Tamb. a	IFX3	Off
C#6	1	ROM Mono,729:Surdo-Open	IFX3	Off
D6	1	ROM Mono,758:Tri. & Tamb. h	IFX3	Off
D#6	1	ROM Mono,730:Surdo-Mute	IFX3	Off
E6	1	ROM Mono,753:Tri.& Tamb. c	IFX3	Off
F6	1	ROM Mono,799:Shaker 3-Push	IFX3	Off
F#6	1	ROM Mono,1265:Meditation Tree	IFX3	Off
G6	1	ROM Mono,780:Shaker 1-Push b	IFX3	Off
G#6	1	ROM Mono,1260:Noise 2	IFX5	Off
A6	1	ROM Mono,719:Maracas 2-Push b	IFX3	Off
A#6	1	ROM Mono,1261:Cricket Spectrum	IFX5	Off
B6	1	ROM Mono,720:Maracas 2-Pull a	IFX3	Off
C7	1	EXs14 Mono,181:Hi Hat-Funk 12-EXs14	IFX4	Off
C#7	1	EXs14 Mono,184:Hi Hat-HipHop-Open-EXs14	IFX4	Off
D7	1	EXs14 Mono,182:Hi Hat-Funk 13-EXs14	IFX4	Off
D#7	1	EXs14 Mono,174:Hi Hat-Funk 05-EXs14	IFX3	Off
E7	1	EXs14 Mono,183:Hi Hat-Funk 14-EXs14	IFX4	Off
F7	1	EXs14 Mono,157:Hi Hat-Electro 06-EXs14	IFX5	Off
F#7	1	ROM Mono,425:Hi-Hat Basic 2-Closed mp	IFX4	3
G7	1	EXs14 Mono,191:Synth Hit 07-EXs14	IFX3	Off
G#7	1	ROM Mono,426:Hi-Hat Basic 2-Closed mf	IFX4	3
A7	1	EXs14 Stereo,9:Clap-Dance 4-EXs14-L	IFX5	Off
A#7	1	ROM Mono,428:Hi-Hat Basic 2-Open mp	IFX4	3
B7	1	EXs14 Stereo,19:Dance Hit 6-EXs14-L	IFX3	Off
C8	1	EXs14 Mono,20:DB-Breaks 2-EXs14	IFX2	Off
C#8	1	ROM Mono,1373:HarpGliss	IFX5	Off
D8	1	EXs14 Mono,87:SD-Breaks 14-EXs14	IFX5	Off
D#8	1	ROM Mono,1100:Industry Hit 15	IFX5	Off
E8	1	EXs14 Mono,170:Hi Hat-Funk 01-EXs14	IFX4	Off

U-G08: Electronica Kit

Key	Zone	Drumsample	Bus	Ex
E0	1	EXs14 Mono,432:BD-88-Trap 2-EXs14	IFX2	5
F0	1	EXs14 Mono,432:BD-88-Trap 2-EXs14	IFX2	5
F#0	1	EXs14 Mono,442:Clap-88 1-EXs14	IFX3	4
G0	1	EXs14 Mono,432:BD-88-Trap 2-EXs14	IFX2	5
G#0	1	EXs14 Mono,557:Tom-Smns 5-EXs14	IFX3	Off
A0	1	EXs14 Mono,266:Acc-Donkama-DE20-EXs14	IFX2	Off
A#0	1	EXs14 Mono,432:BD-88-Trap 2-EXs14	IFX2	10
B0	1	EXs14 Mono,266:Acc-Donkama-DE20-EXs14	IFX5	Off
C1	1	EXs14 Mono,2:BD-Electro 03-EXs14	IFX2	Off
C#1	1	EXs14 Mono,9:BD-Electro 10-EXs14	IFX2	Off
D1	1	EXs14 Mono,511:BD-Ln-EXs14	IFX2	Off
D#1	1	EXs14 Mono,422:BD-88 1-EXs14	IFX2	Off
E1	1	EXs14 Mono,423:BD-88 2-EXs14	IFX2	Off
F1	1	EXs14 Mono,62:SD-Electro 19-EXs14	IFX1	Off
F#1	1	EXs14 Mono,64:SD-Electro 21-EXs14	IFX1	Off
G1	1	EXs14 Mono,52:SD-Electro 09-EXs14	IFX1	Off
G#1	1	EXs14 Mono,46:SD-Electro 03-EXs14	IFX1	Off
A1	1	EXs14 Mono,512:SD-Ln-EXs14	IFX1	Off
A#1	1	ROM Mono,537:Crash-Dance 99	IFX4	Off
B1	1	EXs14 Mono,2:BD-Electro 03-EXs14	IFX2	Off
C2	1	EXs14 Mono,451:BD-99 1-EXs14	IFX2	Off
C#2	1	EXs14 Mono,426:BD-88 5-EXs14	IFX2	Off
D2	1	EXs14 Mono,274:BD-KPR55 2-EXs14	IFX2	Off
D#2	1	EXs14 Mono,282:BD-KPR77-EXs14	IFX2	Off
E2	1	EXs14 Mono,424:BD-88 3-EXs14	IFX2	Off
F2	1	EXs14 Mono,64:SD-Electro 21-EXs14	IFX1	Off
F#2	1	EXs14 Mono,51:SD-Electro 08-EXs14	IFX1	Off
G2	1	EXs14 Mono,439:SD-88-Trap 6-EXs14	IFX1	Off
G#2	1	EXs14 Mono,82:SD-Breaks 09-EXs14	IFX1	Off
A2	1	EXs14 Mono,415:SD-66-EXs14	IFX1	Off
A#2	1	EXs14 Mono,66:SD-Electro 23-EXs14	IFX1	Off
B2	1	EXs14 Mono,0:BD-Electro 01-EXs14	IFX2	Off
C3	1	EXs14 Mono,452:BD-99 2-EXs14	IFX2	Off
C#3	1	EXs14 Mono,497:Sidestick-DrTr-EXs14	IFX1	Off
D3	1	EXs14 Mono,44:SD-Electro 01-EXs14	IFX1	Off
D#3	1	EXs14 Mono,127:Clap-Electro 02-EXs14	IFX5	Off
E3	1	EXs14 Mono,52:SD-Electro 09-EXs14	IFX1	Off
F3	1	EXs14 Mono,143:Tom-Processed-EXs14-L	IFX3	Off
F#3	1	EXs14 Mono,560:FX-Smns 2-EXs14	IFX5	1
G3	1	EXs14 Mono,143:Tom-Processed-EXs14-L	IFX3	Off
G#3	1	EXs14 Mono,164:Hi Hat-Electro 13-EXs14	IFX5	1
A3	1	EXs14 Mono,143:Tom-Processed-EXs14-L	IFX3	Off
A#3	1	EXs14 Mono,152:Hi Hat-Electro 01-EXs14	IFX5	1
B3	1	EXs14 Mono,279:Tom-KPR55-EXs14	IFX3	Off
C4	1	EXs14 Mono,279:Tom-KPR55-EXs14	IFX3	Off
C#4	1	EXs14 Mono,419:Cym-66-EXs14	IFX4	Off
D4	1	EXs14 Mono,279:Tom-KPR55-EXs14	IFX3	Off
D#4	1	EXs14 Mono,503:Ride-DrTr-EXs14	IFX5	Off
E4	1	EXs14 Mono,527:Crash-Ln-EXs14	IFX5	Off
F4	1	EXs14 Mono,482:Ride-99 2-EXs14	IFX5	Off
F#4	1	EXs14 Mono,164:Hi Hat-Electro 13-EXs14	IFX5	2
G4	1	EXs14 Mono,392:Ride-DDD5-EXs14	IFX5	Off
G#4	1	EXs14 Mono,183:Hi Hat-Funk 14-EXs14	IFX5	2
A4	1	EXs14 Mono,502:Crash-DrTr-EXs14	IFX5	Off
A#4	1	EXs14 Stereo,13:Hi Hat-Electro16-EXs14-L	IFX5	2
B4	1	EXs14 Mono,418:Hi Hat-Open-66-EXs14	IFX5	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	EXs14 Mono,532:Conga-Ln 5-EXs14	IFX3	Off
C#5	1	EXs14 Mono,529:Conga-Ln 2-EXs14	IFX3	Off
D5	1	EXs14 Mono,530:Conga-Ln 3-EXs14	IFX3	Off
D#5	1	EXs14 Mono,531:Conga-Ln 4-EXs14	IFX3	Off
E5	1	EXs14 Mono,528:Conga-Ln 1-EXs14	IFX3	Off
F5	1	EXs14 Mono,484:Hi Hat-Cl-99-comp2-EXs14	IFX4	Off
F#5	1	EXs14 Mono,417:Hi-Hat-Closed-66-EXs14	IFX4	Off
G5	1	EXs14 Mono,490:Hi Hat-Op-99-comp1-EXs14	IFX4	Off
G#5	1	EXs14 Mono,418:Hi-Hat-Open-66-EXs14	IFX3	Off
A5	1	EXs14 Mono,227:Drum Hit 24-EXs14	IFX3	Off
A#5	1	EXs14 Mono,418:Hi-Hat-Open-66-EXs14	IFX5	Off
B5	1	EXs14 Mono,204:Drum Hit 01-EXs14	IFX5	Off
C6	1	EXs14 Mono,259:LBongo-DonkamaDE11-EXs14	IFX3	Off
C#6	1	EXs14 Mono,261:Maraca-DonkamaDE11-EXs14	IFX3	Off
D6	1	EXs14 Mono,260:HBongo-DonkamaDE11-EXs14	IFX3	Off
D#6	1	EXs14 Mono,262:WBlock-DonkamaDE11-EXs14	IFX3	Off
E6	1	EXs14 Mono,271:Claves-DonkamaDE20-EXs14	IFX3	Off
F6	1	EXs14 Mono,267:LBongo-DonkamaDE20-EXs14	IFX3	Off
F#6	1	EXs14 Mono,264:SD-Donkama-DE20-EXs14	IFX3	Off
G6	1	EXs14 Mono,270:Maraca-DonkamaDE20-EXs14	IFX3	Off
G#6	1	EXs14 Mono,455:BD-99-Electro 3-EXs14	IFX3	Off
A6	1	EXs14 Mono,276:SD-KPR55 2-EXs14	IFX1	Off
A#6	1	EXs14 Mono,250:Record Noise 2-EXs14-L	IFX2	Off
B6	1	EXs14 Stereo,11:Tom-Processed-EXs14-L	IFX2	Off
C7	1	EXs14 Stereo,2:BD-Techno 2-EXs14-L	IFX2	Off
C#7	1	ROM Mono,1153:Voice 39 "Uuh"	IFX3	Off
D7	1	EXs14 Mono,420:SD-77 1-EXs14	IFX1	Off
D#7	1	EXs14 Mono,220:Drum Hit 17-EXs14	IFX3	Off
E7	1	EXs14 Mono,189:Synth Hit 05-EXs14	IFX3	Off
F7	1	EXs14 Mono,189:Synth Hit 05-EXs14	IFX5	Off
F#7	1	EXs14 Mono,154:Hi Hat-Electro 03-EXs14	IFX5	3
G7	1	EXs14 Mono,278:SD-KPR55 4-EXs14	IFX3	Off
G#7	1	EXs14 Mono,280:HH-Closed-KPR55-EXs14	IFX4	3
A7	1	EXs14 Mono,222:Drum Hit 19-EXs14	IFX3	Off
A#7	1	EXs14 Mono,289:Ride-KPR77-EXs14	IFX4	3
B7	1	EXs14 Mono,247:Scratch 2-EXs14	IFX3	Off
C8	1	EXs14 Mono,246:Scratch 1-EXs14	IFX3	Off
C#8	1	EXs14 Mono,328:Cowbell-DDD1 1-EXs14	IFX3	Off
D8	1	EXs14 Mono,258:Acc-Donkama-DE11-EXs14	IFX3	Off
D#8	1	EXs14 Mono,330:Cowbell-DDD1 3-EXs14	IFX3	Off
E8	1	EXs14 Mono,304:Bongo-DDD1 13-EXs14	IFX5	Off

U-G09: Vintage Machine Kit

Key	Zone	Drumsample	Bus	Ex
E0	1	EXs14 Mono,559:FX-Smns 1-EXs14	IFX3	Off
F0	1	EXs14 Mono,560:FX-Smns 2-EXs14	IFX3	Off
F#0	1	EXs14 Mono,561:FX-Smns 3-EXs14	IFX3	Off
G0	1	EXs14 Mono,562:FX-Smns 4-EXs14	IFX3	Off
G#0	1	EXs14 Mono,563:FX-Smns 5-EXs14	IFX3	Off
A0	1	EXs14 Mono,564:FX-Smns 6-EXs14	IFX3	Off
A#0	1	EXs14 Mono,565:FX-Smns 7-EXs14	IFX5	Off
B0	1	EXs14 Mono,566:FX-Smns 8-EXs14	IFX5	Off
C1	1	EXs14 Mono,535:BD-Smns 1-EXs14	IFX2	Off
C#1	1	EXs14 Mono,539:BD-Smns 2-EXs14	IFX2	Off
D1	1	EXs14 Mono,536:BD-Smns 2-EXs14	IFX2	Off
D#1	1	EXs14 Mono,537:BD-Smns 3-EXs14	IFX2	Off
E1	1	EXs14 Mono,538:BD-Smns 4-EXs14	IFX2	Off
F1	1	EXs14 Mono,543:SD-Smns 03-EXs14	IFX1	Off
F#1	1	EXs14 Mono,547:SD-Smns 07-EXs14	IFX1	Off
G1	1	EXs14 Mono,541:SD-Smns 01-EXs14	IFX1	Off
G#1	1	EXs14 Mono,546:SD-Smns 06-EXs14	IFX1	Off
A1	1	EXs14 Mono,545:SD-Smns 05-EXs14	IFX1	Off
A#1	1	ROM Mono,561:Ride-Dance 99	IFX4	Off
B1	1	ROM Mono,10:BD-05-amb f	IFX2	Off
C2	1	EXs14 Mono,423:BD-88 2-EXs14	IFX2	Off
C#2	1	EXs14 Mono,511:BD-Ln-EXs14	IFX2	Off
D2	1	EXs14 Mono,425:BD-88 4-EXs14	IFX2	Off
D#2	1	EXs14 Mono,414:BD-66 2-EXs14	IFX2	Off
E2	1	EXs14 Mono,451:BD-99 1-EXs14	IFX2	Off
F2	1	EXs14 Mono,496:SD-DrTr-EXs14	IFX1	Off
F#2	1	EXs14 Mono,512:SD-Ln-EXs14	IFX1	Off
G2	1	EXs14 Mono,440:SD-88-Trap 7-EXs14	IFX1	Off
G#2	1	EXs14 Mono,472:SD-99 12-EXs14	IFX1	Off
A2	1	EXs14 Mono,420:SD-77 1-EXs14	IFX1	Off
A#2	1	EXs14 Mono,415:SD-66-EXs14	IFX1	Off
B2	1	EXs14 Mono,495:BD-DrTr-EXs14	IFX2	Off
C3	1	EXs14 Mono,457:BD-99-Electro 5-EXs14	IFX2	Off
C#3	1	EXs14 Mono,513:Sidestick-Ln-EXs14	IFX1	Off
D3	1	EXs14 Mono,434:SD-88-Trap 1-EXs14	IFX1	Off
D#3	1	EXs14 Mono,514:Clap-Ln-EXs14	IFX1	Off
E3	1	EXs14 Mono,463:SD-99 03-EXs14	IFX1	Off
F3	1	EXs14 Mono,416:Tom-66-EXs14	IFX3	Off
F#3	1	EXs14 Mono,448:HiHat-Cl-88 2-Trap-EXs14	IFX4	1
G3	1	EXs14 Mono,416:Tom-66-EXs14	IFX3	Off
G#3	1	EXs14 Mono,447:HiHat-Cl-88 1-Trap-EXs14	IFX4	1
A3	1	EXs14 Mono,416:Tom-66-EXs14	IFX3	Off
A#3	1	EXs14 Mono,449:HiHat-Open-88-Trap-EXs14	IFX4	1
B3	1	EXs14 Mono,519:Tom-Ln 5-EXs14	IFX3	Off
C4	1	EXs14 Mono,519:Tom-Ln 5-EXs14	IFX3	Off
C#4	1	EXs14 Mono,419:Cym-66-EXs14	IFX4	Off
D4	1	EXs14 Mono,519:Tom-Ln 5-EXs14	IFX3	Off
D#4	1	EXs14 Mono,419:Cym-66-EXs14	IFX4	Off
E4	1	EXs14 Mono,527:Crash-Ln-EXs14	IFX4	Off
F4	1	EXs14 Mono,526:Ride-Ln-EXs14	IFX4	Off
F#4	1	EXs14 Mono,520:Hi Hat-Ln 1-EXs14	IFX4	2
G4	1	EXs14 Mono,481:Ride-99 1-EXs14	IFX4	Off
G#4	1	EXs14 Mono,522:Hi Hat-Ln 3-EXs14	IFX4	2
A4	1	EXs14 Mono,502:Crash-DrTr-EXs14	IFX4	Off
A#4	1	EXs14 Mono,525:Hi Hat-Ln 6-EXs14	IFX4	2
B4	1	EXs14 Mono,503:Ride-DrTr-EXs14	IFX4	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	EXs14 Mono,532:Conga-Ln 5-EXs14	IFX3	Off
C#5	1	EXs14 Mono,531:Conga-Ln 4-EXs14	IFX3	Off
D5	1	EXs14 Mono,530:Conga-Ln 3-EXs14	IFX3	Off
D#5	1	EXs14 Mono,529:Conga-Ln 2-EXs14	IFX3	Off
E5	1	EXs14 Mono,528:Conga-Ln 1-EXs14	IFX3	Off
F5	1	EXs14 Mono,504:Cabasa-DrTr-EXs14	IFX3	Off
F#5	1	EXs14 Mono,417:Hi-Hat-Closed-66-EXs14	IFX4	4
G5	1	EXs14 Mono,505:Cowbell-DrTr-EXs14	IFX3	Off
G#5	1	EXs14 Mono,418:Hi-Hat-Open-66-EXs14	IFX4	4
A5	1	EXs14 Mono,497:Sidestick-DrTr-EXs14	IFX3	Off
A#5	1	EXs14 Mono,418:Hi-Hat-Open-66-EXs14	IFX4	4
B5	1	EXs14 Mono,506:Tambourine-DrTr-EXs14	IFX3	Off
C6	1	EXs14 Mono,499:Tom-DrTr-EXs14	IFX3	Off
C#6	1	EXs14 Mono,533:Cowbell-Ln-EXs14	IFX3	Off
D6	1	EXs14 Mono,499:Tom-DrTr-EXs14	IFX3	Off
D#6	1	EXs14 Mono,534:Tambourine-Ln-EXs14	IFX3	Off
E6	1	EXs14 Mono,499:Tom-DrTr-EXs14	IFX3	Off
F6	1	EXs14 Mono,556:Tom-Smns 4-EXs14	IFX3	Off
F#6	1	EXs14 Mono,500:Hi Hat-Close-DrTr-EXs14	IFX4	3
G6	1	EXs14 Mono,555:Tom-Smns 3-EXs14	IFX3	Off
G#6	1	EXs14 Mono,501:Hi Hat-Open-DrTr-EXs14	IFX4	3
A6	1	EXs14 Mono,554:Tom-Smns 2-EXs14	IFX3	Off
A#6	1	EXs14 Mono,501:Hi Hat-Open-DrTr-EXs14	IFX4	3
B6	1	EXs14 Mono,553:Tom-Smns 1-EXs14	IFX3	Off
C7	1	EXs14 Mono,542:SD-Smns 02-EXs14	IFX3	Off
C#7	1	EXs14 Mono,558:Tom-Smns 6-EXs14	IFX3	Off
D7	1	EXs14 Mono,544:SD-Smns 04-EXs14	IFX3	Off
D#7	1	EXs14 Mono,557:Tom-Smns 5-EXs14	IFX3	Off
E7	1	EXs14 Mono,548:SD-Smns 08-EXs14	IFX5	Off
F7	1	EXs14 Mono,549:SD-Smns 09-EXs14	IFX5	Off
F#7	1	EXs14 Mono,460:BD-99-Electro 8-EXs14	IFX3	Off
G7	1	EXs14 Mono,550:SD-Smns 10-EXs14	IFX5	Off
G#7	1	EXs14 Mono,465:SD-99 05-EXs14	IFX3	Off
A7	1	EXs14 Mono,551:SD-Smns 11-EXs14	IFX5	Off
A#7	1	EXs14 Mono,470:SD-99 10-EXs14	IFX3	Off
B7	1	EXs14 Mono,552:SD-Smns 12-EXs14	IFX5	Off
C8	1	EXs14 Mono,540:BD-Smns 6-EXs14	IFX1	Off
C#8	1	EXs14 Mono,421:SD-77 2-EXs14	IFX1	Off
D8	1	EXs14 Stereo,26:BD-Ln9000-EXs14-L	IFX1	Off
D#8	1	EXs14 Mono,461:SD-99 01-EXs14	IFX1	Off
E8	1	EXs14 Stereo,27:SD-Ln9000-EXs14-L	IFX1	Off

U-G10: Korg Vintage Machine Kit

Key	Zoon	Drumsample	Bus	Ex
E0	1	EXs14 Mono,353:Rim-DDD1 2-EXs14	IFX1	Off
F0	1	EXs14 Mono,352:Rim-DDD1 1-EXs14	IFX1	Off
F#0	1	EXs14 Mono,351:Tsuzumi-DDD1 2-EXs14	IFX3	Off
G0	1	EXs14 Mono,350:Tsuzumi-DDD1 1-EXs14	IFX3	Off
G#0	1	EXs14 Mono,349:Taiko-DDD1 4-EXs14	IFX3	Off
A0	1	EXs14 Mono,348:Taiko-DDD1 3-EXs14	IFX3	Off
A#0	1	EXs14 Mono,347:Taiko-DDD1 2-EXs14	IFX3	10
B0	1	EXs14 Mono,346:Taiko-DDD1 1-EXs14	IFX3	Off
C1	1	EXs14 Mono,290:BD-DDD1 1-EXs14	IFX2	Off
C#1	1	EXs14 Mono,263:BD-Denkama-DE20-EXs14	IFX2	Off
D1	1	EXs14 Mono,282:BD-KPR77-EXs14	IFX2	Off
D#1	1	EXs14 Mono,291:BD-DDD1 2-EXs14	IFX2	Off
E1	1	EXs14 Mono,290:BD-DDD1 1-EXs14	IFX2	Off
F1	1	EXs14 Mono,383:SD-DDD5 1-EXs14	IFX1	Off
F#1	1	EXs14 Mono,277:SD-KPR55 3-EXs14	IFX1	Off
G1	1	EXs14 Mono,275:SD-KPR55 1-EXs14	IFX1	Off
G#1	1	EXs14 Mono,283:SD-KPR77-EXs14	IFX1	Off
A1	1	EXs14 Mono,384:SD-DDD5 2-EXs14	IFX1	Off
A#1	1	ROM Mono,561:Ride-Dance 99	IFX4	Off
B1	1	ROM Mono,10:BD-05-amb f	IFX2	Off
C2	1	EXs14 Mono,282:BD-KPR77-EXs14	IFX2	Off
C#2	1	EXs14 Mono,282:BD-KPR77-EXs14	IFX2	Off
D2	1	EXs14 Mono,274:BD-KPR55 2-EXs14	IFX2	Off
D#2	1	EXs14 Mono,273:BD-KPR55 1-EXs14	IFX2	Off
E2	1	EXs14 Mono,263:BD-Denkama-DE20-EXs14	IFX2	Off
F2	1	EXs14 Mono,383:SD-DDD5 1-EXs14	IFX1	Off
F#2	1	EXs14 Mono,283:SD-KPR77-EXs14	IFX1	Off
G2	1	EXs14 Mono,278:SD-KPR55 4-EXs14	IFX1	Off
G#2	1	EXs14 Mono,277:SD-KPR55 3-EXs14	IFX1	Off
A2	1	EXs14 Mono,276:SD-KPR55 2-EXs14	IFX1	Off
A#2	1	EXs14 Mono,275:SD-KPR55 1-EXs14	IFX1	Off
B2	1	EXs14 Mono,255:BD-Denkama 2-DE11-EXs14	IFX2	Off
C3	1	EXs14 Mono,254:BD-Denkama 1-DE11-EXs14	IFX2	Off
C#3	1	EXs14 Mono,353:Rim-DDD1 2-EXs14	IFX1	Off
D3	1	EXs14 Mono,264:SD-Denkama-DE20-EXs14	IFX1	Off
D#3	1	EXs14 Mono,284:Clap-KPR77-EXs14	IFX3	Off
E3	1	EXs14 Mono,265:Cym-Denkama-DE20-EXs14	IFX1	Off
F3	1	EXs14 Mono,286:Tom-KPR77 2-EXs14	IFX3	Off
F#3	1	EXs14 Mono,261:Maraca-Denkama-DE11-EXs14	IFX4	1
G3	1	EXs14 Mono,286:Tom-KPR77 2-EXs14	IFX3	Off
G#3	1	EXs14 Mono,261:Maraca-Denkama-DE11-EXs14	IFX4	1
A3	1	EXs14 Mono,286:Tom-KPR77 2-EXs14	IFX3	Off
A#3	1	EXs14 Mono,257:Cym-Denkama-DE11-EXs14	IFX4	1
B3	1	EXs14 Mono,408:Tom-DDD5 3-EXs14	IFX3	Off
C4	1	EXs14 Mono,408:Tom-DDD5 3-EXs14	IFX3	Off
C#4	1	EXs14 Mono,265:Cym-Denkama-DE20-EXs14	IFX4	Off
D4	1	EXs14 Mono,408:Tom-DDD5 3-EXs14	IFX3	Off
D#4	1	EXs14 Mono,289:Ride-KPR77-EXs14	IFX4	Off
E4	1	EXs14 Mono,265:Cym-Denkama-DE20-EXs14	IFX4	Off
F4	1	EXs14 Mono,392:Ride-DDD5-EXs14	IFX4	Off
F#4	1	EXs14 Mono,280:HH-Closed-KPR55-EXs14	IFX4	2
G4	1	EXs14 Mono,289:Ride-KPR77-EXs14	IFX4	Off
G#4	1	EXs14 Mono,280:HH-Closed-KPR55-EXs14	IFX4	2
A4	1	EXs14 Mono,391:Crash-DDD5-EXs14	IFX4	Off
A#4	1	EXs14 Mono,281:HH-Open-KPR55-EXs14	IFX4	2
B4	1	EXs14 Mono,392:Ride-DDD5-EXs14	IFX4	Off

Key	Zoon	Drumsample	Bus	Ex
C5	1	EXs14 Mono,259:LBongo-Denkama-DE11-EXs14	IFX3	Off
C#5	1	EXs14 Mono,261:Maraca-Denkama-DE11-EXs14	IFX3	Off
D5	1	EXs14 Mono,260:HBongo-Denkama-DE11-EXs14	IFX3	Off
D#5	1	EXs14 Mono,260:HBongo-Denkama-DE11-EXs14	IFX3	Off
E5	1	EXs14 Mono,262:WBlock-Denkama-DE11-EXs14	IFX3	Off
F5	1	EXs14 Mono,271:Claves-Denkama-DE20-EXs14	IFX3	Off
F#5	1	EXs14 Mono,267:LBongo-Denkama-DE20-EXs14	IFX3	Off
G5	1	EXs14 Mono,269:Conga-Denkama-DE20-EXs14	IFX3	Off
G#5	1	EXs14 Mono,270:Maraca-Denkama-DE20-EXs14	IFX3	Off
A5	1	EXs14 Mono,268:HBongo-Denkama-DE20-EXs14	IFX3	Off
A#5	1	EXs14 Mono,272:WBlock-Denkama-DE20-EXs14	IFX3	Off
B5	1	EXs14 Mono,412:Bass-DDD5-EXs14	IFX3	Off
C6	1	EXs14 Mono,324:Agogo-DDD1 1-EXs14	IFX3	Off
C#6	1	EXs14 Mono,327:Agogo-DDD1 4-EXs14	IFX3	Off
D6	1	EXs14 Mono,325:Agogo-DDD1 2-EXs14	IFX3	Off
D#6	1	EXs14 Mono,410:Agogo-DDD5-EXs14	IFX3	Off
E6	1	EXs14 Mono,326:Agogo-DDD1 3-EXs14	IFX3	Off
F6	1	EXs14 Mono,292:Bongo-DDD1 01-EXs14	IFX3	Off
F#6	1	EXs14 Mono,293:Bongo-DDD1 02-EXs14	IFX3	Off
G6	1	EXs14 Mono,294:Bongo-DDD1 03-EXs14	IFX3	Off
G#6	1	EXs14 Mono,295:Bongo-DDD1 04-EXs14	IFX3	Off
A6	1	EXs14 Mono,296:Bongo-DDD1 05-EXs14	IFX3	Off
A#6	1	EXs14 Mono,297:Bongo-DDD1 06-EXs14	IFX3	Off
B6	1	EXs14 Mono,300:Bongo-DDD1 09-EXs14	IFX3	Off
C7	1	EXs14 Mono,309:Conga-DDD1 04-EXs14	IFX3	Off
C#7	1	EXs14 Mono,363:Timbale-DDD1 2-EXs14	IFX3	Off
D7	1	EXs14 Mono,317:Conga-DDD1 12-EXs14	IFX3	Off
D#7	1	EXs14 Mono,364:Timbale-DDD1 3-EXs14	IFX3	Off
E7	1	EXs14 Mono,319:Conga-DDD1 14-EXs14	IFX3	Off
F7	1	EXs14 Mono,344:Mokugyo-DDD1 1-EXs14	IFX3	Off
F#7	1	EXs14 Mono,345:Mokugyo-DDD1 2-EXs14	IFX3	Off
G7	1	EXs14 Mono,361:Timpani-DDD1-EXs14	IFX3	Off
G#7	1	EXs14 Mono,342:Kiuchi-DDD1 1-EXs14	IFX3	Off
A7	1	EXs14 Mono,343:Kiuchi-DDD1 2-EXs14	IFX3	Off
A#7	1	EXs14 Mono,340:JingleBell-DDD1 1-EXs14	IFX3	Off
B7	1	EXs14 Mono,341:JingleBell-DDD1 2-EXs14	IFX3	Off
C8	1	EXs14 Mono,336:Guiro-DDD1 1-EXs14	IFX3	Off
C#8	1	EXs14 Mono,337:Guiro-DDD1 2-EXs14	IFX3	Off
D8	1	EXs14 Mono,338:Guiro-DDD1 3-EXs14	IFX3	Off
D#8	1	EXs14 Mono,339:Guiro-DDD1 4-EXs14	IFX3	Off
E8	1	EXs14 Mono,379:Whistle-DDD1-EXs14	IFX3	Off
F8	1	EXs14 Mono,361:Timpani-DDD1-EXs14	IFX3	Off

U-G11: Dance BD Kit [E0~E8]

Key	Zone	Drumsample	Bus	Ex
D#0	1	ROM Mono,0:BD-01-amb f	L/R	Off
E0	1	ROM Mono,78:BD-Dance 29	IFX2	Off
F0	1	ROM Mono,44:BD-Ambi	IFX2	Off
F#0	1	ROM Mono,49:BD-Dance 06	IFX2	Off
G0	1	ROM Mono,118:99:BD 1	IFX2	Off
G#0	1	ROM Mono,117:BD-99 Dance 12	IFX2	Off
A0	1	ROM Mono,74:BD-Dance 25	IFX2	Off
A#0	1	ROM Mono,97:BD-Dance 48	IFX2	Off
B0	1	ROM Mono,98:BD-Dance 49	IFX2	Off
C1	1	ROM Mono,99:BD-Dance 50	IFX2	Off
C#1	1	ROM Mono,86:BD-Dance 37	IFX2	Off
D1	1	ROM Mono,56:BD-Hip 3	IFX2	Off
D#1	1	ROM Mono,43:BD-Dance 03	IFX2	Off
E1	1	ROM Mono,58:BD-Dance 12	IFX2	Off
F1	1	ROM Mono,40:BD-Trance 2	IFX2	Off
F#1	1	ROM Mono,39:BD-Trance 1	IFX2	Off
G1	1	EXs14 Mono,457:BD-99-Electro 5-EXs14	IFX2	Off
G#1	1	EXs14 Mono,458:BD-99-Electro 6-EXs14	IFX2	Off
A1	1	EXs14 Mono,459:BD-99-Electro 7-EXs14	IFX2	Off
A#1	1	EXs14 Mono,455:BD-99-Electro 3-EXs14	IFX2	Off
B1	1	EXs14 Mono,456:BD-99-Electro 4-EXs14	IFX2	Off
C2	1	EXs14 Mono,0:BD-Electro 01-EXs14	IFX2	Off
C#2	1	EXs14 Mono,1:BD-Electro 02-EXs14	IFX2	Off
D2	1	EXs14 Mono,2:BD-Electro 03-EXs14	IFX2	Off
D#2	1	EXs14 Mono,3:BD-Electro 04-EXs14	IFX2	Off
E2	1	EXs14 Mono,4:BD-Electro 05-EXs14	IFX2	Off
F2	1	EXs14 Mono,5:BD-Electro 06-EXs14	IFX2	Off
F#2	1	EXs14 Mono,6:BD-Electro 07-EXs14	IFX2	Off
G2	1	EXs14 Mono,6:BD-Electro 07-EXs14	IFX2	Off
G#2	1	EXs14 Mono,8:BD-Electro 09-EXs14	IFX2	Off
A2	1	EXs14 Mono,9:BD-Electro 10-EXs14	IFX2	Off
A#2	1	EXs14 Mono,10:BD-Electro 11-EXs14	IFX2	Off
B2	1	EXs14 Mono,11:BD-Electro 12-EXs14	IFX2	Off
C3	1	EXs14 Mono,12:BD-Electro 13-EXs14	IFX2	Off
C#3	1	EXs14 Mono,13:BD-Electro 14-EXs14	IFX2	Off
D3	1	EXs14 Mono,14:BD-Electro 15-EXs14	IFX2	Off
D#3	1	EXs14 Mono,15:BD-Electro 16-EXs14	IFX2	Off
E3	1	EXs14 Mono,16:BD-Electro 17-EXs14	IFX2	Off
F3	1	EXs14 Stereo,0:BD-Electro 17-EXs14-L	IFX2	Off
F#3	1	EXs14 Mono,427:BD-88-Electro 1-EXs14	IFX2	Off
G3	1	EXs14 Mono,428:BD-88-Electro 2-EXs14	IFX2	Off
G#3	1	EXs14 Mono,453:BD-99-Electro 1-EXs14	IFX2	Off
A3	1	EXs14 Mono,454:BD-99-Electro 2-EXs14	IFX2	Off
A#3	1	EXs14 Mono,19:BD-Breaks 1-EXs14	IFX2	Off
B3	1	EXs14 Mono,20:BD-Breaks 2-EXs14	IFX2	Off
C4	1	EXs14 Mono,21:BD-Breaks 3-EXs14	IFX2	Off
C#4	1	EXs14 Mono,22:BD-Breaks 4-EXs14	IFX2	Off
D4	1	EXs14 Mono,23:BD-Breaks 5-EXs14	IFX2	Off
D#4	1	EXs14 Mono,24:BD-Breaks 6-EXs14	IFX2	Off
E4	1	EXs14 Mono,429:BD-88-Electro 3-EXs14	IFX2	Off
F4	1	EXs14 Mono,430:BD-88-Electro 4-EXs14	IFX2	Off
F#4	1	EXs14 Mono,25:BD-Funk 1-EXs14	IFX2	Off
G4	1	EXs14 Mono,26:BD-Funk 2-EXs14	IFX2	Off
G#4	1	EXs14 Mono,27:BD-Funk 3-EXs14	IFX2	Off
A4	1	EXs14 Mono,28:BD-Funk 4-EXs14	IFX2	Off
A#4	1	EXs14 Mono,29:BD-Funk 5-EXs14	IFX2	Off
B4	1	EXs14 Mono,30:BD-Funk 6-EXs14	IFX2	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	EXs14 Mono,31:BD-Funk 7-EXs14	IFX2	Off
C#5	1	EXs14 Mono,32:BD-Funk 8-EXs14	IFX2	Off
D5	1	EXs14 Mono,33:BD-Funk 9-EXs14	IFX2	Off
D#5	1	EXs14 Mono,34:BD-HipHop 1-EXs14	IFX2	Off
E5	1	EXs14 Mono,35:BD-HipHop 2-EXs14	IFX2	Off
F5	1	EXs14 Mono,36:BD-HipHop 3-EXs14	IFX2	Off
F#5	1	EXs14 Mono,37:BD-HipHop 4-EXs14	IFX2	Off
G5	1	EXs14 Mono,38:BD-HipHop 5-EXs14	IFX2	Off
G#5	1	EXs14 Mono,39:BD-HipHop 6-EXs14	IFX2	Off
A5	1	EXs14 Mono,431:BD-Trap 1-EXs14	IFX2	Off
A#5	1	EXs14 Mono,432:BD-88-Trap 2-EXs14	IFX2	Off
B5	1	EXs14 Mono,254:BD-Donkama 1-DE11-EXs14	IFX2	Off
C6	1	EXs14 Mono,255:BD-Donkama 2-DE11-EXs14	IFX2	Off
C#6	1	EXs14 Mono,263:BD-Donkama-DE20-EXs14	IFX2	Off
D6	1	EXs14 Mono,282:BD-KPR77-EXs14	IFX2	Off
D#6	1	EXs14 Mono,290:BD-DDD1 1-EXs14	IFX2	Off
E6	1	EXs14 Mono,291:BD-DDD1 2-EXs14	IFX2	Off
F6	1	EXs14 Mono,380:BD-DDD5 1-EXs14	IFX2	Off
F#6	1	EXs14 Mono,381:BD-DDD5 2-EXs14	IFX2	Off
G6	1	EXs14 Mono,382:BD-DDD5 3-EXs14	IFX2	Off
G#6	1	EXs14 Mono,433:BD-88-Trap 3-EXs14	IFX2	Off
A6	1	EXs14 Mono,413:BD-66 1-EXs14	IFX2	Off
A#6	1	EXs14 Mono,414:BD-66 2-EXs14	IFX2	Off
B6	1	EXs14 Mono,422:BD-88 1-EXs14	IFX2	Off
C7	1	EXs14 Mono,423:BD-88 2-EXs14	IFX2	Off
C#7	1	EXs14 Mono,424:BD-88 3-EXs14	IFX2	Off
D7	1	EXs14 Mono,425:BD-88 4-EXs14	IFX2	Off
D#7	1	EXs14 Mono,426:BD-88 5-EXs14	IFX2	Off
E7	1	EXs14 Mono,451:BD-99 1-EXs14	IFX2	Off
F7	1	EXs14 Mono,452:BD-99 2-EXs14	IFX2	Off
F#7	1	EXs14 Mono,495:BD-DrTr-EXs14	IFX2	Off
G7	1	EXs14 Mono,511:BD-Ln-EXs14	IFX2	Off
G#7	1	EXs14 Mono,535:BD-Smns 1-EXs14	IFX2	Off
A7	1	EXs14 Mono,536:BD-Smns 2-EXs14	IFX2	Off
A#7	1	EXs14 Mono,537:BD-Smns 3-EXs14	IFX2	Off
B7	1	EXs14 Mono,538:BD-Smns 4-EXs14	IFX2	Off
C8	1	EXs14 Mono,539:BD-Smns 5-EXs14	IFX2	Off
C#8	1	EXs14 Mono,540:BD-Smns 6-EXs14	IFX2	Off
D8	1	EXs14 Stereo,1:BD-Techno 1-EXs14-L	IFX2	Off
D#8	1	EXs14 Stereo,2:BD-Techno 2-EXs14-L	IFX2	Off
E8	1	EXs14 Stereo,26:BD-Ln9000-EXs14-L	IFX2	Off

U-G12: Dance SD Kit [E0~E8]

Key	Zone	Drumsample	Bus	Ex
D#0	1	ROM Mono,0:BD-01-amb f	L/R	Off
E0	1	EXs14 Mono,415:SD-66-EXs14	IFX1	Off
F0	1	EXs14 Mono,479:SD-99 19-EXs14	IFX1	Off
F#0	1	EXs14 Mono,474:SD-99 14-EXs14	IFX1	Off
G0	1	EXs14 Mono,461:SD-99 01-EXs14	IFX1	Off
G#0	1	EXs14 Mono,435:SD-88-Trap 2-EXs14	IFX1	Off
A0	1	EXs14 Mono,436:SD-88-Trap 3-EXs14	IFX1	Off
A#0	1	EXs14 Mono,437:SD-88-Trap 4-EXs14	IFX1	Off
B0	1	EXs14 Mono,438:SD-88-Trap 5-EXs14	IFX1	Off
C1	1	EXs14 Mono,439:SD-88-Trap 6-EXs14	IFX1	Off
C#1	1	EXs14 Mono,440:SD-88-Trap 7-EXs14	IFX1	Off
D1	1	EXs14 Mono,420:SD-77 1-EXs14	IFX1	Off
D#1	1	EXs14 Mono,421:SD-77 2-EXs14	IFX1	Off
E1	1	EXs14 Mono,384:SD-DDD5 2-EXs14	IFX1	Off
F1	1	EXs14 Mono,383:SD-DDD5 1-EXs14	IFX1	Off
F#1	1	EXs14 Mono,283:SD-KPR77-EXs14	IFX1	Off
G1	1	EXs14 Mono,278:SD-KPR55 4-EXs14	IFX1	Off
G#1	1	EXs14 Mono,277:SD-KPR55 3-EXs14	IFX1	Off
A1	1	EXs14 Mono,276:SD-KPR55 2-EXs14	IFX1	Off
A#1	1	EXs14 Mono,275:SD-KPR55 1-EXs14	IFX1	Off
B1	1	EXs14 Mono,264:SD-Donkama-DE20-EXs14	IFX1	Off
C2	1	EXs14 Mono,44:SD-Electro 01-EXs14	IFX1	Off
C#2	1	EXs14 Mono,45:SD-Electro 02-EXs14	IFX1	Off
D2	1	EXs14 Mono,46:SD-Electro 03-EXs14	IFX1	Off
D#2	1	EXs14 Mono,47:SD-Electro 04-EXs14	IFX1	Off
E2	1	EXs14 Mono,48:SD-Electro 05-EXs14	IFX1	Off
F2	1	EXs14 Mono,49:SD-Electro 06-EXs14	IFX1	Off
F#2	1	EXs14 Mono,50:SD-Electro 07-EXs14	IFX1	Off
G2	1	EXs14 Mono,51:SD-Electro 08-EXs14	IFX1	Off
G#2	1	EXs14 Mono,52:SD-Electro 09-EXs14	IFX1	Off
A2	1	EXs14 Mono,53:SD-Electro 10-EXs14	IFX1	Off
A#2	1	EXs14 Mono,54:SD-Electro 11-EXs14	IFX1	Off
B2	1	EXs14 Mono,55:SD-Electro 12-EXs14	IFX1	Off
C3	1	EXs14 Mono,56:SD-Electro 13-EXs14	IFX1	Off
C#3	1	EXs14 Mono,57:SD-Electro 14-EXs14	IFX1	Off
D3	1	EXs14 Mono,58:SD-Electro 15-EXs14	IFX1	Off
D#3	1	EXs14 Mono,59:SD-Electro 16-EXs14	IFX1	Off
E3	1	EXs14 Mono,60:SD-Electro 17-EXs14	IFX1	Off
F3	1	EXs14 Mono,61:SD-Electro 18-EXs14	IFX1	Off
F#3	1	EXs14 Mono,62:SD-Electro 19-EXs14	IFX1	Off
G3	1	EXs14 Mono,63:SD-Electro 20-EXs14	IFX1	Off
G#3	1	EXs14 Mono,64:SD-Electro 21-EXs14	IFX1	Off
A3	1	EXs14 Mono,65:SD-Electro 22-EXs14	IFX1	Off
A#3	1	EXs14 Mono,66:SD-Electro 23-EXs14	IFX1	Off
B3	1	EXs14 Mono,67:SD-Electro 24-EXs14	IFX1	Off
C4	1	EXs14 Stereo,3:SD-Electro 25-EXs14-L	IFX1	Off
C#4	1	EXs14 Stereo,4:SD-Electro 26-EXs14-L	IFX1	Off
D4	1	EXs14 Stereo,5:SD-Electro 27-EXs14-L	IFX1	Off
D#4	1	EXs14 Mono,74:SD-Breaks 01-EXs14	IFX1	Off
E4	1	EXs14 Mono,75:SD-Breaks 02-EXs14	IFX1	Off
F4	1	EXs14 Mono,76:SD-Breaks 03-EXs14	IFX1	Off
F#4	1	EXs14 Mono,77:SD-Breaks 04-EXs14	IFX1	Off
G4	1	EXs14 Mono,78:SD-Breaks 05-EXs14	IFX1	Off
G#4	1	EXs14 Mono,79:SD-Breaks 06-EXs14	IFX1	Off
A4	1	EXs14 Mono,80:SD-Breaks 07-EXs14	IFX1	Off
A#4	1	EXs14 Mono,81:SD-Breaks 08-EXs14	IFX1	Off
B4	1	EXs14 Mono,82:SD-Breaks 09-EXs14	IFX1	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	EXs14 Mono,83:SD-Breaks 10-EXs14	IFX1	Off
C#5	1	EXs14 Mono,84:SD-Breaks 11-EXs14	IFX1	Off
D5	1	EXs14 Mono,85:SD-Breaks 12-EXs14	IFX1	Off
D#5	1	EXs14 Mono,86:SD-Breaks 13-EXs14	IFX1	Off
E5	1	EXs14 Mono,87:SD-Breaks 14-EXs14	IFX1	Off
F5	1	EXs14 Mono,88:SD-Breaks 15-EXs14	IFX1	Off
F#5	1	EXs14 Mono,89:SD-Breaks 16-EXs14	IFX1	Off
G5	1	EXs14 Mono,90:SD-Breaks 17-EXs14	IFX1	Off
G#5	1	EXs14 Mono,91:SD-Breaks 18-EXs14	IFX1	Off
A5	1	EXs14 Mono,92:SD-Breaks 19-EXs14	IFX1	Off
A#5	1	EXs14 Mono,93:SD-Breaks 20-EXs14	IFX1	Off
B5	1	EXs14 Mono,94:SD-Breaks 21-EXs14	IFX1	Off
C6	1	EXs14 Mono,441:SD-88-Trap 8-EXs14	IFX1	Off
C#6	1	EXs14 Mono,95:SD-Funk 01-EXs14	IFX1	Off
D6	1	EXs14 Mono,96:SD-Funk 02-EXs14	IFX1	Off
D#6	1	EXs14 Mono,97:SD-Funk 03-EXs14	IFX1	Off
E6	1	EXs14 Mono,98:SD-Funk 04-EXs14	IFX1	Off
F6	1	EXs14 Mono,99:SD-Funk 05-EXs14	IFX1	Off
F#6	1	EXs14 Mono,100:SD-Funk 06-EXs14	IFX1	Off
G6	1	EXs14 Mono,101:SD-Funk 07-EXs14	IFX1	Off
G#6	1	EXs14 Mono,102:SD-Funk 08-EXs14	IFX1	Off
A6	1	EXs14 Mono,103:SD-Funk 09-EXs14	IFX1	Off
A#6	1	EXs14 Mono,104:SD-Funk 10-EXs14	IFX1	Off
B6	1	EXs14 Mono,105:SD-Funk 11-EXs14	IFX1	Off
C7	1	EXs14 Mono,106:SD-Funk 12-EXs14	IFX1	Off
C#7	1	EXs14 Mono,107:SD-Funk 13-EXs14	IFX1	Off
D7	1	EXs14 Mono,108:SD-Funk 14-EXs14	IFX1	Off
D#7	1	EXs14 Mono,109:SD-Funk 15-EXs14	IFX1	Off
E7	1	EXs14 Mono,110:SD-Funk 16-EXs14	IFX1	Off
F7	1	EXs14 Mono,111:SD-Funk 17-EXs14	IFX1	Off
F#7	1	EXs14 Mono,112:SD-Funk 18-EXs14	IFX1	Off
G7	1	EXs14 Mono,113:SD-HipHop 1-EXs14	IFX1	Off
G#7	1	EXs14 Mono,114:SD-HipHop 2-EXs14	IFX1	Off
A7	1	EXs14 Mono,115:SD-HipHop 3-EXs14	IFX1	Off
A#7	1	EXs14 Mono,116:SD-HipHop 4-EXs14	IFX1	Off
B7	1	EXs14 Mono,117:SD-HipHop 5-EXs14	IFX1	Off
C8	1	EXs14 Stereo,27:SD-Ln9000-EXs14-L	IFX1	Off
C#8	1	EXs14 Mono,541:SD-Smns 01-EXs14	IFX1	Off
D8	1	EXs14 Mono,542:SD-Smns 02-EXs14	IFX1	Off
D#8	1	EXs14 Mono,543:SD-Smns 03-EXs14	IFX1	Off
E8	1	EXs14 Mono,546:SD-Smns 06-EXs14	IFX1	Off

U-G13: Dance Clap Kit [C3~F5]

Key	Zone	Drumsample	Bus	Ex
B2	1	ROM Mono,0:BD-01-amb f	IFX2	Off
C3	1	EXs14 Stereo,6:Clap-Dance 1-EXs14-L	IFX1	Off
C#3	1	EXs14 Stereo,7:Clap-Dance 2-EXs14-L	IFX1	Off
D3	1	EXs14 Stereo,8:Clap-Dance 3-EXs14-L	IFX1	Off
D#3	1	EXs14 Stereo,9:Clap-Dance 4-EXs14-L	IFX1	Off
E3	1	EXs14 Mono,126:Clap-Electro 01-EXs14	IFX1	Off
F3	1	EXs14 Mono,127:Clap-Electro 02-EXs14	IFX1	Off
F#3	1	EXs14 Mono,128:Clap-Electro 03-EXs14	IFX1	Off
G3	1	EXs14 Mono,129:Clap-Electro 04-EXs14	IFX1	Off
G#3	1	EXs14 Mono,130:Clap-Electro 05-EXs14	IFX1	Off
A3	1	EXs14 Mono,131:Clap-Electro 06-EXs14	IFX1	Off
A#3	1	EXs14 Mono,132:Clap-Electro 07-EXs14	IFX1	Off
B3	1	EXs14 Mono,133:Clap-Electro 08-EXs14	IFX1	Off
C4	1	EXs14 Mono,134:Clap-Electro 09-EXs14	IFX1	Off
C#4	1	EXs14 Mono,135:Clap-Electro 10-EXs14	IFX1	Off
D4	1	EXs14 Mono,136:Clap-Electro 11-EXs14	IFX1	Off
D#4	1	EXs14 Mono,443:Clap-88 2-EXs14	IFX1	Off
E4	1	EXs14 Mono,139:Clap-HipHop 1-EXs14	IFX1	Off
F4	1	EXs14 Mono,140:Clap-HipHop 2-EXs14	IFX1	Off
F#4	1	EXs14 Mono,141:Clap-HipHop 3-EXs14	IFX1	Off
G4	1	EXs14 Mono,284:Clap-KPR77-EXs14	IFX1	Off
G#4	1	EXs14 Mono,385:Clap-DDD5-EXs14	IFX1	Off
A4	1	EXs14 Mono,442:Clap-88 1-EXs14	IFX1	Off
A#4	1	ROM Mono,574:Hand Claps 1	IFX1	Off
B4	1	ROM Mono,575:Hand Claps 2-a	IFX1	Off
C5	1	ROM Mono,576:Hand Claps 2-b	IFX1	Off
C#5	1	ROM Mono,577:Hand Claps 2-c	IFX1	Off
D5	1	ROM Mono,578:Hand Claps 2-d	IFX1	Off
D#5	1	ROM Mono,579:Hand Claps 2-e	IFX1	Off
E5	1	ROM Mono,580:Hand Claps 2-f	IFX1	Off
F5	1	ROM Mono,581:Hand Claps 2-g	IFX1	Off

U-G14: Dance HH Kit [E0~E8]

Key	Zone	Drumsample	Bus	Ex
D#0	1	ROM Mono,0:BD-01-amb f	IFX5	3
E0	1	ROM Mono,508:H.Hat-Whispy	IFX5	Off
F0	1	ROM Mono,507:H.Hat-ClangyOpen	IFX5	1
F#0	1	ROM Mono,506:H.Hat-Crisp Open	IFX5	1
G0	1	ROM Mono,505:H.Hat-Ambi	IFX5	1
G#0	1	ROM Mono,504:H.Hat-Hip	IFX5	Off
A0	1	ROM Mono,503:H.Hat-Vintage	IFX5	Off
A#0	1	ROM Mono,502:H.Hat-Chili	IFX5	Off
B0	1	ROM Mono,498:Hi-Hat WS-Closed a	IFX5	2
C1	1	ROM Mono,499:Hi-Hat WS-Closed b	IFX5	2
C#1	1	ROM Mono,500:Hi-Hat WS-HalfOpen	IFX5	2
D1	1	ROM Mono,501:Hi-Hat WS-Open	IFX5	2
D#1	1	ROM Mono,496:Hi-Hat Dance 31	IFX5	2
E1	1	ROM Mono,497:Hi-Hat Dance 32	IFX5	2
F1	1	EXs14 Mono,448:HiHat-Cl-88 2-Trap-EXs14	IFX5	3
F#1	1	EXs14 Mono,447:HiHat-Cl-88 1-Trap-EXs14	IFX5	3
G1	1	EXs14 Mono,449:HiHat-Open-88-Trap-EXs14	IFX5	3
G#1	1	ROM Mono,511:88-HHat Closed	IFX5	3
A1	1	ROM Mono,512:88-HHat Open	IFX5	3
A#1	1	ROM Mono,509:99-HHat Closed	IFX5	4
B1	1	ROM Mono,510:99-HHat Open	IFX5	4
C2	1	EXs14 Stereo,12:Hi Hat-Electro15-EXs14-L	IFX5	Off
C#2	1	EXs14 Stereo,13:Hi Hat-Electro16-EXs14-L	IFX5	Off
D2	1	EXs14 Mono,152:Hi Hat-Electro 01-EXs14	IFX5	Off
D#2	1	EXs14 Mono,153:Hi Hat-Electro 02-EXs14	IFX5	Off
E2	1	EXs14 Mono,154:Hi Hat-Electro 03-EXs14	IFX5	Off
F2	1	EXs14 Mono,155:Hi Hat-Electro 04-EXs14	IFX5	Off
F#2	1	EXs14 Mono,156:Hi Hat-Electro 05-EXs14	IFX5	Off
G2	1	EXs14 Mono,157:Hi Hat-Electro 06-EXs14	IFX5	Off
G#2	1	EXs14 Mono,158:Hi Hat-Electro 07-EXs14	IFX5	Off
A2	1	EXs14 Mono,159:Hi Hat-Electro 08-EXs14	IFX5	Off
A#2	1	EXs14 Mono,160:Hi Hat-Electro 09-EXs14	IFX5	Off
B2	1	EXs14 Mono,161:Hi Hat-Electro 10-EXs14	IFX5	Off
C3	1	EXs14 Mono,162:Hi Hat-Electro 11-EXs14	IFX5	Off
C#3	1	EXs14 Mono,163:Hi Hat-Electro 12-EXs14	IFX5	Off
D3	1	EXs14 Mono,164:Hi Hat-Electro 13-EXs14	IFX5	Off
D#3	1	EXs14 Mono,165:Hi Hat-Electro 14-EXs14	IFX5	Off
E3	1	EXs14 Mono,170:Hi Hat-Funk 01-EXs14	IFX5	4
F3	1	EXs14 Mono,171:Hi Hat-Funk 02-EXs14	IFX5	4
F#3	1	EXs14 Mono,172:Hi Hat-Funk 03-EXs14	IFX5	4
G3	1	EXs14 Mono,173:Hi Hat-Funk 04-Op-EXs14	IFX5	4
G#3	1	EXs14 Mono,174:Hi Hat-Funk 05-EXs14	IFX5	5
A3	1	EXs14 Mono,175:Hi Hat-Funk 06-EXs14	IFX5	5
A#3	1	EXs14 Mono,176:Hi Hat-Funk 07-EXs14	IFX5	5
B3	1	EXs14 Mono,177:Hi Hat-Funk 08-Op-EXs14	IFX5	5
C4	1	EXs14 Mono,178:Hi Hat-Funk 09-EXs14	IFX5	Off
C#4	1	EXs14 Mono,179:Hi Hat-Funk 10-EXs14	IFX5	6
D4	1	EXs14 Mono,180:Hi Hat-Funk 11-Op-EXs14	IFX5	6
D#4	1	EXs14 Mono,181:Hi Hat-Funk 12-EXs14	IFX5	Off
E4	1	EXs14 Mono,182:Hi Hat-Funk 13-EXs14	IFX5	Off
F4	1	EXs14 Mono,183:Hi Hat-Funk 14-EXs14	IFX5	Off
F#4	1	EXs14 Mono,184:Hi Hat-HipHop-Open-EXs14	IFX5	Off
G4	1	EXs14 Mono,280:HH-Closed-KPR55-EXs14	IFX5	16
G#4	1	EXs14 Mono,281:HH-Open-KPR55-EXs14	IFX5	16
A4	1	EXs14 Mono,287:HH-Closed-KPR77-EXs14	IFX5	7
A#4	1	EXs14 Mono,288:HH-Open-KPR77-EXs14	IFX5	7
B4	1	EXs14 Mono,388:HH Closed-DDD5 1-EXs14	IFX5	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	EXs14 Mono,389:HH Closed-DDD5 2-EXs14	IFX5	Off
C#5	1	EXs14 Mono,483:Hi Hat-Cl-99-comp1-EXs14	IFX5	8
D5	1	EXs14 Mono,484:Hi Hat-Cl-99-comp2-EXs14	IFX5	8
D#5	1	EXs14 Mono,485:Hi Hat-Cl-99-comp3-EXs14	IFX5	8
E5	1	EXs14 Mono,486:Hi Hat-Cl-99-comp4-EXs14	IFX5	8
F5	1	EXs14 Mono,487:Hi Hat-Cl-99-comp5-EXs14	IFX5	8
F#5	1	EXs14 Mono,488:Hi Hat-Cl-99-comp6-EXs14	IFX5	8
G5	1	EXs14 Mono,489:Hi Hat-Cl-99-comp7-EXs14	IFX5	8
G#5	1	EXs14 Mono,490:Hi Hat-Op-99-comp1-EXs14	IFX5	8
A5	1	EXs14 Mono,491:Hi Hat-Op-99-comp2-EXs14	IFX5	8
A#5	1	EXs14 Mono,492:Hi Hat-Op-99-comp3-EXs14	IFX5	8
B5	1	EXs14 Mono,493:Hi Hat-Op-99-comp4-EXs14	IFX5	8
C6	1	EXs14 Mono,494:Hi Hat-Op-99-comp5-EXs14	IFX5	8
C#6	1	EXs14 Mono,447:HiHat-Cl-88 1-Trap-EXs14	IFX5	Off
D6	1	EXs14 Mono,448:HiHat-Cl-88 2-Trap-EXs14	IFX5	9
D#6	1	EXs14 Mono,449:HiHat-Open-88-Trap-EXs14	IFX5	9
E6	1	EXs14 Mono,417:Hi-Hat-Closed-66-EXs14	IFX5	9
F6	1	EXs14 Mono,418:Hi-Hat-Open-66-EXs14	IFX5	9
F#6	1	EXs14 Mono,500:Hi Hat-Close-Drt-EXs14	IFX5	10
G6	1	EXs14 Mono,501:Hi Hat-Open-Drt-EXs14	IFX5	10
G#6	1	EXs14 Mono,520:Hi Hat-Ln 1-EXs14	IFX5	17
A6	1	EXs14 Mono,521:Hi Hat-Ln 2-EXs14	IFX5	17
A#6	1	EXs14 Mono,522:Hi Hat-Ln 3-EXs14	IFX5	17
B6	1	EXs14 Mono,523:Hi Hat-Ln 4-EXs14	IFX5	17
C7	1	EXs14 Mono,524:Hi Hat-Ln 5-EXs14	IFX5	11
C#7	1	EXs14 Mono,525:Hi Hat-Ln 6-EXs14	IFX5	11
D7	1	ROM Mono,479:Hi-Hat Dance 14	IFX5	Off
D#7	1	ROM Mono,480:Hi-Hat Dance 15	IFX5	12
E7	1	ROM Mono,481:Hi-Hat Dance 16	IFX5	12
F7	1	ROM Mono,482:Hi-Hat Dance 17	IFX5	12
F#7	1	ROM Mono,483:Hi-Hat Dance 18	IFX5	Off
G7	1	ROM Mono,484:Hi-Hat Dance 19	IFX5	13
G#7	1	ROM Mono,485:Hi-Hat Dance 20	IFX5	13
A7	1	ROM Mono,486:Hi-Hat Dance 21	IFX5	13
A#7	1	ROM Mono,487:Hi-Hat Dance 22	IFX5	14
B7	1	ROM Mono,488:Hi-Hat Dance 23	IFX5	14
C8	1	ROM Mono,489:Hi-Hat Dance 24	IFX5	Off
C#8	1	ROM Mono,490:Hi-Hat Dance 25	IFX5	15
D8	1	ROM Mono,491:Hi-Hat Dance 26	IFX5	15
D#8	1	ROM Mono,492:Hi-Hat Dance 27	IFX5	15
E8	1	ROM Mono,513:Hi-Hat WS Syn-Closed	IFX5	Off

U-G15: Dance Hit Kit [E0~E8]

Key	Zone	Drumsample	Bus	Ex
D#0	1	ROM Mono,0:BD-01-amb f	L/R	Off
E0	1	ROM Mono,1053:Synth Hit Decay 4	IFX5	Off
F0	1	ROM Mono,1053:Synth Hit Decay 4	IFX5	Off
F#0	1	ROM Mono,1052:Synth Hit Decay 3	IFX5	Off
G0	1	ROM Mono,1052:Synth Hit Decay 3	IFX5	Off
G#0	1	ROM Mono,1051:Synth Hit Decay 2	IFX5	Off
A0	1	ROM Mono,1051:Synth Hit Decay 2	IFX5	Off
A#0	1	ROM Mono,1050:Synth Hit Decay 1	IFX5	Off
B0	1	ROM Mono,1050:Synth Hit Decay 1	IFX5	Off
C1	1	ROM Mono,1049:Synth Hit Loop 6	IFX5	Off
C#1	1	ROM Mono,1049:Synth Hit Loop 6	IFX5	Off
D1	1	ROM Mono,1048:Synth Hit Loop 5	IFX5	Off
D#1	1	ROM Mono,1048:Synth Hit Loop 5	IFX5	Off
E1	1	ROM Mono,1047:Synth Hit Loop 4	IFX5	Off
F1	1	ROM Mono,1047:Synth Hit Loop 4	IFX5	Off
F#1	1	ROM Mono,1046:Synth Hit Loop 3	IFX5	Off
G1	1	ROM Mono,1046:Synth Hit Loop 3	IFX5	Off
G#1	1	ROM Mono,1045:Synth Hit Loop 2	IFX5	Off
A1	1	ROM Mono,1045:Synth Hit Loop 2	IFX5	Off
A#1	1	ROM Mono,1044:Synth Hit Loop 1	IFX5	Off
B1	1	ROM Mono,1044:Synth Hit Loop 1	IFX5	Off
C2	1	EXs14 Stereo,17:Dance Hit 4-EXs14-L	IFX5	Off
C#2	1	EXs14 Stereo,17:Dance Hit 4-EXs14-L	IFX5	Off
D2	1	EXs14 Stereo,19:Dance Hit 6-EXs14-L	IFX5	Off
D#2	1	EXs14 Stereo,19:Dance Hit 6-EXs14-L	IFX5	Off
E2	1	EXs14 Stereo,20:Dance Hit 7-EXs14-L	IFX5	Off
F2	1	EXs14 Stereo,20:Dance Hit 7-EXs14-L	IFX5	Off
F#2	1	EXs14 Stereo,21:Dance Hit 8-EXs14-L	IFX5	Off
G2	1	EXs14 Stereo,21:Dance Hit 8-EXs14-L	IFX5	Off
G#2	1	EXs14 Mono,186:Synth Hit 02-EXs14	IFX5	Off
A2	1	EXs14 Mono,186:Synth Hit 02-EXs14	IFX5	Off
A#2	1	EXs14 Mono,187:Synth Hit 03-EXs14	IFX5	Off
B2	1	EXs14 Mono,187:Synth Hit 03-EXs14	IFX5	Off
C3	1	EXs14 Mono,188:Synth Hit 04-EXs14	IFX5	Off
C#3	1	EXs14 Mono,188:Synth Hit 04-EXs14	IFX5	Off
D3	1	EXs14 Mono,189:Synth Hit 05-EXs14	IFX5	Off
D#3	1	EXs14 Mono,189:Synth Hit 05-EXs14	IFX5	Off
E3	1	EXs14 Mono,190:Synth Hit 06-EXs14	IFX5	Off
F3	1	EXs14 Mono,190:Synth Hit 06-EXs14	IFX5	Off
F#3	1	EXs14 Mono,191:Synth Hit 07-EXs14	IFX5	Off
G3	1	EXs14 Mono,191:Synth Hit 07-EXs14	IFX5	Off
G#3	1	EXs14 Mono,191:Synth Hit 07-EXs14	IFX5	Off
A3	1	EXs14 Mono,191:Synth Hit 07-EXs14	IFX5	Off
A#3	1	EXs14 Mono,193:Synth Hit 09-EXs14	IFX5	Off
B3	1	EXs14 Mono,193:Synth Hit 09-EXs14	IFX5	Off
C4	1	EXs14 Mono,196:Synth Hit 12-EXs14	IFX5	Off
C#4	1	EXs14 Mono,196:Synth Hit 12-EXs14	IFX5	Off
D4	1	EXs14 Mono,197:Synth Hit 13-EXs14	IFX5	Off
D#4	1	EXs14 Mono,197:Synth Hit 13-EXs14	IFX5	Off
E4	1	EXs14 Mono,198:Synth Hit 14-EXs14	IFX5	Off
F4	1	EXs14 Mono,198:Synth Hit 14-EXs14	IFX5	Off
F#4	1	EXs14 Mono,200:Synth Hit 16-EXs14	IFX5	Off
G4	1	EXs14 Mono,200:Synth Hit 16-EXs14	IFX5	Off
G#4	1	EXs14 Mono,202:Synth Hit 18-EXs14	IFX5	Off
A4	1	EXs14 Mono,202:Synth Hit 18-EXs14	IFX5	Off
A#4	1	EXs14 Mono,203:Synth Hit 19-EXs14	IFX5	Off
B4	1	EXs14 Mono,203:Synth Hit 19-EXs14	IFX5	Off

Key	Zone	Drumsample	Bus	Ex
C5	1	ROM Mono,1023:Orch Hit 1	IFX5	Off
C#5	1	ROM Mono,1023:Orch Hit 1	IFX5	Off
D5	1	ROM Mono,1024:Orch Hit 2	IFX5	Off
D#5	1	ROM Mono,1024:Orch Hit 2	IFX5	Off
E5	1	ROM Mono,1025:Orch Hit 3	IFX5	Off
F5	1	ROM Mono,1025:Orch Hit 3	IFX5	Off
F#5	1	ROM Mono,1026:Orch Hit 4	IFX5	Off
G5	1	ROM Mono,1026:Orch Hit 4	IFX5	Off
G#5	1	ROM Mono,1027:Orch Hit 5	IFX5	Off
A5	1	ROM Mono,1027:Orch Hit 5	IFX5	Off
A#5	1	ROM Mono,1028:Orch Hit 6	IFX5	Off
B5	1	ROM Mono,1028:Orch Hit 6	IFX5	Off
C6	1	ROM Mono,1029:Orch Hit 7	IFX5	Off
C#6	1	ROM Mono,1029:Orch Hit 7	IFX5	Off
D6	1	ROM Mono,1030:Impact Hit	IFX5	Off
D#6	1	ROM Mono,1030:Impact Hit	IFX5	Off
E6	1	ROM Mono,1031:Band Hit 1	IFX5	Off
F6	1	ROM Mono,1031:Band Hit 1	IFX5	Off
F#6	1	ROM Mono,1032:Band Hit 2	IFX5	Off
G6	1	ROM Mono,1032:Band Hit 2	IFX5	Off
G#6	1	ROM Mono,1033:Big Hit	IFX5	Off
A6	1	ROM Mono,1033:Big Hit	IFX5	Off
A#6	1	ROM Mono,1034:Jazz Hit 1	IFX5	Off
B6	1	ROM Mono,1034:Jazz Hit 1	IFX5	Off
C7	1	ROM Mono,1035:Jazz Hit 2	IFX5	Off
C#7	1	ROM Mono,1035:Jazz Hit 2	IFX5	Off
D7	1	ROM Mono,1036:Jazz Hit 3	IFX5	Off
D#7	1	ROM Mono,1036:Jazz Hit 3	IFX5	Off
E7	1	ROM Mono,1041:Dance Hit	IFX5	Off
F7	1	ROM Mono,1041:Dance Hit	IFX5	Off
F#7	1	ROM Mono,1042:VibeChord	IFX5	Off
G7	1	ROM Mono,1042:VibeChord	IFX5	Off
G#7	1	ROM Mono,1043:W.E.P.Chord	IFX5	Off
A7	1	ROM Mono,1043:W.E.P.Chord	IFX5	Off
A#7	1	EXs14 Mono,186:Synth Hit 02-EXs14	IFX5	Off
B7	1	EXs14 Mono,186:Synth Hit 02-EXs14	IFX5	Off
C8	1	EXs14 Mono,212:Drum Hit 09-EXs14	IFX5	Off
C#8	1	EXs14 Mono,212:Drum Hit 09-EXs14	IFX5	Off
D8	1	EXs14 Mono,225:Drum Hit 22-EXs14	IFX5	Off
D#8	1	EXs14 Stereo,22:Dance Hit 9-EXs14-L	IFX5	Off
E8	1	EXs14 Mono,194:Synth Hit 10-EXs14	IFX5	Off

Drum Samples

#	Name
0000	BD-Electro 01-EXs14
0001	BD-Electro 02-EXs14
0002	BD-Electro 03-EXs14
0003	BD-Electro 04-EXs14
0004	BD-Electro 05-EXs14
0005	BD-Electro 06-EXs14
0006	BD-Electro 07-EXs14
0007	BD-Electro 08-EXs14
0008	BD-Electro 09-EXs14
0009	BD-Electro 10-EXs14
0010	BD-Electro 11-EXs14
0011	BD-Electro 12-EXs14
0012	BD-Electro 13-EXs14
0013	BD-Electro 14-EXs14
0014	BD-Electro 15-EXs14
0015	BD-Electro 16-EXs14
0016	BD-Electro 17-EXs14
0017	BD-Electro 18-EXs14-L
0018	BD-Electro 18-EXs14-R
0019	BD-Breaks 1-EXs14
0020	BD-Breaks 2-EXs14
0021	BD-Breaks 3-EXs14
0022	BD-Breaks 4-EXs14
0023	BD-Breaks 5-EXs14
0024	BD-Breaks 6-EXs14
0025	BD-Funk 1-EXs14
0026	BD-Funk 2-EXs14
0027	BD-Funk 3-EXs14
0028	BD-Funk 4-EXs14
0029	BD-Funk 5-EXs14
0030	BD-Funk 6-EXs14
0031	BD-Funk 7-EXs14
0032	BD-Funk 8-EXs14
0033	BD-Funk 9-EXs14
0034	BD-HipHop 1-EXs14
0035	BD-HipHop 2-EXs14
0036	BD-HipHop 3-EXs14
0037	BD-HipHop 4-EXs14
0038	BD-HipHop 5-EXs14
0039	BD-HipHop 6-EXs14
0040	BD-Techno 1-EXs14-L
0041	BD-Techno 1-EXs14-R
0042	BD-Techno 2-EXs14-L
0043	BD-Techno 2-EXs14-R
0044	SD-Electro 01-EXs14
0045	SD-Electro 02-EXs14
0046	SD-Electro 03-EXs14
0047	SD-Electro 04-EXs14
0048	SD-Electro 05-EXs14
0049	SD-Electro 06-EXs14
0050	SD-Electro 07-EXs14
0051	SD-Electro 08-EXs14
0052	SD-Electro 09-EXs14
0053	SD-Electro 10-EXs14
0054	SD-Electro 11-EXs14
0055	SD-Electro 12-EXs14
0056	SD-Electro 13-EXs14
0057	SD-Electro 14-EXs14
0058	SD-Electro 15-EXs14
0059	SD-Electro 16-EXs14
0060	SD-Electro 17-EXs14
0061	SD-Electro 18-EXs14
0062	SD-Electro 19-EXs14
0063	SD-Electro 20-EXs14
0064	SD-Electro 21-EXs14
0065	SD-Electro 22-EXs14
0066	SD-Electro 23-EXs14
0067	SD-Electro 24-EXs14
0068	SD-Electro 25-EXs14-L
0069	SD-Electro 25-EXs14-R
0070	SD-Electro 26-EXs14-L

#	Name
0071	SD-Electro 26-EXs14-R
0072	SD-Electro 27-EXs14-L
0073	SD-Electro 27-EXs14-R
0074	SD-Breaks 01-EXs14
0075	SD-Breaks 02-EXs14
0076	SD-Breaks 03-EXs14
0077	SD-Breaks 04-EXs14
0078	SD-Breaks 05-EXs14
0079	SD-Breaks 06-EXs14
0080	SD-Breaks 07-EXs14
0081	SD-Breaks 08-EXs14
0082	SD-Breaks 09-EXs14
0083	SD-Breaks 10-EXs14
0084	SD-Breaks 11-EXs14
0085	SD-Breaks 12-EXs14
0086	SD-Breaks 13-EXs14
0087	SD-Breaks 14-EXs14
0088	SD-Breaks 15-EXs14
0089	SD-Breaks 16-EXs14
0090	SD-Breaks 17-EXs14
0091	SD-Breaks 18-EXs14
0092	SD-Breaks 19-EXs14
0093	SD-Breaks 20-EXs14
0094	SD-Breaks 21-EXs14
0095	SD-Funk 01-EXs14
0096	SD-Funk 02-EXs14
0097	SD-Funk 03-EXs14
0098	SD-Funk 04-EXs14
0099	SD-Funk 05-EXs14
0100	SD-Funk 06-EXs14
0101	SD-Funk 07-EXs14
0102	SD-Funk 08-EXs14
0103	SD-Funk 09-EXs14
0104	SD-Funk 10-EXs14
0105	SD-Funk 11-EXs14
0106	SD-Funk 12-EXs14
0107	SD-Funk 13-EXs14
0108	SD-Funk 14-EXs14
0109	SD-Funk 15-EXs14
0110	SD-Funk 16-EXs14
0111	SD-Funk 17-EXs14
0112	SD-Funk 18-EXs14
0113	SD-HipHop 1-EXs14
0114	SD-HipHop 2-EXs14
0115	SD-HipHop 3-EXs14
0116	SD-HipHop 4-EXs14
0117	SD-HipHop 5-EXs14
0118	Clap-Dance 1-EXs14-L
0119	Clap-Dance 1-EXs14-R
0120	Clap-Dance 2-EXs14-L
0121	Clap-Dance 2-EXs14-R
0122	Clap-Dance 3-EXs14-L
0123	Clap-Dance 3-EXs14-R
0124	Clap-Dance 4-EXs14-L
0125	Clap-Dance 4-EXs14-R
0126	Clap-Electro 01-EXs14
0127	Clap-Electro 02-EXs14
0128	Clap-Electro 03-EXs14
0129	Clap-Electro 04-EXs14
0130	Clap-Electro 05-EXs14
0131	Clap-Electro 06-EXs14
0132	Clap-Electro 07-EXs14
0133	Clap-Electro 08-EXs14
0134	Clap-Electro 09-EXs14
0135	Clap-Electro 10-EXs14
0136	Clap-Electro 11-EXs14
0137	Clap-Electro 12-EXs14-L
0138	Clap-Electro 12-EXs14-R
0139	Clap-HipHop 1-EXs14
0140	Clap-HipHop 2-EXs14
0141	Clap-HipHop 3-EXs14

#	Name
0142	Tom-Electro-EXs14
0143	Tom-Processed-EXs14-L
0144	Tom-Processed-EXs14-R
0145	Tom-Breaks 1-EXs14
0146	Tom-Breaks 2-EXs14
0147	Tom-Breaks 3-EXs14
0148	Tom-Breaks 4-EXs14
0149	Tom-Breaks 5-EXs14
0150	Tom-Breaks 6-EXs14
0151	Tom-Breaks 7-EXs14
0152	Hi Hat-Electro 01-EXs14
0153	Hi Hat-Electro 02-EXs14
0154	Hi Hat-Electro 03-EXs14
0155	Hi Hat-Electro 04-EXs14
0156	Hi Hat-Electro 05-EXs14
0157	Hi Hat-Electro 06-EXs14
0158	Hi Hat-Electro 07-EXs14
0159	Hi Hat-Electro 08-EXs14
0160	Hi Hat-Electro 09-EXs14
0161	Hi Hat-Electro 10-EXs14
0162	Hi Hat-Electro 11-EXs14
0163	Hi Hat-Electro 12-EXs14
0164	Hi Hat-Electro 13-EXs14
0165	Hi Hat-Electro 14-EXs14
0166	Hi Hat-Electro 15-EXs14-L
0167	Hi Hat-Electro 15-EXs14-R
0168	Hi Hat-Electro 16-EXs14-L
0169	Hi Hat-Electro 16-EXs14-R
0170	Hi Hat-Funk 01-EXs14
0171	Hi Hat-Funk 02-EXs14
0172	Hi Hat-Funk 03-EXs14
0173	Hi Hat-Funk 04-Op-EXs14
0174	Hi Hat-Funk 05-EXs14
0175	Hi Hat-Funk 06-EXs14
0176	Hi Hat-Funk 07-EXs14
0177	Hi Hat-Funk 08-Op-EXs14
0178	Hi Hat-Funk 09-EXs14
0179	Hi Hat-Funk 10-EXs14
0180	Hi Hat-Funk 11-Op-EXs14
0181	Hi Hat-Funk 12-EXs14
0182	Hi Hat-Funk 13-EXs14
0183	Hi Hat-Funk 14-EXs14
0184	Hi Hat-HipHop-Open-EXs14
0185	Synth Hit 01-EXs14
0186	Synth Hit 02-EXs14
0187	Synth Hit 03-EXs14
0188	Synth Hit 04-EXs14
0189	Synth Hit 05-EXs14
0190	Synth Hit 06-EXs14
0191	Synth Hit 07-EXs14
0192	Synth Hit 08-EXs14
0193	Synth Hit 09-EXs14
0194	Synth Hit 10-EXs14
0195	Synth Hit 11-EXs14
0196	Synth Hit 12-EXs14
0197	Synth Hit 13-EXs14
0198	Synth Hit 14-EXs14
0199	Synth Hit 15-EXs14
0200	Synth Hit 16-EXs14
0201	Synth Hit 17-EXs14
0202	Synth Hit 18-EXs14
0203	Synth Hit 19-EXs14
0204	Drum Hit 01-EXs14
0205	Drum Hit 02-EXs14
0206	Drum Hit 03-EXs14
0207	Drum Hit 04-EXs14
0208	Drum Hit 05-EXs14
0209	Drum Hit 06-EXs14
0210	Drum Hit 07-EXs14
0211	Drum Hit 08-EXs14
0212	Drum Hit 09-EXs14

#	Name
0213	Drum Hit 10-EXs14
0214	Drum Hit 11-EXs14
0215	Drum Hit 12-EXs14
0216	Drum Hit 13-EXs14
0217	Drum Hit 14-EXs14
0218	Drum Hit 15-EXs14
0219	Drum Hit 16-EXs14
0220	Drum Hit 17-EXs14
0221	Drum Hit 18-EXs14
0222	Drum Hit 19-EXs14
0223	Drum Hit 20-EXs14
0224	Drum Hit 21-EXs14
0225	Drum Hit 22-EXs14
0226	Drum Hit 23-EXs14
0227	Drum Hit 24-EXs14
0228	Dance Hit 1-EXs14-L
0229	Dance Hit 1-EXs14-R
0230	Dance Hit 2-EXs14-L
0231	Dance Hit 2-EXs14-R
0232	Dance Hit 3-EXs14-L
0233	Dance Hit 3-EXs14-R
0234	Dance Hit 4-EXs14-L
0235	Dance Hit 4-EXs14-R
0236	Dance Hit 5-EXs14-L
0237	Dance Hit 5-EXs14-R
0238	Dance Hit 6-EXs14-L
0239	Dance Hit 6-EXs14-R
0240	Dance Hit 7-EXs14-L
0241	Dance Hit 7-EXs14-R
0242	Dance Hit 8-EXs14-L
0243	Dance Hit 8-EXs14-R
0244	Dance Hit 9-EXs14-L
0245	Dance Hit 9-EXs14-R
0246	Scratch 1-EXs14
0247	Scratch 2-EXs14
0248	Record Noise 1-EXs14-L
0249	Record Noise 1-EXs14-R
0250	Record Noise 2-EXs14-L
0251	Record Noise 2-EXs14-R
0252	White Noise -EXs14-L
0253	White Noise -EXs14-R
0254	BD-Donkama 1-DE11-EXs14
0255	BD-Donkama 2-DE11-EXs14
0256	SD-Donkama-DE11-EXs14
0257	Cym-Donkama-DE11-EXs14
0258	Acc-Donkama-DE11-EXs14
0259	LBongo-DonkamaDE11-EXs14
0260	HBongo-DonkamaDE11-EXs14
0261	Maraca-DonkamaDE11-EXs14
0262	WBlock-DonkamaDE11-EXs14
0263	BD-Donkama-DE20-EXs14
0264	SD-Donkama-DE20-EXs14
0265	Cym-Donkama-DE20-EXs14
0266	Acc-Donkama-DE20-EXs14
0267	LBongo-DonkamaDE20-EXs14
0268	HBongo-DonkamaDE20-EXs14
0269	LConga-DonkamaDE20-EXs14
0270	Maraca-DonkamaDE20-EXs14
0271	Claves-DonkamaDE20-EXs14
0272	WBlock-DonkamaDE20-EXs14
0273	BD-KPR55 1-EXs14
0274	BD-KPR55 2-EXs14
0275	SD-KPR55 1-EXs14
0276	SD-KPR55 2-EXs14
0277	SD-KPR55 3-EXs14
0278	SD-KPR55 4-EXs14
0279	Tom-KPR55-EXs14
0280	HH-Closed-KPR55-EXs14
0281	HH-Open-KPR55-EXs14
0282	BD-KPR77-EXs14
0283	SD-KPR77-EXs14

#	Name	#	Name	#	Name	#	Name
0284	Clap-KPR77-Exs14	0355	Shaker-DDD1 2-Exs14	0426	BD-88 5-Exs14	0497	Sidestick-DrTr-Exs14
0285	Tom-KPR77 1-Exs14	0356	Shaker-DDD1 3-Exs14	0427	BD-88-Electro 1-Exs14	0498	Clap-DrTr-Exs14
0286	Tom-KPR77 2-Exs14	0357	Shaker-DDD1 4-Exs14	0428	BD-88-Electro 2-Exs14	0499	Tom-DrTr-Exs14
0287	HH-Closed-KPR77-Exs14	0358	Tambourine-DDD1 1-Exs14	0429	BD-88-Electro 3-Exs14	0500	Hi Hat-Close-DrTr-Exs14
0288	HH-Open-KPR77-Exs14	0359	Tambourine-DDD1 2-Exs14	0430	BD-88-Electro 4-Exs14	0501	Hi Hat-Open-DrTr-Exs14
0289	Ride-KPR77-Exs14	0360	Tambourine-DDD1 3-Exs14	0431	BD-88-Trap 1-Exs14	0502	Crash-DrTr-Exs14
0290	BD-DDD1 1-Exs14	0361	Timpani-DDD1-Exs14	0432	BD-88-Trap 2-Exs14	0503	Ride-DrTr-Exs14
0291	BD-DDD1 2-Exs14	0362	Timbale-DDD1 1-Exs14	0433	BD-88-Trap 3-Exs14	0504	Cabasa-DrTr-Exs14
0292	Bongo-DDD1 01-Exs14	0363	Timbale-DDD1 2-Exs14	0434	SD-88-Trap 1-Exs14	0505	Cowbell-DrTr-Exs14
0293	Bongo-DDD1 02-Exs14	0364	Timbale-DDD1 3-Exs14	0435	SD-88-Trap 2-Exs14	0506	Tambourine-DrTr-Exs14
0294	Bongo-DDD1 03-Exs14	0365	Timbale-DDD1 4-Exs14	0436	SD-88-Trap 3-Exs14	0507	BD-Ln9000-Exs14-L
0295	Bongo-DDD1 04-Exs14	0366	Timbale-DDD1 5-Exs14	0437	SD-88-Trap 4-Exs14	0508	BD-Ln9000-Exs14-R
0296	Bongo-DDD1 05-Exs14	0367	Timbale-DDD1 6-Exs14	0438	SD-88-Trap 5-Exs14	0509	SD-Ln9000-Exs14-L
0297	Bongo-DDD1 06-Exs14	0368	Timbale-DDD1 7-Exs14	0439	SD-88-Trap 6-Exs14	0510	SD-Ln9000-Exs14-R
0298	Bongo-DDD1 07-Exs14	0369	Timbale-DDD1 8-Exs14	0440	SD-88-Trap 7-Exs14	0511	BD-Ln-Exs14
0299	Bongo-DDD1 08-Exs14	0370	Triangle-DDD1 1-Exs14	0441	SD-88-Trap 8-Exs14	0512	SD-Ln-Exs14
0300	Bongo-DDD1 09-Exs14	0371	Triangle-DDD1 2-Exs14	0442	Clap-88 1-Exs14	0513	Sidestick-Ln-Exs14
0301	Bongo-DDD1 10-Exs14	0372	Triangle-DDD1 3-Exs14	0443	Clap-88 2-Exs14	0514	Clap-Ln-Exs14
0302	Bongo-DDD1 11-Exs14	0373	WBlock-DDD1 1-Exs14	0444	HH-Cl-88-Electro 1-Exs14	0515	Tom-Ln 1-Exs14
0303	Bongo-DDD1 12-Exs14	0374	WBlock-DDD1 2-Exs14	0445	HH-Cl-88-Electro 2-Exs14	0516	Tom-Ln 2-Exs14
0304	Bongo-DDD1 13-Exs14	0375	WBlock-DDD1 3-Exs14	0446	HH-Open-88-Electro-Exs14	0517	Tom-Ln 3-Exs14
0305	Bongo-DDD1 14-Exs14	0376	WBlock-DDD1 4-Exs14	0447	HiHat-Cl-88 1-Trap-Exs14	0518	Tom-Ln 4-Exs14
0306	Conga-DDD1 01-Exs14	0377	WD-DDD1 1-Exs14	0448	HiHat-Cl-88 2-Trap-Exs14	0519	Tom-Ln 5-Exs14
0307	Conga-DDD1 02-Exs14	0378	WD-DDD1 2-Exs14	0449	HiHat-Open-88-Trap-Exs14	0520	Hi Hat-Ln 1-Exs14
0308	Conga-DDD1 03-Exs14	0379	Whistle-DDD1-Exs14	0450	Tublar-Trap-Exs14	0521	Hi Hat-Ln 2-Exs14
0309	Conga-DDD1 04-Exs14	0380	BD-DDD5 1-Exs14	0451	BD-99 1-Exs14	0522	Hi Hat-Ln 3-Exs14
0310	Conga-DDD1 05-Exs14	0381	BD-DDD5 2-Exs14	0452	BD-99 2-Exs14	0523	Hi Hat-Ln 4-Exs14
0311	Conga-DDD1 06-Exs14	0382	BD-DDD5 3-Exs14	0453	BD-99-Electro 1-Exs14	0524	Hi Hat-Ln 5-Exs14
0312	Conga-DDD1 07-Exs14	0383	SD-DDD5 1-Exs14	0454	BD-99-Electro 2-Exs14	0525	Hi Hat-Ln 6-Exs14
0313	Conga-DDD1 08-Exs14	0384	SD-DDD5 2-Exs14	0455	BD-99-Electro 3-Exs14	0526	Ride-Ln-Exs14
0314	Conga-DDD1 09-Exs14	0385	Clap-DDD5-Exs14	0456	BD-99-Electro 4-Exs14	0527	Crash-Ln-Exs14
0315	Conga-DDD1 10-Exs14	0386	Tom-DDD5 1-Exs14	0457	BD-99-Electro 5-Exs14	0528	Conga-Ln 1-Exs14
0316	Conga-DDD1 11-Exs14	0387	Tom-DDD5 2-Exs14	0458	BD-99-Electro 6-Exs14	0529	Conga-Ln 2-Exs14
0317	Conga-DDD1 12-Exs14	0388	HH Closed-DDD5 1-Exs14	0459	BD-99-Electro 7-Exs14	0530	Conga-Ln 3-Exs14
0318	Conga-DDD1 13-Exs14	0389	HH Closed-DDD5 2-Exs14	0460	BD-99-Electro 8-Exs14	0531	Conga-Ln 4-Exs14
0319	Conga-DDD1 14-Exs14	0390	HH Open-DDD5-Exs14	0461	SD-99 01-Exs14	0532	Conga-Ln 5-Exs14
0320	Conga-DDD1 15-Exs14	0391	Crash-DDD5-Exs14	0462	SD-99 02-Exs14	0533	Cowbell-Ln-Exs14
0321	Conga-DDD1 16-Exs14	0392	Ride-DDD5-Exs14	0463	SD-99 03-Exs14	0534	Tambourine-Ln-Exs14
0322	Claves-DDD1 1-Exs14	0393	Rim-DDD5 1-Exs14	0464	SD-99 04-Exs14	0535	BD-Smns 1-Exs14
0323	Claves-DDD1 2-Exs14	0394	Rim-DDD5 2-Exs14	0465	SD-99 05-Exs14	0536	BD-Smns 2-Exs14
0324	Agogo-DDD1 1-Exs14	0395	Stick-DDD5 1-Exs14	0466	SD-99 06-Exs14	0537	BD-Smns 3-Exs14
0325	Agogo-DDD1 2-Exs14	0396	Stick-DDD5 2-Exs14	0467	SD-99 07-Exs14	0538	BD-Smns 4-Exs14
0326	Agogo-DDD1 3-Exs14	0397	Bongo-DDD5 1-Exs14	0468	SD-99 08-Exs14	0539	BD-Smns 5-Exs14
0327	Agogo-DDD1 4-Exs14	0398	Bongo-DDD5 2-Exs14	0469	SD-99 09-Exs14	0540	BD-Smns 6-Exs14
0328	Cowbell-DDD1 1-Exs14	0399	Cabasa-DDD5 1-Exs14	0470	SD-99 10-Exs14	0541	SD-Smns 01-Exs14
0329	Cowbell-DDD1 2-Exs14	0400	Cabasa-DDD5 2-Exs14	0471	SD-99 11-Exs14	0542	SD-Smns 02-Exs14
0330	Cowbell-DDD1 3-Exs14	0401	Conga-DDD5 1-Exs14	0472	SD-99 12-Exs14	0543	SD-Smns 03-Exs14
0331	Cowbell-DDD1 4-Exs14	0402	Conga-DDD5 2-Exs14	0473	SD-99 13-Exs14	0544	SD-Smns 04-Exs14
0332	Cuica-DDD1 1-Exs14	0403	Conga-DDD5 3-Exs14	0474	SD-99 14-Exs14	0545	SD-Smns 05-Exs14
0333	Cuica-DDD1 2-Exs14	0404	Conga-DDD5 4-Exs14	0475	SD-99 15-Exs14	0546	SD-Smns 06-Exs14
0334	Cuica-DDD1 3-Exs14	0405	Claves-DDD5-Exs14	0476	SD-99 16-Exs14	0547	SD-Smns 07-Exs14
0335	Cuica-DDD1 4-Exs14	0406	Cowbell-DDD5-Exs14	0477	SD-99 17-Exs14	0548	SD-Smns 08-Exs14
0336	Guiro-DDD1 1-Exs14	0407	Tambourine-DDD5-Exs14	0478	SD-99 18-Exs14	0549	SD-Smns 09-Exs14
0337	Guiro-DDD1 2-Exs14	0408	Tom-DDD5 3-Exs14	0479	SD-99 19-Exs14	0550	SD-Smns 10-Exs14
0338	Guiro-DDD1 3-Exs14	0409	Timbale-DDD5-Exs14	0480	Crash-99-Exs14	0551	SD-Smns 11-Exs14
0339	Guiro-DDD1 4-Exs14	0410	Agogo-DDD5-Exs14	0481	Ride-99 1-Exs14	0552	SD-Smns 12-Exs14
0340	JingleBell-DDD1 1-Exs14	0411	Bass-DDD5 1-Exs14	0482	Ride-99 2-Exs14	0553	Tom-Smns 1-Exs14
0341	JingleBell-DDD1 2-Exs14	0412	Bass-DDD5 2-Exs14	0483	Hi Hat-Cl-99-comp1-Exs14	0554	Tom-Smns 2-Exs14
0342	Kiuchi-DDD1 1-Exs14	0413	BD-66 1-Exs14	0484	Hi Hat-Cl-99-comp2-Exs14	0555	Tom-Smns 3-Exs14
0343	Kiuchi-DDD1 2-Exs14	0414	BD-66 2-Exs14	0485	Hi Hat-Cl-99-comp3-Exs14	0556	Tom-Smns 4-Exs14
0344	Mokugyo-DDD1 1-Exs14	0415	SD-66-Exs14	0486	Hi Hat-Cl-99-comp4-Exs14	0557	Tom-Smns 5-Exs14
0345	Mokugyo-DDD1 2-Exs14	0416	Tom-66-Exs14	0487	Hi Hat-Cl-99-comp5-Exs14	0558	Tom-Smns 6-Exs14
0346	Taiko-DDD1 1-Exs14	0417	Hi-Hat-Closed-66-Exs14	0488	Hi Hat-Cl-99-comp6-Exs14	0559	FX-Smns 1-Exs14
0347	Taiko-DDD1 2-Exs14	0418	Hi-Hat-Open-66-Exs14	0489	Hi Hat-Cl-99-comp7-Exs14	0560	FX-Smns 2-Exs14
0348	Taiko-DDD1 3-Exs14	0419	Cym-66-Exs14	0490	Hi Hat-Op-99-comp1-Exs14	0561	FX-Smns 3-Exs14
0349	Taiko-DDD1 4-Exs14	0420	SD-77 1-Exs14	0491	Hi Hat-Op-99-comp2-Exs14	0562	FX-Smns 4-Exs14
0350	Tsuzumi-DDD1 1-Exs14	0421	SD-77 2-Exs14	0492	Hi Hat-Op-99-comp3-Exs14	0563	FX-Smns 5-Exs14
0351	Tsuzumi-DDD1 2-Exs14	0422	BD-88 1-Exs14	0493	Hi Hat-Op-99-comp4-Exs14	0564	FX-Smns 6-Exs14
0352	Rim-DDD1 1-Exs14	0423	BD-88 2-Exs14	0494	Hi Hat-Op-99-comp5-Exs14	0565	FX-Smns 7-Exs14
0353	Rim-DDD1 2-Exs14	0424	BD-88 3-Exs14	0495	BD-DrTr-Exs14	0566	FX-Smns 8-Exs14
0354	Shaker-DDD1 1-Exs14	0425	BD-88 4-Exs14	0496	SD-DrTr-Exs14		

Drum Track Patterns

#	Name
U230	E.House 01 EXs14 [Dance]
U231	E.House 02 EXs14 [Dance]
U232	E.House 03 EXs14 [Dance]
U233	E.House 04 EXs14 [Dance]
U234	E.House 05 EXs14 [Dance]
U235	E.House 06 EXs14 [Dance]
U236	E.House 07 EXs14 [Dance]
U237	E.House 08 EXs14 [Dance]
U238	E.House 09 EXs14 [Dance]
U239	E.House 10 EXs14 [Dance]
U240	E.House 11 EXs14 [Dance]
U241	E.House 12 EXs14 [Dance]
U242	E.House 13 EXs14 [Dance]
U243	E.House 14 EXs14 [Dance]
U244	E.House 15 EXs14 [Dance]
U245	E.House 16 EXs14 [Dance]
U246	E.House 17 EXs14 [Dance]
U247	E.House 18 EXs14 [Dance]
U248	Progresve01 EXs14[Dance]
U249	Progresve02 EXs14[Dance]
U250	Progresve03 EXs14[Dance]
U251	Progresve04 EXs14[Dance]
U252	Progresve05 EXs14[Dance]
U253	Progresve06 EXs14[Dance]
U254	Progresve07 EXs14[Dance]
U255	Progresve08 EXs14[Dance]
U256	Progresve09 EXs14[Dance]
U257	Progresve10 EXs14[Dance]
U258	Progresve11 EXs14[Dance]
U259	Progresve12 EXs14[Dance]
U260	Progresve13 EXs14[Dance]
U261	Techno 01 EXs14 [Dance]
U262	Techno 02 EXs14 [Dance]
U263	Techno 03 EXs14 [Dance]
U264	Techno 04 EXs14 [Dance]
U265	Techno 05 EXs14 [Dance]
U266	Techno 06 EXs14 [Dance]
U267	Techno 07 EXs14 [Dance]
U268	Techno 08 EXs14 [Dance]
U269	Techno 09 EXs14 [Dance]
U270	Techno 10 EXs14 [Dance]
U271	Techno 11 EXs14 [Dance]
U272	Techno 12 EXs14 [Dance]
U273	Techno 13 EXs14 [Dance]
U274	Techno 14 EXs14 [Dance]
U275	Techno 15 EXs14 [Dance]
U276	Techno 16 EXs14 [Dance]
U277	Techno 17 EXs14 [Dance]
U278	Techno 18 EXs14 [Dance]
U279	Techno 19 EXs14 [Dance]
U280	Dubstep 01 EXs14 [Dance]
U281	Dubstep 02 EXs14 [Dance]
U282	Dubstep 03 EXs14 [Dance]
U283	Dubstep 04 EXs14 [Dance]
U284	Dubstep 05 EXs14 [Dance]
U285	Dubstep 06 EXs14 [Dance]
U286	Dubstep 07 EXs14 [Dance]
U287	Dubstep 08 EXs14 [Dance]
U288	Dubstep 09 EXs14 [Dance]
U289	Dubstep 10 EXs14 [Dance]

#	Name
U290	Dubstep 11 EXs14 [Dance]
U291	Dubstep 12 EXs14 [Dance]
U292	GlitchHop01 EXs14 [Dance]
U293	GlitchHop02 EXs14 [Dance]
U294	GlitchHop03 EXs14 [Dance]
U295	GlitchHop04 EXs14 [Dance]
U296	GlitchHop05 EXs14 [Dance]
U297	GlitchHop06 EXs14 [Dance]
U298	GlitchHop07 EXs14 [Dance]
U299	GlitchHop08 EXs14 [Dance]
U300	GlitchHop09 EXs14 [Dance]
U301	GlitchHop10 EXs14 [Dance]
U302	GlitchHop11 EXs14 [Dance]
U303	GlitchHop12 EXs14 [Dance]
U304	Trap 01 EXs14 [Dance]
U305	Trap 02 EXs14 [Dance]
U306	Trap 03 EXs14 [Dance]
U307	Trap 04 EXs14 [Dance]
U308	Trap 05 EXs14 [Dance]
U309	Trap 06 EXs14 [Dance]
U310	Trap 07 EXs14 [Dance]
U311	Trap 08 EXs14 [Dance]
U312	Trap 09 EXs14 [Dance]
U313	Trap 10 EXs14 [Dance]
U314	Trap 11 EXs14 [Dance]
U315	Trap 12 EXs14 [Dance]
U316	Trap 13 EXs14 [Dance]
U317	Trap 14 EXs14 [Dance]
U318	Trap 15 EXs14 [Dance]
U319	Trap 16 EXs14 [Dance]
U320	Trap 17 EXs14 [Dance]
U321	R&B/Funk 01 EXs14 [Dance]
U322	R&B/Funk 02 EXs14 [Dance]
U323	R&B/Funk 03 EXs14 [Dance]
U324	R&B/Funk 04 EXs14 [Dance]
U325	R&B/Funk 05 EXs14 [Dance]
U326	R&B/Funk 06 EXs14 [Dance]
U327	R&B/Funk 07 EXs14 [Dance]
U328	R&B/Funk 08 EXs14 [Dance]
U329	R&B/Funk 09 EXs14 [Dance]
U330	R&B/Funk 10 EXs14 [Dance]
U331	R&B/Funk 11 EXs14 [Dance]
U332	R&B/Funk 12 EXs14 [Dance]
U333	Drum&Bass01 EXs14 [Dance]
U334	Drum&Bass02 EXs14 [Dance]
U335	Drum&Bass03 EXs14 [Dance]
U336	Drum&Bass04 EXs14 [Dance]
U337	Drum&Bass05 EXs14 [Dance]
U338	Drum&Bass06 EXs14 [Dance]
U339	Drum&Bass07 EXs14 [Dance]
U340	Drum&Bass08 EXs14 [Dance]
U341	Drum&Bass09 EXs14 [Dance]
U342	Drum&Bass10 EXs14 [Dance]
U343	Drum&Bass11 EXs14 [Dance]
U344	Drum&Bass12 EXs14 [Dance]
U345	Breaks 01 EXs14 [Dance]
U346	Breaks 02 EXs14 [Dance]
U347	Breaks 03 EXs14 [Dance]
U348	Breaks 04 EXs14 [Dance]
U349	Breaks 05 EXs14 [Dance]

#	Name
U350	Breaks 06 EXs14 [Dance]
U351	Breaks 07 EXs14 [Dance]
U352	Breaks 08 EXs14 [Dance]
U353	Breaks 09 EXs14 [Dance]
U354	Breaks 10 EXs14 [Dance]
U355	Breaks 11 EXs14 [Dance]
U356	Breaks 12 EXs14 [Dance]
U357	Chill 01 EXs14 [Dance]
U358	Chill 02 EXs14 [Dance]
U359	Chill 03 EXs14 [Dance]
U360	Chill 04 EXs14 [Dance]
U361	Chill 05 EXs14 [Dance]
U362	Chill 06 EXs14 [Dance]
U363	Chill 07 EXs14 [Dance]
U364	Chill 08 EXs14 [Dance]
U365	Chill 09 EXs14 [Dance]
U366	Chill 10 EXs14 [Dance]
U367	Chill 11 EXs14 [Dance]
U368	Chill 12 EXs14 [Dance]
U369	Electro 01 EXs14 [Dance]
U370	Electro 02 EXs14 [Dance]
U371	Electro 03 EXs14 [Dance]
U372	Electro 04 EXs14 [Dance]
U373	Electro 05 EXs14 [Dance]
U374	Electro 06 EXs14 [Dance]
U375	Electro 07 EXs14 [Dance]
U376	Electro 08 EXs14 [Dance]
U377	Electro 09 EXs14 [Dance]
U378	Electro 10 EXs14 [Dance]
U379	Electro 11 EXs14 [Dance]
U380	Electro 12 EXs14 [Dance]
U381	Electro 13 EXs14 [Dance]
U382	Vintage 01 EXs14 [Dance]
U383	Vintage 02 EXs14 [Dance]
U384	Vintage 03 EXs14 [Dance]
U385	Vintage 04 EXs14 [Dance]
U386	Vintage 05 EXs14 [Dance]
U387	Vintage 06 EXs14 [Dance]
U388	Vintage 07 EXs14 [Dance]
U389	Vintage 08 EXs14 [Dance]
U390	Vintage 09 EXs14 [Dance]
U391	Vintage 10 EXs14 [Dance]
U392	Vintage 11 EXs14 [Dance]
U393	Vintage 12 EXs14 [Dance]
U394	KorgVtg 01 EXs14 [Dance]
U395	KorgVtg 02 EXs14 [Dance]
U396	KorgVtg 03 EXs14 [Dance]
U397	KorgVtg 04 EXs14 [Dance]
U398	KorgVtg 05 EXs14 [Dance]
U399	KorgVtg 06 EXs14 [Dance]
U400	KorgVtg 07 EXs14 [Dance]
U401	KorgVtg 08 EXs14 [Dance]
U402	KorgVtg 09 EXs14 [Dance]
U403	KorgVtg 10 EXs14 [Dance]
U404	KorgVtg 11 EXs14 [Dance]
U405	KorgVtg 12 EXs14 [Dance]

Demo RPPRs

S000

Electro House

RPPR

S000 Electro House

#	Pattern Name
U00	Electro Beat 01
U01	Electro Beat 02
U02	Electro Beat 03
U03	Electro Beat 04
U04	Electro Beat 05
U05	Electro Beat 06
U06	Electro Beat 07
U07	Electro Beat 08
U08	Electro Beat 09
U09	Electro Beat 10
U10	Electro Beat 11
U11	Electro Beat 12
U12	Electro Beat 13
U13	Electro Beat 14
U14	Electro Beat 15
U15	Electro Beat 16
U16	Electro Beat 17
U17	Electro Beat 18
U18	Electro Bass
U19	Electro Synth 1
U20	Electro Synth 2

S001

Progressive House

S002

Techno / Minimal

S003

Dubstep

S004

Glitch Hop

S005

Trap

S006

R&B / Funk

S007

Drum & Bass

S008

Breaks

S009

Chill / Down Tempo

S010

Electronica

S011

Vintage Machine

S012

Korg Vintage Machine

Demo RPPRs by KORG Inc.
- all right reserved

RPPR

S000 Electro House

S002 Techno / Minimal

#	Pattern Name
U00	Techno Beat 01
U01	Techno Beat 02
U02	Techno Beat 03
U03	Techno Beat 04
U04	Techno Beat 05
U05	Techno Beat 06
U06	Techno Beat 07
U07	Techno Beat 08
U08	Techno Beat 09
U09	Techno Beat 10
U10	Techno Beat 11
U11	Techno Beat 12
U12	Techno Beat 13
U13	Techno Beat 14
U14	Techno Beat 15
U15	Techno Beat 16
U16	Techno Beat 17
U17	Techno Beat 18
U18	Techno Beat 19
U19	Techno Bass
U20	Techno Hit 1
U21	Techno Per
U22	Techno Synth 1
U23	Techno Hit 2
U24	Techno Synth 2

S 005 Trap

#	Pattern Name
U00	Trap Beat 01
U01	Trap Beat 02
U02	Trap Beat 03
U03	Trap Beat 04
U04	Trap Beat 05
U05	Trap Beat 06
U06	Trap Beat 07
U07	Trap Beat 08
U08	Trap Beat 09
U09	Trap Beat 10
U10	Trap Beat 11
U11	Trap Beat 12
U12	Trap Beat 13
U13	Trap Beat 14
U14	Trap Beat 15
U15	Trap Beat 16
U16	Trap Beat 17
U17	Trap Synth 1
U18	Trap Chord
U19	Trap Synth 2
U20	Trap Synth 3

S 006 R&B / Funk

#	Pattern Name
U00	R&B / Funk Beat 01
U01	R&B / Funk Beat 02
U02	R&B / Funk Beat 03
U03	R&B / Funk Beat 04
U04	R&B / Funk Beat 05
U05	R&B / Funk Beat 06
U06	R&B / Funk Beat 07
U07	R&B / Funk Beat 08
U08	R&B / Funk Beat 09
U09	R&B / Funk Beat 10
U10	R&B / Funk Beat 11
U11	R&B / Funk Beat 12
U12	R&B / Funk Bass
U13	R&B / Funk Ep
U14	R&B / Funk Str

S 007 Drum & Bass

#	Pattern Name
U00	Drum & Bass Beat 01
U01	Drum & Bass Beat 02
U02	Drum & Bass Beat 03
U03	Drum & Bass Beat 04
U04	Drum & Bass Beat 05
U05	Drum & Bass Beat 06
U06	Drum & Bass Beat 07
U07	Drum & Bass Beat 08
U08	Drum & Bass Beat 09
U09	Drum & Bass Beat 10
U10	Drum & Bass Beat 11
U11	Drum & Bass Beat 12
U12	Drum & Bass Bass 1
U13	Drum & Bass Bass 2
U14	Drum & Bass Synth

S004 Glitch Hop

#	Pattern Name
U00	Glitch Hop Beat 1
U01	Glitch Hop Beat 2
U02	Glitch Hop Beat 3
U03	Glitch Hop Beat 4
U04	Glitch Hop Beat 5
U05	Glitch Hop Beat 6
U06	Glitch Hop Beat 7
U07	Glitch Hop Beat 8
U08	Glitch Hop Beat 9
U09	Glitch Hop Beat 10
U10	Glitch Hop Beat 11
U11	Glitch Hop Beat 12
U12	Glitch Hop Bass 1
U13	Glitch Hop Bass 2
U14	Glitch Hop Synth 1
U15	Glitch Hop Synth 2

S008 Breaks

#	Pattern Name
U00	Breaks 01
U01	Breaks 02
U02	Breaks 03
U03	Breaks 04
U04	Breaks 05
U05	Breaks 06
U06	Breaks 07
U07	Breaks 08
U08	Breaks 09
U09	Breaks 10
U10	Breaks 11
U11	Breaks 12
U12	Breaks Bass 1
U13	Breaks Bass 2
U14	Breaks Synth 1
U15	Breaks Synth 2

S011 Vintage Machine

#	Pattern Name
U00	Vintage Machine Beat 01
U01	Vintage Machine Beat 02
U02	Vintage Machine Beat 03
U03	Vintage Machine Beat 04
U04	Vintage Machine Beat 05
U05	Vintage Machine Beat 06
U06	Vintage Machine Beat 07
U07	Vintage Machine Beat 08
U08	Vintage Machine Beat 09
U09	Vintage Machine Beat 10
U10	Vintage Machine Beat 11
U11	Vintage Machine Beat 12
U12	Vintage Machine Beat Bass
U13	Vintage Machine Beat SQ 1
U14	Vintage Machine Beat SQ 2
U15	Vintage Machine Beat SFX

S009 Chill / Down Tempo

#	Pattern Name
U00	Chill Down Tempo Beat 01
U01	Chill Down Tempo Beat 02
U02	Chill Down Tempo Beat 03
U03	Chill Down Tempo Beat 04
U04	Chill Down Tempo Beat 05
U05	Chill Down Tempo Beat 06
U06	Chill Down Tempo Beat 07
U07	Chill Down Tempo Beat 08
U08	Chill Down Tempo Beat 09
U09	Chill Down Tempo Beat 10
U10	Chill Down Tempo Beat 11
U11	Chill Down Tempo Beat 12
U12	Chill Down Tempo Beat Bass
U13	Chill Down Tempo Beat Ep
U14	Chill Down Tempo Beat Str
U15	Chill Down Tempo Beat Pf
U16	Chill Down Tempo Beat SQ

S012 Korg Vintage Machine

#	Pattern Name
U00	Korg VintMachine Beat 01
U01	Korg VintMachine Beat 02
U02	Korg VintMachine Beat 03
U03	Korg VintMachine Beat 04
U04	Korg VintMachine Beat 05
U05	Korg VintMachine Beat 06
U06	Korg VintMachine Beat 07
U07	Korg VintMachine Beat 08
U08	Korg VintMachine Beat 09
U09	Korg VintMachine Beat 10
U10	Korg VintMachine Beat 11
U11	Korg VintMachine Beat 12
U12	Korg Vint Machine Bass
U13	Korg Vint Machine SQ
U14	Korg Vint Machine Voice
U15	Korg Vint Machine Synth

S010 Electronica

#	Pattern Name
U00	Electronica Beat 01
U01	Electronica Beat 02
U02	Electronica Beat 03
U03	Electronica Beat 04
U04	Electronica Beat 05
U05	Electronica Beat 06
U06	Electronica Beat 07
U07	Electronica Beat 08
U08	Electronica Beat 09
U09	Electronica Beat 10
U10	Electronica Beat 11
U11	Electronica Beat 12
U12	Electronica Beat 13
U13	Electronica Bass 1
U14	Electronica Bass 2
U15	Electronica Synth 1
U16	Electronica Synth 2

KORG INC.

4015-2 Yanokuchi, Inagi-City, Tokyo 206-0812 JAPAN

© 2014 KORG INC.